

OPERATOR'S MANUAL

Original instructions

TB290

Serial No. 185100001~

TB290

Serial No. 190200001~

Book No. AM3E016

OETB290_H-XQ

HYDRAULIC EXCAVATOR

TAKEUCHI



WARNING Read and understand these instructions.
Failure to do so can cause injury or death.

SAFETY ALERT SYMBOL



This symbol represents the safety alert. The message that follows the symbol contains important information about safety.

Read and understand the message to avoid personal injury or death.


It is the owner or employer's responsibility to fully instruct each operator in the proper and safe operation of all equipment. All persons using this machine should thoroughly familiarize themselves with the contents of this manual.

All operators must be instructed on the proper functions of the excavator before running the machine.

Learn and practice correct use of the machine controls in a safe, clear area before operating this machine on a job site.



WARNING



Improper operation, inspection and maintenance of this machine can cause injury or death.

Read and understand this manual before performing any operation, inspection or maintenance on this machine.

Always store this manual near at hand preferably on the machine itself. If it should be lost or damaged, immediately order a new one from your Takeuchi dealer. When transferring ownership of this machine, be sure to hand this manual to the next owner.

Takeuchi supplies machines complying with the local regulations and standards of the country of export. If your machine has been purchased in another country or from a person or company of another country, it may not have the safety devices or safety standards required for use in your country. Should you have any question about whether your machine complies with the regulations and standards of your country, contact a Takeuchi dealer.

SIGNAL WORDS

Safety messages appearing in this manual and on machine decals are identified by the words “DANGER”, “WARNING” and “CAUTION”. These signal words mean the following:



DANGER

DANGER indicates a hazard with a high level of risk which, if not avoided, will result in death or serious injury.



WARNING

WARNING indicates a hazard with a medium level of risk which, if not avoided, could result in death or serious injury.



CAUTION

CAUTION indicates a hazard with a low level of risk which, if not avoided, could result in minor moderate injury.

IMPORTANT: The word **IMPORTANT** is used to alert operators and maintenance personnel about situations which could result in damage to the machine and its components.

It is impossible to foresee every possible circumstance that might involve a potential hazard. The warnings in this manual or on the machine can not cover all possible contingencies. You must exercise all due care and follow normal safety procedures when operating the machine so as to ensure that no damage occurs to the machine, its operators or other persons.

INTRODUCTION

FOREWORD


This manual describes operation, inspection and maintenance of the machine, as well as safety instructions to be heeded during these operations.

If you have any questions about the machine, please contact a Takeuchi sales or service outlet.

- Some details in this manual may differ from those provided in the machine you are using.
- Please note that the information and specifications in this manual are subject to change without prior notice.

MANUAL STORAGE COMPARTMENT

A compartment for storing this manual is provided at the position shown on the diagram below.




1. After using the manual, place it in the plastic pouch and store it back in the manual storage compartment.

SERIAL NUMBERS


IMPORTANT: Do not remove the machine name plate with the serial number. Check the serial numbers of the machine and engine and write them down in the spaces below.

Machine number:




Engine number:

<Applicable machine models 185100001 or later>




<Applicable machine models 190200001 or later>



MACHINE DESCRIPTION

FRONT, REAR, LEFT AND RIGHT



This manual refers the front, rear, left and right of the machine as seen when sitting in the operator's seat with the dozer blade visible to the front.

DESIGNATED OPERATIONS

Use this machine primarily for the following operations:

- Excavation
- Digging ditches
- Digging side ditches
- Leveling
- Loading

FEATURES

- Hydromounted cab minimizes vibration
- Automatic travel shift-down system
- Self-adjusting shoe tension system
- Short pitch rubber crawler
- Low engine noise and exhaust emissions
- Electronic control of auxiliary hydraulic circuit
- Automatic and manual operation for engine deceleration
- Engine emergency stop system

BREAK-IN PERIOD

When the machine is new, operate the machine for the first 100 hours (as indicated on the hour meter) by following the instructions below.

Using a new machine without a break-in period will lead to quicker deterioration of machine performance and may shorten the machine's service life.

- Sufficiently warm up the engine and hydraulic oil.
- Avoid heavy loads and rapid operations. Operate with a load of about 80% the maximum load.
- Do not abruptly start up, accelerate, change directions, or stop unless necessary.

NOTES ON READING THIS MANUAL

Please note that the descriptions and diagrams included in this manual may not be applicable to your machine.

The numbers used in the illustration are with circles around them. The same numbers appear between the parentheses in the text.
(Example: ① → (1))

Symbols used in this manual

The symbols used in this manual have the following meanings.

 ,  Prohibition

 Lock

 Unlock

CONTENTS

Introduction	0-2
---------------------------	------------

Machine description	0-3
----------------------------------	------------

Safety	1-1
---------------------	------------

General precautions	1-2
Precautions when preparing	1-8
Precautions when starting	1-12
Precautions when operating	1-14
Precautions when stopping	1-23
Precautions when transporting	1-24
Precautions on maintenance	1-26
Safety signs (decals)	1-35

Controls	2-1
-----------------------	------------

Names of components	2-2
Covers	2-4
Starter key	2-4
Side cover	2-4
Fuel lid	2-5
Fuel filler port	2-5
Engine hood	2-6
Fuse box cover	2-6
Cab	2-7
Cab door	2-7
Emergency exit	2-7
Front window	2-8
Lower front window	2-9
Side window	2-10
Sun shade	2-10
Emergency hammer (optional)	2-10
Seat and seat belt	2-11
Seat	2-11
Seat belt	2-12
Air Suspension Seat	2-13
Multi-information display	2-16
Main Menu screen	2-16
Warning lamps	2-17
Indicators	2-18
Screen control key	2-23
Screen navigation	2-25
Screen navigation	2-30
Switching images	2-38
Switches	2-39
Starter switch	2-39
Engine shutdown switch	2-39
Throttle controller	2-39
Horn button	2-40

Deceleration button	2-40
Travel speed button	2-40
Auxiliary 1st switches	2-41
Auxiliary 2nd/4th switch (If equipped)	2-41
Swing/Second boom select button	2-42
Third auxiliary hydraulic switch and button (If equipped)	2-42
Auxiliary 2/4 select button (If equipped)	2-42
Third auxiliary hard-lock switch (If equipped)	2-42
DPF manual regeneration/inhibit select switch <Applicable machine models 185100001 or later>	2-43
Light switch	2-44
Wiper switch	2-45
Washer switch	2-45
Automatic deceleration switch	2-45
Power/Highland mode switch	2-46
Detent mode switch (Auxiliary 1st)	2-46
Auxiliary 1st auto tank switch (If equipped)	2-47
Lift overload warning switch	2-47
Beacon lamp switch	2-47
Levers and Pedals	2-48
Safety lock lever	2-48
Operating levers	2-48
Blade lever	2-49
Travel levers/pedals	2-50
Boom swing/Second boom pedal	2-50
Accessories	2-51
Air conditioner	2-51
Cup holder	2-56
Cigarette lighter	2-57
Ashtray	2-57
Interior light	2-58
External power sockets	2-59
Radio	2-60
Radio (Bluetooth equipped)	2-64
Auxiliary hydraulic lines	2-76
Operating the machine with an accumulator	2-82
Load safety device (If equipped)	2-83
Fuel Supply Pump (If equipped)	2-85
Engine auto stop	2-85
Mirrors	2-86
Camera	2-88
Auto camera mode	2-89

Operation3-1

Before starting operation	3-2
Getting on or off the machine.....	3-2
Walk-around inspection	3-2
Daily inspection.....	3-2
Starting and stopping the engine	3-3
Before starting the engine	3-3
Starting the Engine	3-4
Warming up the engine.....	3-6
Stopping the engine	3-6
Operating the machine	3-8
Lever pattern (ISO pattern).....	3-8
Lever pattern (G pattern) (If equipped)..	3-9
Warming up the machine (hydraulic oil).....	3-10
Inspection after warm-up.....	3-11
Operating the travel levers/pedals.....	3-12
Stopping travel	3-15
Operating the working equipment	3-16
Operating procedures.....	3-18
Prohibited operations.....	3-18
Cautions on operating	3-21
Cautions on traveling on slopes	3-22
Getting out of mud	3-24
Operations possible with this machine.....	3-24
Parking the machine.....	3-26
Parking.....	3-26
Inspection and checks after stopping the engine.....	3-26
Handling in cold climates.....	3-27
Preparing for cold climates	3-27
Cautions after operations.....	3-27
After the cold climate	3-27
Handling rubber crawlers.....	3-28
Prohibitions.....	3-28
Cautions.....	3-29
Preventing the rubber crawlers from coming off	3-29
Handling the engine.....	3-31
Prohibitions.....	3-31
Cautions.....	3-31
Diesel fuel.....	3-31

Transport4-1

Loading and unloading	4-2
Hoisting the machine	4-4
Securing the machine.....	4-6

Maintenance5-1

General.....	5-2
Maintenance overview	5-2
Cautions on maintenance	5-2
Service data	5-4
Fuel and lubricant table.....	5-4
Regularly replace the hydraulic oil	5-8
List of consumables.....	5-9
List of tools (If equipped).....	5-10
List of tightening torques	5-11
Safety-critical parts.....	5-12
Maintenance list <Applicable machine models 185100001 or later>	5-14
Maintenance list <Applicable machine models 190200001 or later >	5-16
Walk-around inspection	5-18
Inspecting by opening the engine hood and covers.....	5-18
Inspecting by walking around the machine.....	5-19
Inspecting while sitting in the operator's seat	5-19
Daily inspection (every 10 hours).....	5-20
Inspecting and replenishing the coolant	5-20
Inspecting and replenishing the engine oil.....	5-21
Inspecting the water separator and the fuel filters	5-22
Inspecting the fuel level.....	5-23
Inspecting the hydraulic oil tank level and replenishing	5-24
Lubricating the working equipment	5-25
After the initial 50 hours (only for new machines)	5-26
Inspecting and adjusting the fan belt..	5-26
Inspecting and adjusting the compressor belt (AC)	5-28
Every 50 hours	5-30
Inspecting the crawler belt tension.....	5-30
Lubricating the slew bearing	5-30
Draining the water from the fuel tank..	5-31
Inspecting the battery fluid level and replenishing	5-32
After the initial 250 hours (only for new machines)	5-34
Replacing the hydraulic oil return filter	5-34
Replacing the pilot line filter.....	5-35

Replacing the travel motor gear oil.....	5-36
Every 250 hours	5-37
Inspecting and adjusting the fan belt..	5-37
Inspecting and adjusting the compressor belt (AC)	5-37
Replacing the engine oil and the oil filter	5-38
Cleaning the air cleaner	5-40
Cleaning the radiator fins and the oil cooler fins.....	5-41
Cleaning the air filters (AC)	5-42
Cleaning the condenser (AC)	5-43
Inspecting the refrigerant (gas) level (AC)	5-44
Every 500 hours	5-46
Replacing the fuel filter.....	5-46
Replacing the water separator filter <Applicable machine models 185100001 or later>	5-47
Cleaning the feed pump filter <Applicable machine models 190200001 or later>	5-48
Inspecting the slew pinion gear	5-48
Inspecting and cleaning the supply pump strainer <Applicable machine models 190200001 or later>	5-49
Every 1000 hours	5-50
Replacing the hydraulic oil return filter	5-50
Replacing the pilot line filter.....	5-50
Replacing the travel motor gear oil.....	5-50
Cleaning the engine cooling system <Applicable machine models 190200001 or later>	5-50
Replacing the air cleaner element	5-52
Replacing the air breather filter	5-53
Inspecting and adjusting the engine valve clearance	5-53
Inspecting the engine compression pressure <Applicable machine models 190200001 or later>	5-53
Inspecting and cleaning the engine starter and the alternator <Applicable machine models 190200001 or later>	5-53
Every 1500 hours	5-54
Inspecting the crankcase breather system <Applicable machine models 185100001 or later>	5-54
Inspecting and replacing the air filter case for cracking <Applicable machine models 190200001 or later>	5-54
Inspecting and cleaning the EGR cooler <Applicable machine models 190200001 or later>	5-54
Every 2000 hours	5-55
Cleaning the engine cooling system <Applicable machine models 185100001 or later>	5-55
Every 3000 hours	5-56
Inspecting the turbocharger (blow wash as necessary)	5-56
Inspecting, cleaning and checking operation of the EGR valve <Applicable machine models: 185100001 or later>	5-56
Cleaning the EGR lead valve <Applicable machine models 185100001 or later>	5-56
Cleaning the EGR cooler (cleaning the water side and exhaust air passage blower) <Applicable machine models 185100001 or later>	5-56
Inspecting the operation of the air intake throttle valve <Applicable machine models 185100001 or later>	5-56
Inspecting and cleaning the fuel injector	5-56
Inspecting and cleaning the EGR valve <Applicable machine models 190200001 or later>	5-56
Inspecting the engine controller (ECM) <Applicable machine models 190200001 or later>	5-56
Every 4000 hours	5-57
Replacing the hydraulic oil and cleaning the suction strainer	5-57
When required	5-62
Replacing the bucket teeth and the side cutters.....	5-62
Replacing the bucket	5-64
Adjusting the gap between the bucket and arm (If equipped)	5-66
Inspecting and replenishing the windshield washer fluid	5-67
Inspecting and cleaning the DPF soot filter <Applicable machine models: 185100001 or later>	5-67

Draining the water from the water separator <Applicable machine models 185100001 or later>.....	5-68
Draining the water from the water separator <Applicable machine models 190200001 or later>.....	5-69
Lubricating the levers and pedals.....	5-70
Inspecting the rubber crawlers.....	5-71
Replacing the rubber crawlers	5-72
Every 2 years.....	5-74
Replacing the receiver dryer.....	5-74
Maintenance during extended storage period.....	5-75

Troubleshooting6-1

Symptoms that are not malfunctions	6-2
If the engine overheats.....	6-3
If the battery goes dead.....	6-4
If a fuse blows	6-6
Inspecting and replacing the fuse.....	6-6
Inspecting the fusible link.....	6-7
Restarting after adding fuel	6-8
Bleeding air from the fuel system	6-8
If a warning lamp flashes	6-10
Vehicle error code list.....	6-12
Engine error code list.....	6-14
Other symptoms.....	6-26
Lowering the boom to the ground	6-29
Towing.....	6-30
If the cab is damaged	6-31
Exhaust gas control system error.....	6-32
Error code list	6-33
NOx control diagnostic system (NCD). ..	6-33
Particulate control diagnostic system (PCD)	6-33
Limiting the engine output.....	6-34

Specifications7-1

Basic Specifications.....	7-2
Machine dimensions.....	7-4
Operating ranges.....	7-10
Lifting Capacities	7-17

Options8-1

General precautions	8-2
Safety precautions	8-2
Cautions when installing attachments ..	8-2
Cautions when operating attachments.....	8-3
Attachment combination table	8-4
Selecting a lever pattern	8-5

Switching the lever pattern	8-5
Hydraulic breaker	8-6
Cautions on operating	8-6
Replacing the hydraulic oil regularly	8-7
Travel alarm	8-8
Optional equipment mass	8-9
Biodegradable oil.....	8-10
Replacing the hydraulic oil with biodegradable oil	8-10
Cab options.....	8-11
Angle dozer blade.....	8-12
Specifications	8-13
Operating lever switch kit 1.....	8-14
Horn button	8-14
Deceleration button	8-14
Travel speed button	8-14
Auxiliary 1st switches.....	8-15
Auxiliary 2nd/4th switch.....	8-15
Auxiliary 2/4 select button.....	8-16
Swing/Second boom select button....	8-16
Takeuchi Security System	8-18
Starter key	8-18
Starting the engine.....	8-18
Registering and deleting the starter key	8-19
If the master key is lost	8-25
Countries where the system can be used	8-25
LED Lights.....	8-26





GENERAL PRECAUTIONS

It is your responsibility to observe all pertinent laws and regulations and to follow the manufacture's instructions on machine operation, inspection and maintenance.

Virtually all accidents occur as the result of a failure to observe basic safety rules and precautions.

Most accidents can be prevented by identifying the potentially hazardous situations beforehand.

Read and understand all safety messages which describe how to prevent accidents.

Do not operate the machine until you are sure that you have gained a proper understanding of its operation, inspection and maintenance.

Observe all safety rules

- Operation, inspection and maintenance of this machine must be performed only by a trained and qualified person.
- All rules, regulations, precautions and safety procedures must be understood and followed when performing operation, inspection and maintenance of this machine.
- Do not perform any operation, inspection and maintenance of this machine when under the adverse influence of alcohol, drugs, medication, fatigue, or insufficient sleep.

When a problem is found on the machine

If any problem (noise, vibration, smell, disorder of instrument, smoke, oil leak, wrong indication of alarm or unusual indication in the instrument cluster, etc.) is detected during the operation or inspection and maintenance of the machine, immediately inform your sales or service dealer and take proper actions. Do not operate the machine until the trouble is cleared.

Operating temperature range

To maintain the performance of machine and to prevent it from early wear, observe the following operating conditions.

- Do not operate the machine if the ambient temperature is higher than +45°C (+113°F) or lower than -15°C (+5°F).
 - If operated at an ambient temperature of higher than +45°C (+113°F), the engine may overheat and cause the engine oil to degrade. Also, the hydraulic oil may become very hot, causing damage to the hydraulic equipment.
 - If operated at an ambient temperature of lower than -15°C (+5°F), the parts made of rubber such as gaskets may get hardened to cause an early wear or damage to the machine.
 - If the machine is to be used outside the ambient temperature range described above, consult your sales or a service dealer.



SAFETY


GENERAL PRECAUTIONS

Wear appropriate clothing and protective equipment



- Do not wear loose clothing or any accessory that can catch on controls or in moving parts.
- Do not wear oily or fuel stained clothing that can easily catch fire.
- Wear a hard hat, safety shoes, safety glasses, filter mask, heavy gloves, ear protection and other protective equipment as required by job conditions. Wear required appropriate equipment such as safety glasses and filter mask when using grinders, hammers or compressed air, as metal fragments or other objects can fly and cause serious injury.
- Use hearing protection when operating the machine. Loud prolonged noise can cause hearing impairments, even the total loss of hearing.


Install a fire extinguisher and first aid kit




Be prepared for fire and accidents

- Install an extinguisher and a first aid kit, and learn how to use them.
- Learn how to fight a fire and how to deal with accidents.
- Know how to contact emergency assistance and make a list of emergency contacts.

Never remove safety equipment




- Make sure all protective guards, covers and doors are in place and secured. Repair or replace damaged parts before operating the machine.
- Know how to use the safety lock lever, seat belt and other safety equipment and use them properly.
- Never remove any safety equipment except for servicing. Keep all safety equipment in good operating condition.

**Use a signal person and a flag person**

Learn how to use the hand signals required for particular jobs and make sure who has the responsibility for signaling.

- All personnel must fully understand all the signals.
- The operator must respond to signals only from the appointed signal person, but must obey a stop signal at any time from anyone.
- The signal person must stand in a clearly visible location when giving signals.


Cautions when standing up from or leaving the operator's seat

- Before standing up from the operator's seat to open/close the window or remove/install the lower window, lower the working equipment to the ground, raise the safety lock lever to engage the lock and stop the engine. If any controls should be accidentally touched when the safety lock lever is lowered (unlocked), the machine will suddenly move and cause serious injury or death.
- Be careful not to touch the operating levers when raising or lowering the safety lock lever.
- Before leaving the operator's seat, lower the working equipment to the ground, raise the safety lock lever to engage the lock and stop the engine. Also, be sure to remove the key, lock the door and covers, take it with you and store it in a specified place.

**Avoid fire and explosion hazards**

Keep flames away from fuel, oil, grease and antifreeze. Fuel is particularly flammable and dangerous.

- When handling these combustible materials, keep lit cigarettes, matches, lighters and other flames or sources of flames away.
- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Do not leave the location while refilling with fuel or oil.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Also, do not spill the fuel on the hot surface of the machine or the component of the electric system.
- Clean up spilled fuel or oil immediately.
- Check for fuel, oil leak. Stop all leaks and clean the machine before operating.
- When operating with grinder or welding, move inflammables to a safe place.
- Do not cut or weld on pipes or tubes that contain flammable fluids. Clean thoroughly with nonflammable solvent before cutting or welding.
- Remove all trash or debris from the machine. Make sure that oily rags or other flammable material are not stored on the machine.
- Handle all solvents and dry chemicals (foam type fire extinguisher) according to procedures identified on manufacturer's containers. Work in a well-ventilated area.
- Never use fuel for cleaning purposes. Always use a nonflammable solvent.
- When handling the fuel, washing oil or paint, open the door and windows to ventilate thoroughly.
- Store all flammable fluids and materials in a safe and well-ventilated place.
- The short circuit of the electric system may cause the fire. Check for any loosened connections or damage to the wires every day. Retighten the loosened connector and wire clamp. Fix or change the damaged wire.
- Fire from the pipes:
Make sure that the clamps, guards and cushions of the hoses and tubes are securely fixed. If not, hoses or tubes may be damaged due to vibration or contact with other parts during operation. This can cause the high-pressure oil to spurt out, resulting in the fire or injury.
- Do not perform the DPF regeneration if the machine is surrounded by flammable items such as plants, trees, dry grass, wastepaper, oil and waste tires. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF.
DPF: Diesel Particulate Filter
<Applicable machine models 185100001 or later>

**Exhaust fumes from the engine are poisonous**

AG7A011

- Do not operate the engine in an enclosed area without adequate ventilation.
- If natural ventilation is not possible, install ventilators, fans, exhaust extension pipes or other venting devices.
- Do not perform the DPF regeneration in poorly-ventilated indoor spaces, as smoke could be generated during the DPF regeneration or carbon monoxide poisoning could result.

Handling asbestos dust

Inhaling asbestos dust can cause lung cancer. When handling the materials which may contain asbestos, take the following precautions:

- Never use compressed air for cleaning.
- Avoid brushing or grinding parts containing asbestos.
- For clean up, use a vacuum equipped with a high efficiency particulate air filter (HEPA).
- Wear the stipulated respirator if there is no other way to control the dust. When working indoors, install a ventilation system with a macromolecular filter.
- Do not allow unauthorized personnel in the work area while working.
- Follow the rules and environmental standard applicable to the work area.

Be careful not to get crushed or cut

AG7A013

Never put your hands, feet or other parts of your body between the upperstructure and the undercarriage or tracks, between the machine body and working equipment, or between a cylinder and moving part. The sizes of these gaps change when the machine moves, and a person can suffer severe injury or death.

**Using optional products**

- Consult with Takeuchi before installing optional attachments. Depending on the type of attachments or the combination of them, the attachment may come into contact with the operator's compartment or the other parts of the machine. Make sure that the optional attachment installed is not contacted with other parts before use.
- Do not use attachments that have not been approved by Takeuchi. Doing so may compromise safety or adversely affect the machine's operation or service life.
- Takeuchi will not be held responsible for any injuries, accidents or damage to its products caused by the use by a non-approved attachment.

Never modify the machine

Unauthorized modifications to this machine can cause injury or death. Never make unauthorized modifications to any part of this machine.

If you modify or alter the configuration of the machine in a way which results in a restriction of the operator's field of vision, a new risk assessment will need to be performed. If this becomes necessary, contact your Takeuchi service or sales dealer.




PRECAUTIONS WHEN PREPARING

Know the work area

Before starting operation, know the working area condition to ensure safe operation.

- Inspect the topography and ground condition of the working area, or the structure of the building when working indoors, and take the safety precautions as necessary.
- Be sure to avoid all hazards and obstructions such as ditches, underground lines, trees, cliffs, overhead electrical wires, or places where there is a danger of falling rocks or slides.



- Check with the administrator for the locations of buried gas pipes, water pipes and power cables. If necessary, determine what specific precautions must be taken to insure safety by consulting with the administrator.
- When working on roads, be sure to consider the safety of pedestrians and vehicles.
 - Use a flag person and/or a signal.
 - Fence off the working area and keep off unauthorized persons.
- When working in water or crossing shallow streams or creeks, check the depth of the water, the solidity of the ground and the water flow speed beforehand. Refer to "Cautions on operating" for further instructions.

<Applicable machine models 185100001 or later>




- Do not perform the DPF regeneration if the machine is surrounded by flammable items such as plants, trees, dry grass, wastepaper, oil and waste tires. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF. DPF: Diesel Particulate Filter
- The DPF may automatically perform the regeneration while the engine is left running. Make sure that there are no flammable items around the DPF and the exhaust line, and also that the engine hood is closed to prevent fire. Be careful not to burn yourself on the high-temperature exhaust gas.
- Do not perform the DPF regeneration in poorly-ventilated indoor spaces, as smoke could be generated during the DPF regeneration or carbon monoxide poisoning could result.




Check the strength of the bridge


When traveling over a bridge or a structure, check the permissible load. If the strength is insufficient, reinforce the bridge or the structure.



Always keep the machine clean



- Wipe off any oil, grease, mud, snow or ice, to prevent accidents due to slipping.
- Remove all loose objects and unnecessary devices from the machine.
- Remove any dirt, oil or grease from the engine area to prevent fires.
- Clean around the operator's seat and remove any unnecessary object from the machine.

**Perform inspection and maintenance every day**

Failure to identify or repair the irregularities or damage on machine can lead to accidents.

- Before operating, perform the specified inspection and make prompt repairs where necessary.
- If a failure occurs and the operation becomes impossible or the engine fails, immediately stop the machine by following the shutdown procedure, and keep machine securely parked until the malfunction is corrected.


Cautions in the operator's compartment

- Remove mud and grease from shoe soles before entering the operator's compartment. Pedaling the machine with the shoes with mud and grease will cause a slip accident.
- Do not leave the parts or tools around the operator's seat.
- Do not leave any plastic bottles in the operator's compartment or attach any suction cups on the window glass. The plastic bottle or suction cup act as a lens and can cause fire.
- Do not use the mobile phone during traveling or working.
- Do not bring combustibles or explosives into the operator's compartment.
- After smoking, be sure to tightly close the lid of the ashtray to put out the match or cigarette.
- Do not leave the cigarette lighter in the operator's compartment. When the room temperature rises, the lighter may explore.




Emergency exit

Front window (excluding machines with a front guard)



If you should become trapped inside the cab, open the front window to get out.

Emergency hammer (optional)



An emergency hammer is installed to be used to escape from the cab in an emergency. When escaping, break the windows with the hammer.

- When breaking the windowpane with a hammer, take great care not to injure yourself with the broken glass pieces.
- Remove the glass pieces from the window sill so as not to cut yourself when evacuating. Broken glass will fall from the window, so be careful of your footing and do not slip on the glass.



PRECAUTIONS WHEN STARTING

Support your weight in a three point secure stance when getting on/off the machine

- Do not jump on or down from the machine. Never attempt to get on or off the moving machine.
- When getting on or off the cab, first fully open the door to the locked position and check that it does not move (for machines with cab).



- Climb up/down the steps facing the machine and holding the handrail to support your weight in a three point secure stance (hand and feet).
- Never use the safety lock lever or control levers as hand holds.

Before starting the machine, ask any unauthorized personnel to leave the area

Do not start the engine until you are sure it is safe to start the machine by checking the following items.

- Walk around the machine and warn the person who is servicing the machine or is walking near the machine. Do not start the machine until you are certain that no one is around the machine.



- Check if there is a “DO NOT OPERATE” alert sign or similar sign is on the cab door, controls or starter switch. If there is one, do not start the engine or touch any levers.
- Sound the horn to warn people around the machine.

Sit in the operator's seat and start the engine


- Adjust the seat to securely latch it.



- Fasten the seat belt.
- Check if the parking brake is on and all control levers and pedals are in the neutral position.
- Check if the safety lock lever is in the lock position.
- Make sure that no one is near the machine.
- Start and operate the machine only from the operator's seat.
- Never attempt to start the engine by shorting across the starter terminals.



Starting with jumper cables



Use jumper cables only in the recommended manner. Improper use of jumper cables can result in battery explosion or unexpected machine motion.

Refer to “If the battery goes dead” for further instructions.

After starting the engine

After starting the engine, perform the operations and checks described below in a safe place with no persons or obstacles in the area. If any malfunction is found, follow the shutdown procedure and report the malfunction.

- Warm up the engine and hydraulic oil.
- Check if all gauges and warning devices are properly working.
- Check for any noises.
- Test the engine speed control.
- Operate each control to ensure they are properly working.

In cold climates



- Be careful of slippery conditions on freezing ground, steps and hand holds.
- In severe cold climates, do not touch any metal parts of the machine with bare hands. The skin will freeze to the metal, resulting in severe injury.
- Do not use ether or starting fluid on this engine. The starting fluids can cause explosion and serious injury or death.
- Warm up the engine and hydraulic oil. If the levers are operated without warming, the machine will not react or move promptly or properly, resulting in accident.



PRECAUTIONS WHEN OPERATING

Ensure good visibility

Check the field of view before operating the machine.


- When working in dark places, turn on the machine's working lights and headlights and additional lighting equipment installed, as necessary.
- When visibility is poor due to bad weather (fog, snow, rain or a cloud of dust), stop operating the machine and wait until visibility improves.
- Clean the windows, mirrors, lights and camera to ensure good visibility. Adjust the mirror and camera to the best positions so that the operator can see the rear view (blind spots) from the operator's seat.
- Unauthorized machine modifications or installation of unapproved attachments could impair the visibility. The operator's field of view must conform to ISO 5006.

Do not permit riders on the machine



Do not allow anyone to ride on any part of the machine at any time while traveling or operating.

Check if the work area is safe and secure before operation




- Confirm the performance limits of the machine.
- Use a signal person at road shoulders, narrow places or where your vision is obstructed.
- Never allow anyone to enter the machine's slewing radius and path.
- Signal your intention to move by sounding the horn.
- There is a blind spot in the rear of the machine. Before traveling in reverse, check that the area is safe and clear.

Safety precautions when performing the DPF regeneration


The DPF may automatically perform the regeneration while the engine is left running. Make sure that there are no flammable items around the DPF and the exhaust line, and also that the engine hood is closed to prevent fire. Be careful not to burn yourself on the high-temperature exhaust gas.

DPF: Diesel Particulate Filter

<Applicable machine models 185100001 or later>

**Check the position of the undercarriage (tracks) before traveling**


Before operating the travel levers/pedals, make sure that the dozer blade is to the front of the operator's seat. Remember that when the dozer blade is to the rear of the operator's seat, the travel levers/pedals must be operated in the reverse direction from when it is to the front.

Travel safely

- Travel with the dozer blade raised, the hoe attachment folded as shown on the figure above, and the bucket raised 30 to 40 cm (12 to 16 in.) above the ground.
- Do not slew while traveling. If you must operate the hoe attachment while traveling, operate at speeds slow enough so you have complete control at all times.
- When a load greater than a set value is applied during traveling in 2nd (high) speed, the speed will automatically slow down to 1st (low) speed. When the load becomes lighter, the speed will increase and return to 2nd (high) speed. It should be

noted that the travel speed changes depending on the load condition (for machines with the automatic travel shift-down system).

- When traveling on the uneven road or sharp slope, turn off the deceleration switch and the auto-deceleration switch. If the machine is operated on such roads with these switches turned on, the engine speed may increase, causing the machine to travel unexpectedly rapidly (for machines with the deceleration and auto-deceleration switches).





- Avoid crossing over obstacles whenever possible. If you must do so, keep the hoe attachment close to the ground level and travel slowly. Never cross obstacles which will tilt the machine to an angle of 10° or greater.
- On uneven ground, maintain the low speed and avoid starting, stopping or changing directions abruptly. Otherwise, the working equipment may come in contact with the ground, causing the machine to lose its balance and get damaged or to damage the structures in the surrounding area.


**Cautions on traveling on slopes**

When traveling on slopes or grades, be careful that the machine does not tip (roll) over or slide.

- Never travel on slopes that are too steep for the machine to maintain its stability (maximum gradeability: 35°, lateral tipping angle: 15°). Note that in reality, the machine's stability becomes lower than the above values depending on the working condition.



- When traveling on slopes or grades, drive slowly in 1st (low) speed. When descending a slope, slow down the engine speed.
- Do not descend slopes in reverse.




- Do not change directions on slopes or traverse slopes. First return to a flat surface, and then take an alternative path.
- The machine may slip sideways even on a slight slope if the ground is covered with grass or dead leaves, or when traveling on a wet metal plate or frozen surfaces. Make sure the machine is never positioned sideways on slopes.
- If the machine is stalled on the slope, return each operating lever to the neutral position before restarting the engine.

- When climbing a hill, keep the operator's seat facing the hillside. When descending a hill, keep the operator's seat facing the downhill direction. In either case, travel must be done while paying attention to the ground in front of the machine.
- When traveling on slopes, lower the bucket to a height of 20 to 30 cm (8 to 12 in.) above the ground. When climbing a steep slope, extend the hoe attachment to the front. In emergencies, lower the bucket to the ground and stop the machine.


**Operate the machine on snow or ice with extra care**

- When traveling on snow or on frozen surfaces, drive at a low speed and avoid starting, stopping or changing directions abruptly.
- In the snowy area, the road shoulder and objects placed beside the road are buried in the snow and cannot be seen. There is a hazard of the machine tipping over or hitting covered objects, so always carry out operations carefully.
- If the machine enters deep snow, there is a hazard that it may tip over or become buried in the snow.
Be careful not to drive beyond the road shoulder or to get trapped in a snow drift.
- With frozen ground surfaces, the ground becomes soft when the temperature rises, and this may cause the machine to tip over, resulting in an operator trapped inside the machine.
- When parking the machine on an unstable ground, lower the dozer blade.

Ensure driver's safety when loading

Do not load a truck unless the truck driver is in a safe place.

- Never swing or position the bucket over a person or the cab room.
- Load the truck from the rear.

Do not move the bucket over the heads of people


Moving the bucket over the heads of people entails the danger of the load spilling or the sudden dropping of the bucket.



SAFETY


PRECAUTIONS WHEN OPERATING

Keep a safe distance from the overhead high-voltage cables



Never bring any part of the machine or loaded material to near to the high voltage cables unless all safety precautions required by the local and national authorities have been installed. If a person comes near to the machine that is discharging sparks or located near to or in contact with the power source, there is a hazard of electric shock and death.

- Always maintain a safe distance between the machine and the high-voltage electric cable.
- Check with the local power company about safe operating procedure before starting operations.
- Consider all cables to be high-voltage cables and treat all cables as energized even though it is known or believed that the power is shut off and the cables are visibly grounded.
- Use a signal person to give warning if the machine approaches too close to the high-voltage electric cables.
- Caution all personnel in the work area not to come close to the machine or the loaded material.




- Pay also careful attention to the high-voltage electric cables buried underground.




SAFETY

PRECAUTIONS WHEN OPERATING


Watch out for hazardous working conditions




- Never undercut a high bank. Doing so is dangerous as it may cause ground collapse.
- Do not operate in places where there is a danger of falling rocks.



- Maintain a safe distance between the machine and the edge of the digging site. Do not dig the ground under the front of the machine.
- When working close to the cliffs or road shoulders, to make it easier to escape if there is any problem, set the crawlers at right angles to the cliff or road shoulder and the dozer blade to the front when carrying out operations.



- Do not enter areas where there is soft ground. Doing so could cause the machine to tilt under its own weight, resulting in a machine tipping over or sinking into the ground.




- Do not come close to unstable grounds (cliffs, road shoulders, deep ditches). If the ground should collapse under the weight or vibration of the machine, there is a hazard that the machine may fall or tip over.
 - Remember that the soil after heavy rain or blasting is weak.
 - The ground of top of the embankment and of the circumferences of the excavated ditches are also weak.



SAFETY

PRECAUTIONS WHEN OPERATING




- Do not perform demolition work under the machine. There is a hazard that the machine may fall down, because the ground becomes unstable.
- When working on or from the top of buildings or other structures, check the strength and the structure before starting operations. If a building or structure collapses, serious injury or damage will result.


- Do not use the impact force of the hoe attachment for breaking work. There is a hazard of serious injury being caused by flying pieces of broken materials and by the damaged hoe attachment.

Be careful with flying objects

This machine is not equipped with protective equipment to protect the operator from flying objects. Do not use this machine in places where there are risks of the operator being hit by flying objects.




- When doing demolition work, do not perform demolition above your head. There is a hazard of broken parts falling or of the building collapsing and causing serious injury or damage.






Operating on slopes is dangerous

When operating on slopes or grades, slewing or operation of working equipment may cause the machine to lose stability and tip over. Avoid operating on slopes whenever possible.




- Level off the work area.



- Avoid slewing to the downhill direction with the bucket full of loaded material. This will reduce the stability of the machine and may result in tipping over.


Never slew (swing) sideways with a heavy load



The machine can tip over more easily in the lateral direction than in the longitudinal direction.

- Do not slew (swing) sideways with a heavy load at the tip of the hoe attachment. In particular, do not slew (swing) sideways on slopes.
- The tip of the attachment is heavier for machines equipped with breakers, crushers or long arms than for machines equipped with the standard bucket. For such machines with heavier tips, do not perform excavation with the digging arm (boom) facing the downhill direction or operate toward sideways.

Be careful with the overhead objects



When operating under bridges, in tunnels, near electric cables or indoors, be careful not to let the boom or arm hit overhead objects.



Excavators are not designed for lifting loads




AG7A054

This machine is specifically designed for excavation work. Therefore, it has no safety equipment for crane operation. Extreme caution should be paid if the excavator is used for lifting.

- Never lift loads in excess of capacity. Overload will cause the machine to roll and can result in serious injury or death.
- All rated lift capacities are determined by using a machine placed on a stable and flat ground. For a safe lifting work, the user is expected to make due allowance for the particular job conditions. They include, soft or uneven ground, non-level condition, side loads, dynamic or jerked loads, hazardous conditions, and experience of personnel. The operator and other personnel should fully acquaint themselves with the operator's manual before operating this machine, and rules for safe operation of equipment shall be adhered to at all times.
- The bucket linkage or lifting device may fail if chains or lifting device are incorrectly attached, resulting in serious injury or death.
- Do not attempt to pull stumps out of the ground when using the machine as a crane. The loads imposed on the machine under this use are completely unknown.
- Do not allow anyone to stand on or under the lifted loads or come close to the work area.

Cautions when towing



When towing, serious injury or death could result, if performed incorrectly or the wire rope being used is inappropriate or not properly inspected.


- Do not tow using only a towing hole on one side.
- It becomes dangerous if the wire rope breaks or becomes disengaged. Use a wire rope appropriate for the required tractive force.
- Do not use a wire rope that is kinked, twisted or otherwise damaged.
- Do not apply heavy loads abruptly to the wire rope.
- Wear safety gloves when handling the wire rope.
- Make sure there is an operator on the machine being towed as well as on the machine that is towing.
- Never tow on slopes.
- Do not let anyone come near to the wire rope while towing.

Refer to "Towing" for further instructions.




PRECAUTIONS WHEN STOPPING

Park safely




- Park the machine on a flat, rigid and safe ground. Set the parking brake.



If you must park on a slope or incline, park the machine securely and block the movement of the machine.

- When parking on a street, use barriers, caution signs, lights, etc., so that the machine can easily be seen even at night to avoid collision with other vehicles.




- Before leaving the machine, do the followings:
 1. Lower the bucket and the dozer blade to the ground.
 2. Raise the safety lock lever to the locked position.
 3. Stop the engine and remove the starter key.
 4. Lock the cab and covers and take the key with you.



PRECAUTIONS WHEN TRANSPORTING

Load/unload the machine safely



The machine may roll or tip over or fall while being loaded or unloaded. Take the following precautions:

- Select a firm, level surface and keep sufficient distance from road shoulders.
- Secure the ramps of adequate strength and size to the truck bed. The slope of the ramps must not exceed 15°. If the ramps are bowed down too low, support them with poles or blocks.
- Never use the working equipment to load or unload the machine. Doing so may result in tipping over or falling down of the machine.
- Keep the truck bed and loading ramps clean of oil, soil, ice, snow, and other materials to prevent the machine from sliding sideways. Clean the crawlers.
- Chock the transporter wheels to prevent movement.
- Turn off the deceleration switch and auto-deceleration switch. Otherwise, the engine speed may suddenly increase to cause troubles.
- When being loaded or unloaded, travel slowly in 1st (low) gear by following the signal from the signal person.
- Never change courses on the ramps.
- Do not slew/swing on the ramps. The machine may tip over.
- When slewing/swinging on the truck bed, do it slowly as the footing should be unstable.

- Lock the cab door after being loaded, if applicable. Otherwise, the door may open during transport.
- Chock the tracks and secure the machine to the truck bed with wire rope or chain.

**Hoist the machine safely**

- Know and use correct crane signals.
- Check the hoisting equipment for damaged or missing parts on a daily basis and replace as necessary.
- When hoisting, use a wire rope capable of lifting the machine mass.
- Hoist the machine in such a manner described in the procedure below. Do not do it in any other manner, as it may result in the machine losing its balance. Refer to “Hoisting the machine” for further instructions.
- Do not hoist the machine with an operator on it.
- When hoisting, hoist slowly so that the machine does not tip.
- Keep everyone out of the area when hoisting. Do not move the machine over the heads of the persons.

Transport the machine safely

- Know and follow the applicable safety rules, vehicle code and traffic laws when transporting the machine.
- Select the best transport route by considering the length, width, height and weight of the truck with the machine loaded on it.
- Never abruptly start or stop or run at a high speed at the sharp curves during transport. Doing so will move or lose the balance of the loaded machine.



PRECAUTIONS ON MAINTENANCE

Display a “DO NOT OPERATE” alert sign

Severe injury could result if an unauthorized person should start the engine or touch controls during inspection or maintenance.

- Before performing maintenance, stop the engine, remove the key and take it with you.



AG7A023PE

- Display a “DO NOT OPERATE” alert sign on easy-to-see locations such as on the starter switch or on control levers.

Use the correct tools



AG7A065

Do not use damaged or weakened tools or tools designed for other purposes. Use tools appropriate for the work involved.

Replace safety-critical parts periodically


- Replace fuel hoses periodically. Fuel hoses wear out over time, even if they do not show any symptom of wear.
 - Regardless of the replacement schedule, replace immediately if a symptom of wear is found.
- Refer to “List of safety-critical parts” for further details.

Explosionproof lighting



AG7A067


To prevent an ignition or explosion, use explosion-proof lights when inspecting fuel, oil, coolant or battery fluid. Otherwise, explosion could result causing serious injury or death.

**Prohibit access by unauthorized persons**

Do not allow unauthorized personnel in the work area while working. Be careful when grinding, welding or using a hammer. You could be injured by flying debris from the machine.

Prepare work area

- Select a firm, level work area. Make sure there is adequate light and, if indoors, ventilation.
- Clear obstacles and dangerous objects. Eliminate slippery areas.

Always keep the machine clean

- Clean the machine before performing maintenance.
- Stop the engine before washing the machine. Cover the electrical parts so that water cannot enter. Water on electrical parts could cause short-circuits or malfunctions. Do not use water or steam to wash the battery, electronic control components, sensors, connectors or the operator's compartment.

Stop the engine before performing maintenance


- Avoid lubrication or mechanical adjustments while the machine is moving or while the engine is running when the machine is not moving.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
 - One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
 - The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.



SAFETY

PRECAUTIONS ON MAINTENANCE

Stay clear of the moving parts



- Stay clear of all rotating and moving parts. If a hand or tool becomes trapped in the rotating or moving part, serious injury or death could result.
- If a tool or other objects is dropped or inserted in the fan or fan belt, it will be flown or cut in pieces. Do not drop or insert anything in the fan or fan belt.

Firmly secure the machine or any component that may fall



- Before performing maintenance or repairs under the machine, lower all moveable working equipment to the ground or in the lowermost position.
- Chock the tracks.
- If you must work beneath the raised machine or equipment, always use wood blocks, jack-stands or other rigid and stable supports. Never get under the machine or working equipment if they are not sufficiently supported. This procedure is especially important when working on hydraulic cylinders.

Secure the working equipment

To prevent unexpected movement, firmly secure the working equipment when repairing or replacing the bucket teeth or side cutter.

Secure the engine hood or cover when opened

Be sure to secure the engine hood or cover before working the inside. Do not keep the hood or cover open on a windy day or if the machine is parked on a slope.

Place heavy objects in a stable position



When it is necessary to temporarily place a heavy object or an attachment on the ground during removal or installation, be sure to place it in a stable position. Keep unauthorized persons from the storage place for such object.



Cautions when refueling



- Do not smoke or permit open flames while fueling or near fueling operations.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Do not spill fuel on the hot surface of the machine.
- Fill the fuel tank in a well ventilated place.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Clean up spilled fuel immediately.
- Securely tighten the fuel filler cap. If the fuel cap is lost, replace it only with the genuine cap. Use of a non-approved cap without proper venting may result in pressurization of the tank.
- Never use fuel for cleaning.
- Use the correct grade of fuel for the operating season.

Handling of hoses

Oil leak or fuel leak can cause a fire.

- Do not twist, bend or hit the hoses.
- Never use twisted, bent or cracked pipes, tubes or hoses; otherwise, they may burst.
- Retighten loose connection.

Be careful with hot and pressurized components



Stop the engine and allow the machine to cool down before performing maintenance.

- The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
- The engine coolant, hydraulic oil and other oils are also hot and under high pressure. Be careful not to touch the hydraulic oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- The DPF and the exhaust gas emitted from the exhaust line can be very hot while the engine is running or the regeneration is under way, as well as immediately after the engine is stopped. Be careful not to accidentally touch them; doing so could cause burns.


**Be careful with hot cooling systems**

Do not remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine and wait until the engine and the cooling water cool. Then, slowly loosen the radiator cap to release the internal pressure and remove it.

Be careful with oil internal pressure

Pressure is maintained in the hydraulic circuit long after the engine has been shut down.

- Completely relieve the internal pressure before performing maintenance work.



- The hydraulic oil is high enough pressure to penetrate the skin or eyes and cause serious injury, blindness or death. Remember that the hydraulic oil escaping from a small hole is almost invisible. When checking for leaks, wear protective goggle and thick gloves, and use a paperboard or plywood to keep your skin from oil spurting. If oil penetrates the skin, it must be surgically removed within a few hours by a doctor familiar with this type of injury.

Release pressure before working on the hydraulic system

Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.

- Immediately after the engine is stopped, and while the safety lock lever is still in the unlock position, turn the starter switch to ON and move all the control levers and pedals several times all the way in each direction to release the pressure from the working equipment circuitry.
- Press the air breather button to relieve the internal pressure from the tank.
- When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.
- Oil or plug may spurt out according to the pressure in the travel motor case. Loosen the plug slowly and release the internal pressure.

Be careful with debris when the hammer is being used

When using a hammer, pins may fly out or metal particles may be scattered. This may lead to serious injury.


- If hard metal parts such as pins, bucket teeth, side cutter or bearings are hit with a hammer, wear protective gear such as safety goggles and gloves.
- When hitting pins or bucket teeth, always check that there is no one in the surrounding area.



SAFETY

PRECAUTIONS ON MAINTENANCE

Never disassemble the track adjuster



There is a very strong spring contained in the track adjuster. If the track adjuster is accidentally disassembled, the spring can pop out, resulting in serious injury. Never disassemble the track adjuster.

Cautions when servicing the air conditioner

If the refrigerant comes in contact with eyes, it damages your eyesight. If the refrigerant comes in contact with skin, it may cause frostbite. Never touch the refrigerant.

Handling of the accumulator



Be sure to handle the high-pressure nitrogen gas enclosed in the accumulator with care. If handled incorrectly, it could explode and cause serious injury. Strictly observe the following precautions:

- Do not disassemble.
- Do not allow flame near or throw it into a fire.
- Do not drill, weld or fuse.
- Do not subject it to physical shock such as hitting, rolling or dropping.
- Before disposing of the unit, the sealed gas must be drained. Contact a Takeuchi service agent for help.



Disconnect the battery wiring



Disconnect the battery wiring before working on the electrical system or doing electric welding. Disconnect the negative (–) battery cable first. When reconnecting, connect the negative (–) battery cable last.

Use caution when handling batteries

- Batteries contain sulfuric acid which will damage the eyes or skin in case of contact.
 - If eye contact occurs, flush immediately with clean water and get prompt medical attention.
 - If accidentally swallowed, drink large quantities of water or milk and call a physician immediately.
 - If acid contacts skin or clothing, wash off immediately with a lot of water.
- Wear protective goggle and gloves when working with batteries.
- Batteries generate flammable hydrogen gas which may explode. Keep away from flame, sparks, fire or lighted cigarettes.
- When checking the level of the battery fluid, use a flashlight.
- Be sure to stop the engine by turning off the starter switch before inspecting or handling the battery.
- Be careful not to let metal tools or any metal objects come into contact with the battery terminals and cause a short circuit.
- Loose battery terminals may result in sparks. Be sure to fasten terminals tightly.
- Make sure the battery caps are tightened securely.
- Do not charge a battery or jump-start the engine if the battery is frozen; otherwise it may explode. Warm the frozen battery to 15°C (60°F) before use.
- Do not use the battery when the fluid level is below the lower level limit. Doing so will hasten the deterioration of the internal portions of the battery and shorten the battery life. It also can cause rupturing (explosion).
- Do not add the distilled water above the upper level limit. Doing so could cause the fluid to leak. This fluid can cause skin damage if contacted, or can cause the machine components to corrode.
- Use a dampened cloth to clean around the fluid level line and check the fluid level. Do not clean with a dry cloth; otherwise it could cause static electricity to build up, resulting in ignition or explosion.

**Periodically replace the safety-critical parts**

- To use the machine safely for a longer period, periodically add oil and perform inspection and maintenance. To improve the safety, replace the safety-critical parts like hoses and seat belts periodically. Refer to “Safety-critical parts to be replaced periodically” for further details.
- The “Safety-critical parts to be replaced periodically” are the parts which deteriorate, wear and fatigue after repeated use and whose properties change over time. While these characteristics of these parts could cause serious physical or personal damage, judging the remaining life of these parts are difficult from external inspection or the feeling when operating.
- Replace the “Safety-critical parts to be replaced periodically” if any defect is found from external inspection, even when they have not reached the time specified interval.

Jump starting with booster cables

- When starting the engine using the booster cables, be sure to connect the cables in the proper order described below. Wrongly connected cables can result in sparking and battery explosion.
 - Do not allow the “machine in trouble” and “rescue machine” to touch each other.
 - Do not allow the positive (+) and negative (–) clips of the booster cables to touch each other or to come in contact with the machine.
 - When connecting, attach the positive booster cable to the positive (+) terminals first. When disconnecting, remove the negative cable from the negative (–) terminal (ground) first.
 - Be sure to connect the clips securely.
 - Connect the last clip of the booster cable to a point as far away from the battery as possible.
- Always wear the protective goggles and gloves when starting the engine by using the booster cables.
- Use the booster cables and clips of a size suited to the capacity of battery. Do not use damaged or corroded booster cables and clips.
- Be sure that the battery of the “rescue machine” has the same capacity as the battery of the “machine in trouble”.



Have a Takeuchi service agent repair welding

If welding must be performed, make sure that it is done by a qualified person in a properly equipped workplace. To prevent any part from breaking down or being damaged due to overcurrent or sparks, observe the following.

- Disconnect the wiring from the battery before doing electric welding.
- Do not continuously apply 200 V or more.
- The earth ground must be connected within one meter from the welding section. Do not connect the earth ground near to an electronically controlled device/instrument or connectors.
- Make sure that there are no seals or bearings between the welding section and the earth ground.
- Do not connect the earth ground around the pins for the working equipment or hydraulic cylinders.
- When welding is to be done on the machine body, disconnect the connectors for the electronically controlled devices before working.

Vibrations operators are subject to

According to the results of the tests conducted to determine the vibrations transmitted to the operator by the machine, the upper limbs are subjected to vibrations lower than 2.5 m/s^2 (8.2 ft/s^2) while the seated part of the body is subjected to vibrations lower than 0.5 m/s^2 (1.64 ft/s^2).

Checks after maintenance

- Gradually increase the engine speed from a low idle to maximum speed and check that there is no oil or water leaking from the serviced parts.
- Operate each control lever and check that the machine is operating properly.

Disposing of wastes



- Always collect oil that is drained from the machine in containers. Improperly disposed waste oil can cause environmental harm.
- Follow appropriate laws and regulations when disposing of harmful objects such as oil, fuel, coolant, solvent, filters and batteries.

Handling of poisonous chemicals

Poisonous chemicals will cause serious injury if directly contacted.

Poisonous chemistry used in this machine includes grease, battery solution, coolant, paint and adhesive agent.

Handle the poisonous chemicals properly with care.




SAFETY SIGNS (DECALS)

For the safety of the operator and the personnel working around the site, safety signs (decals) are placed at certain locations on the machine as shown below. Walk around the machine with this manual, and check the content and location of these safety signs. Review these signs and the operating instructions in this manual with your machine operators.

- Keep the signs clean and legible. If any of the safety labels is peeling or damaged and becomes difficult to read, replenish it with a new one. Please include your product serial number when ordering a new sign from the Takeuchi service agent.
- When a part/unit to which a safety sign is attached is replenished, a new sign must be attached to the new part/unit.



SAFETY
SAFETY SIGNS (DECALS)





1. No.08810-31556

Warning
Read and understand this
manual before performing
any operation, inspection
or maintenance on this
machine.



4. No.03793-66006

Hazard of rotating parts
Turn off before inspection and maintenance.



5. No.08810-31557

Hazard from falling window
After raising window, be sure to lock it in
place with lock pins.



2. No.05793-00049

Safety Distance
Hazard of being hit by the working
device of the machine.
Keep away from machine during
operation.



6. No.05793-00045

Hazard at lifting or lowering window
When the front window is opened or closed,
it will come close to the head. Be careful that
the window does not strike the head.



3. No.05793-00011

Safety Distance
Do not get near or stand within the
machine working area.



7. No.05793-03630

Sign indicates a burn hazard from touching
heated parts, such as engine, pump, or muffler
during or right after operation.
Never touch when hot.





SAFETY SAFETY SIGNS (DECALS)


8. No.03393-75040




9. No.03593-47010 (If equipped)



10. No.03593-47020




11. No.03593-13700



12. No.08710-86051

Position of Emergency Exit



13. No.03593-06600

Diesel fuel



14. No.03593-06700

Hydraulic oil



15. No.08810-31549

Tie down point



16. No.03993-00500

Position of hoisting



AM1A0053E



SAFETY

SAFETY SIGNS (DECALS)


17. No.03993-00400

For EU

Position of Fire extinguisher



18. No.03593-32300(Option)



19. No.03993-54628

Noise Outside the Cab (If equipped)

This value indicates the noise level outside the machine and refers to the noise perceived by the persons who are in the vicinity of the work area.



20. No.03793-69110(Option)



WARNING!


Do not press the float switch while the machine is raised by the dozer blade. Doing so may cause the machine to fall.

21. No.05693-68009

Before starting lifting operation, be sure to turn on the lift overload warning switch. An alarm sounds if an excessive weight is lifted.



22. No.05693-00090



23. No.05693-00164

For USA

WARNING

EXCAVATOR MODEL TB290

Long arm length: 2130mm(83.9in.)
Machine with Cab and Rubber crawler, without bucket.

- Do not attempt to lift or hold any load that is greater than these rated values at their specified load rate and height.
- The rated lift capacities are based on the machine being level and situated on a firm supporting surface.
- For safe lifting the operator is expected to make due allowance for the particular job conditions, such as soft or uneven ground/non-level condition, load to the machine side, hazardous conditions, experience of personnel, etc.
- The load safety device shall be equipped for lifting load.
- The overload warning switch shall be turned on when the machine is used for lifting load.

The loads in the charts do not exceed 87% of hydraulic lift capacity or 75 % of tipping load.
The load point is the bucket hinge pin.

Diagram showing the lift point and lift point radius for the excavator model TB290. The diagram includes a grid with lift point height (m) on the vertical axis (0 to 21) and lift point radius (m) on the horizontal axis (0 to 21). A curve represents the lift capacity limit. The lift point is marked at the top right of the curve.

LIFTING CAPACITIES						LIFTING CAPACITIES						LIFTING CAPACITIES						LIFT POINT	
Over Front, Dig Down						Over Front, Dig Up						Over Side						POINT	
LIFT POINT RADIUS (m)						LIFT POINT RADIUS (m)						LIFT POINT RADIUS (m)						HEIGHT (m)	
MAX	18	12	9	6	MAX	18	12	9	6	MAX	18	12	9	6	18	6			
2291	2721	3052	3292	3481	2491	3051	3292	3481	3671	2136	2456	2694	2934	3174	12	12			
2019	2671	2951	3191	3381	2211	2861	3101	3291	3481	1936	2256	2494	2734	2974	9	9			
1992	2591	2871	3111	3301	2191	2841	3081	3271	3461	1811	2131	2371	2611	2851	6	6			
1919	2511	2791	3031	3221	2111	2761	3001	3191	3381	1786	2106	2346	2586	2826	0 (max)	0 (max)			
1649	2241	2521	2761	2951	2021	2571	2811	3001	3191	1591	2191	2431	2671	2911	0	0			
1599	2191	2471	2711	2901	1971	2521	2761	2951	3141	1566	2166	2406	2646	2886	-3	-3			
1587	2181	2461	2701	2891	1961	2511	2751	2941	3131	1556	2156	2396	2636	2876	-6	-6			
1588	1187	1175	1163	1151	1588	1187	1175	1163	1151	1577	1176	1164	1152	1140					


05693-00164 (C)

CONTROLS





NAMES OF COMPONENTS



AM1B0011

Upperstructure

- 1. Cab
- 2. Seat
- 3. Engine hood
- 4. Fuel tank
- 5. Hydraulic oil tank


Undercarriage

- 6. Crawler belt
- 7. Idler
- 8. Track roller
- 9. Carrier roller
- 10. Travel motor

Working equipment

- 11. Bucket
- 12. Bucket cylinder
- 13. Arm
- 14. Arm cylinder
- 15. Boom
- 16. Boom cylinder
- 17. Boom bracket
- 18. Swing cylinder
- 19. Auxiliary hydraulic lines
- 20. Dozer blade
- 21. Blade cylinder
- 22. Second boom
- 23. Second boom cylinder


2-Piece boom



AM3B001



CONTROLS NAMES OF COMPONENTS



AM3B012


- | | |
|--|---------------------------------------|
| 1. Multi-information display | 16. Wiper switch |
| 2. Starter switch | 17. Washer switch |
| 3. Blade lever | 18. Automatic deceleration switch |
| 4. Throttle controller | 19. Power/Highland mode switch |
| 5. Right operating lever* | 20. Detent mode switch |
| 6. Horn button | 21. Auxiliary 1st auto tank switch* |
| 7. Deceleration button | 22. Lift overload warning switch* |
| 8. Boom swing/Second boom pedal | 23. Beacon lamp switch* |
| 9. Travel levers/pedals | 24. Engine shutdown switch |
| 10. Travel speed button | 25. Auxiliary 2nd/4th switch* |
| 11. Left operating lever* | 26. Auxiliary 2/4 select button* |
| 12. Auxiliary 1st switches | 27. Third auxiliary hydraulic button* |
| 13. Safety lock lever | 28. Swing/Second boom select button* |
| 14. DPF manual regeneration/inhibit select switch <Applicable machine models 185100001 or later> | 29. Third auxiliary hydraulic switch* |
| 15. Light switch | 30. Cigarette lighter |
| | 31. Radio |
| | 32. AC Control panel |
| | 33. Third auxiliary hard-lock switch* |

*: Subject to the specifications or optional products selected



COVERS

STARTER KEY



The starter key is used to start and stop the engine, as well as to lock and unlock the following components:

- Cab door
- Engine hood
- Covers


SIDE COVER

WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
- Do not keep the side cover open on a windy day or if the machine is parked on a slope.
- When opening and closing the side cover, be careful not to get your hands or other parts of your body caught by the cover.

For inspection and maintenance of the hydraulic oil system, fuel system, coolant system or window washer, open this cover. The grease gun and the tools are also stored in the cover.

Opening



1. Insert the starter key and turn it counterclockwise to unlock the side cover (1).
2. Push in the key hole with your thumb and open the side cover (1) all the way.
3. Store the tools.


Closing

1. Close the side cover (1) and press it down until a click is heard.
2. Insert the starter key and turn it clockwise to lock the side cover (1).

Stopper

<Applicable machine models 185105180 or later>

<Applicable machine models 190200954 or later>



When it is necessary to leave the side cover (1) open for a long time for servicing or inspecting, use the stopper (2) to prevent the side cover (1) from closing.




FUEL LID

CAUTION

When opening and closing the fuel lid, be careful not to get your hands caught by the lid.

For adding fuel or checking the level of hydraulic oil or coolant, open this cover.

Opening



1. Insert the starter key and turn it counterclockwise to unlock the fuel lid (1).
2. Remove the starter key, push in the key hole with your thumb and open the fuel lid (1) all the way until it stops.

Closing


1. Close the fuel lid (1).
2. Insert the starter key and turn it clockwise to lock the fuel lid (1).

FUEL FILLER PORT

WARNING

- Do not smoke and keep away from heat or flame while filling the fuel tank.
- Fill the fuel tank in a well ventilated place, with the engine turned off.
- Clean up spilled fuel immediately.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Securely tighten the fuel filler cap.

Opening



1. Open the fuel lid.
2. Turn the fuel cap (1) counterclockwise and remove it.

Closing

1. Turn the fuel cap (1) clockwise and close it.
2. Close the fuel lid and lock it.




ENGINE HOOD

WARNING

- Before opening the engine hood, be sure to stop the engine. If a hand or tool becomes trapped in the rotating or moving part, serious injury could result.
- Do not leave the engine hood open on a windy day or if the machine is parked on a slope.
- When opening or closing the engine hood, be careful not to get your hands or other parts of your body caught by it.

Opening



1. Insert the starter key and turn it counterclockwise to unlock the engine hood (1).
2. Push in the key hole with your thumb and open the engine hood (1).


Closing

1. Close the engine hood (1) and press down the edge of it until a click is heard.
2. Insert the starter key and turn it clockwise to lock the engine hood (1).

FUSE BOX COVER

For inspection and maintenance of the fuse or air conditioner filter, open this cover. The port for connecting to a computer is inside the box.

Opening



1. Remove the wing bolt (1).
2. Tilt the fuse box cover (2) forward.

Closing

1. Close the fuse box cover (2) and secure it with the wing bolt (1).



CAB

CAB DOOR


WARNING

When getting on or off the cab, first open the door all the way until it is secured in the catch and check that it does not move.

Open the door fully and press it against the catch at the back of the door to secure it in place.

The door must be locked when getting on or off the machine and while in operation.


Locking and unlocking



Insert the starter key and turn it.

Opening


1. Pull the knob (1) towards you and open the door.



To open the door from inside the cab, push the lever (2) to the lower.

2. Open the door fully and press it against the cab to secure it in place.


Closing



1. Push the release lever (3) to the lower.
2. Close the released door.

EMERGENCY EXIT

Front window (excluding machines with a front guard)



If you should become trapped inside the cab, open the front window to get out.




FRONT WINDOW


WARNING

- Grasp the handles firmly with both hands when opening and closing the front window. Your head or hands may get caught if it slips from your hands.
- When the front window is opened or closed, it will come close to the head. Be careful that the window does not strike the head.
- When you open the front window, be sure to lock it in place with the lock pins on the left and right sides. The window may fall if it is not locked in place.

Opening



1. Park on a level surface and stop the engine.
2. Set the safety lock lever to the locked position.
3. Grasp the left and right handles (1) and press the knobs (2) with your thumb to release the lock.
4. Pull the front window (3) toward you and lift while doing so.




5. Release your thumb from the knobs (2) and then lift the front window (3) fully and lock the front window with lock pin (4).


Closing

WARNING

When closing the front window slowly so as not to hit your head. Lowering the window abruptly may result injury or damage the front window.




1. Grasp the left and right handles (1) and press the knobs (2) with your thumb to release the lock.
2. Pull down the front window (3) and while doing so, slide it to the front and slowly lower it.




3. Release your thumb from the knobs (2) and then press the front window toward front and lock the front window with lock pin (4).

LOWER FRONT WINDOW

Removing




1. Open the front window and stow it in the ceiling.
2. Slowly lift the lower front window (4).



3. Hold the window in a vertical position (the bottom of the window should be in front of you), place it through the guide (5) on the left side of the cab, and then secure it with the support (6).




SIDE WINDOW




1. Grasp the catch (7), unlock it and open the side window.
2. To close the side window, close it until a click is heard.

SUN SHADE



1. Pull out the sun shade forward.
2. Hook the sun shade to the two catches (1)

EMERGENCY HAMMER (OPTIONAL)



An emergency hammer is installed to be used to escape from the cab in an emergency. When escaping, break the windows with the hammer.

- When breaking the windowpane with a hammer, take great care not to injure yourself with the broken glass pieces.
- Remove the glass pieces from the window sill so as not to cut yourself when evacuating. Broken glass will fall from the window, so be careful of your footing and do not slip on the glass.




SEAT AND SEAT BELT

SEAT

WARNING

- Adjust and secure the seat.
- Do not make any adjustments while operating the machine.
- Do not set the backrest to its maximum reclining position and slide the seat backwards at the same time. Doing so may damage the rear window or cause injury.
- Remember that the backrest returns to the forward position abruptly due to the spring force.




(A) Adjusting the backrest angle

1. Sit up and sit back in the seat.
2. Pull up the lever (1), recline the backrest by using the spring force. Release the lever (1) at the desired angle to secure the backrest.

(B) Fore-and-aft adjustment

1. Pull up the lever (2) and slide the seat backward or forward to the desired position for operation of machine.
2. Release the lever (2) at the desired position to secure the seat.
Adjustment range: 15 positions, in 150 mm (5.9 in.)



(C) Adjusting according to operator's weight

1. Turn the handle (3) until the scale (4) indicates the weight of operator.
Adjustment range: 50 to 130 kg (110 to 287 lbs)

(D) Adjusting the height of the seat

Upward

1. Lift the seat to first or second position click-stop.
Adjustment ranges: 2 positions, in 60 mm (2.36 in.)

Downward

1. First lift the seat to highest position, then the seat can be lowered to lowest position.




(E) Adjusting the headrest (Option)

The headrest (E) can be moved upward or downward.

1. Grab the headrest (E) with both hands, and move upward or downward to the desired position.

(F) Adjusting the operating lever stand



1. Pull up the lever (5) and slide the lever stand (seat).
2. Release the lever (5) at the desired angle to secure the lever stand (seat).
Adjustment range: 9 positions, in 90 mm (3.5 in.)

SEAT BELT




WARNING

Be sure to fasten the seat belt securely before starting the engine.


Fastening the seat belt

1. Adjust the seat to the desired position for operation, sit up and sit back in the chair.
2. Pull the seat belt to the desired length.



3. Make sure that the belt is not twisted and then insert the tongue plate (A) into the buckle (B) of the seat belt until you hear a clicking sound as it locks in place.
4. Check if the belt is securely locked by pulling it, and arrange the belt around your waist.

Releasing the seat belt




1. Grasp the tongue plate (A) and press the button (C) on the buckle (B).
The seat belt retracts back into its original position.



AIR SUSPENSION SEAT

WARNING

- Adjust and secure the seat.
- Do not make any adjustments while operating the machine.
- Do not set the backrest to its maximum reclining position and slide the seat backwards at the same time. Doing so may damage the rear window or cause injury.
- Remember that the backrest returns to the forward position abruptly due to the spring force.



(A) Adjusting the lumbar support

1. Turning the knob (1) in the direction of the arrow causes the lumbar of the backrest to curve outwards.
2. Turning the knob (1) further removes the curve and returns the seat to its original position.

(B) Adjusting the backrest angle

1. Sit up and sit back in the chair.
2. Pull up the lever (2), adjust the backrest rear angle by using the spring force on the chair back. Release the lever (2) at the desired angle to secure the backrest.

(C) Adjusting the absorber

The seat adjustment using the absorber is applicable for various traveling conditions on roads or off roads. The cushioning effect can be individually set for each case. Turn the lever (3) to the desired position and release.

Positions between

1: Soft cushioning

and

4: Hard cushioning

(D) The fore/aft isolator

It is activated under certain conditions such as crashing. Impacts of crash applied in the operating direction can be well absorbed by the operator's seat. Switching can be done with the lever (4).

Position 1: Fore/aft isolator on


Position 2: Fore/aft isolator off



(E) Adjusting according to operator's weight

IMPORTANT: Before performing the adjustment by weight, stop the machine and remain seated. Otherwise, the weight cannot be detected, resulting in malfunction.

IMPORTANT: Be sure to set the absorber to the soft cushioning position (1) when performing the adjustment by weight.



The seat should be adjusted according to the operator's weight. Briefly pull the actuator lever (5) of the automatic weight and height adjuster.

(F) Adjusting the seat height

IMPORTANT: Be sure to set the absorber to the soft position (1) when performing the height adjustment.

IMPORTANT: Do not operate the lever (5) (compressor) for one minute or more. Doing so will cause compressor failure. To protect the compressor, wait for at least three minutes before operating the lever (5) again.


IMPORTANT: If the height adjustment function fails, first lower the seat to the lowest position. Then, adjust the height again.

The seat height can be steplessly adjusted using the pneumatic mechanism.

To adjust, push up or push down the lever (5) all the way up or down. When the seat reaches the level where it cannot be raised anymore even the lever (5) is pushed up, that level is the highest. If this happens, the height is automatically lowered a small distance to maintain the stroke of suspension.

Adjustment stroke: 80 mm (3.1 in.)


(G) Adjusting the seat pan angle



The angle of the seat pan can be individually adjusted.


To adjust, lift the left side handle (6). Use the pressure applied to the seat to set the seat pan to the desired angle.

(H) Adjusting the seat depth




The depth of the seat pan can be individually adjusted.

To adjust, lift the right side handle (7). Move the seat cushion forward or backward until the desired seat depth is obtained.

**(J) Adjusting fore-and-aft**

1. Pull up the lever (8) and slide the seat backward or forward to the optimum position for operation.
2. Release the lever (8) at the optimum position to secure the seat.
Adjustment range: 17 positions, in 170 mm (6.7 in.)

(K) Adjusting the operating lever stand

1. Pull up the lever (9) and slide the lever stand (seat).
2. Release the lever (9) at the optimum position to secure the lever stand (seat).
Adjustment range: 9 positions, in 90 mm (3.5 in.)

(L) Adjusting the headrest height

1. Grab the headrest (10) with both hands, and move upward and downward. Adjust the height so that the headrest center is positioned behind your ears.

(M) Seat heater**CAUTION**

- Using the seat heater over an extended period of time may cause burns. People feeling ill or having sensitive skin, in particular, should be careful not to do so.
- Do not use it with a blanket or cushion placed on the seat.
- Clean up spilled water or soft drink immediately with a dry cloth. Dry the seat well before using the heater again.


IMPORTANT: The battery voltage becomes low if the seat heater is left on for a long time when the engine is stopped.

OOFF
ION



MULTI-INFORMATION DISPLAY

MAIN MENU SCREEN



AM1B070

For explanation purposes, all lamps on this page are in the lit condition. This screen image is quite different from that of the real operation. In the actual operation, if a warning is given or any function is selected, the corresponding symbol appears enlarged at the center of the display for approx. one second.

When the starter switch is set to ON, the battery charge warning lamp and the engine oil pressure warning lamp first appear enlarged, and then turn on with an alarm at their original locations. The machine system is normal if the lamps turn off after the engine is started.



WARNING LAMPS

IMPORTANT: If a warning lamp flashes and an alarm is sounded, immediately stop all operations and check the corresponding component. Refer to “If a warning lamp flashes” on pages 6-10 and 6-11.

1. ECM error warning lamp

This warning lamp flashes if the Electronic Control Module (ECM) detects an engine problem while the starter switch is in the ON position. The problem detected is recorded as an ECM error. Refer to “Engine error code list” on pages 6-14 to 6-24.

1-1. Vehicle and engine emergency lamp

This lamp is displayed enlarged for one second, and then flashes and an alarm sounds if there is a problem with the machine. Go to the error code display from the Menu screen, get the vehicle or engine error code number, and consult your sales or service dealer referring to the “Vehicle error code list” or “Engine error code list” in this manual.

Refer to “Menu screen” on page 2-25 or 2-30.

Refer to “(7) Error code display” on page 2-28 or “(6) Error code display” on page 2-36.

Refer to “Vehicle error code list” on pages 6-12 to 6-13.

Refer to “Engine error code list” on pages 6-14 to 6-24.

2. Battery charge warning lamp

This lamp flashes and an alarm is sounded if a problem rises in the charging system while the engine is running.

3. Engine oil pressure warning lamp

This lamp flashes and an alarm is sounded if the lubricant oil pressure abnormally low while the engine is running.

4. Water separator warning lamp

This lamp flashes if the water is detected within the water separator while the starter switch is in the ON position.

5. Coolant temperature warning lamp

This lamp flashes and an alarm is sounded if the engine coolant temperature becomes abnormally high while the engine is running.

6. Air cleaner warning lamp

This lamp flashes and an alarm is sounded if the air cleaner filter is clogged while the engine is running.


7. Fuel filter warning lamp

**<Applicable machine models
190200001 or later>**

This lamp flashes and an alarm is sounded if the fuel filter is clogged while the engine is running.

7-1. NCD warning lamp

**<Applicable machine models
185100001 or later>**



..... This lamp flashes and an alarm is sounded if the NOx control detects any error.

NCD: NOx Control
Diagnostic system

8. Fuel level warning lamp


This lamp flashes when the fuel level is low while the starter switch is in the ON position.

9. Third auxiliary hydraulic warning lamp

This lamp starts flashing and an alarm sounds if the fixed side (left “e”) pressure of the auxiliary 3rd drops abnormally while the engine is running, or while the quick-hitch is being removed or installed.




- 10. Safety start warning lamp**
<Applicable machine models
185104996 or later>
<Applicable machine models
190200924 or later>



This lamp appears enlarged on the display and the buzzer sounds if the engine is started when the safety lock lever is in the unlock position. The engine cannot be started. First, set the safety lock lever to the lock position, and then start the engine.

INDICATORS

- 11. Deceleration indicator lamp**



Automatic deceleration indicator

It flashes when the automatic deceleration switch is pressed and remains lit while in the deceleration mode.

Refer to “Deceleration button” on page 2-40.

Refer to “Automatic deceleration switch” on page 2-45.

Deceleration indicator

This lamp turns on when the deceleration button is pressed. The lamp lights up to indicate that the engine is in the deceleration mode at low idling speed.

- 12. Exhaust temperature warning indicator lamp**

<Applicable machine models
185100001 or later>


This indicator lights up to warn if the exhaust temperature is abnormally increased. Check for any flammable items around the exhaust piping.

- 13. Glow indicator lamp**

This indicator lamp turns off when the engine preheating is completed.



- 14. DPF auto regeneration/inhibit indicator lamp**
<Applicable machine models
185100001 or later>



DPF auto regeneration under way

The DPF regeneration is automatically performed by the engine, when certain criteria are met. The operator only has to check the display.

DPF auto regeneration inhibit

The DPF manual regeneration inhibit symbol appears on the display when the DPF manual regeneration under way or the DPF auto regeneration under way is cancelled.

Refer to “DPF manual regeneration/inhibit select switch <Applicable machine models 185100001 or later>” on page 2-43.

- 15. DPF manual regeneration under way/regeneration promoting indicator lamp**
<Applicable machine models
185100001 or later>

The indicator starts flashing and an alarm starts sounding, if the accumulated PM exceeds the limited amount on the DPF. Immediately perform the manual DPF regeneration.


Refer to “DPF manual regeneration/inhibit select switch <Applicable machine models 185100001 or later>” on page 2-43.

- 16. Highland mode indicator lamp**

Highland mode is selected.

Refer to “Power/Highland mode switch” on page 2-46.

- 17. Travel speed indicator lamp**



This lamp turns on when the travel speed button is set to the 2nd (high) speed.


- 18. Power mode indicator lamp**

This lamp lights up when the power mode side of the Power/Highland mode select switch is pressed. The maximum engine output is maintained for as long as this lamp is lit.

- 19. Lift overload warning indicator lamp**

This lamp turns on when the lift overload warning switch is turned on.

- 20. Auxiliary 2nd/4th select indicator lamp**





21. Swing/Second boom indicator lamp



..... Swing is selected.

..... Second boom is selected.

22. Auxiliary 1st one-way (one-way circuit) indicator lamp



..... Auxiliary 1st auto tank is selected.

..... Auxiliary 1st one-way is selected.

No display:Two-way (two-way circuit) is selected.

23. High-flow indicator lamp

This lamp flashes and then stays lit when the auxiliary 1st flow rate is set to high-flow.

It also flashes when the high-flow setting is changed.

24. Dozer blade float indicator lamp (If equipped)



This lamp lights up when the float switch on the blade lever is pressed.

25. Water temperature gauge

Indicates the temperature of the engine coolant water. The indicator level must be within the green range during machine operation. The red range indicates overheating.


26. Fuel gauge

Indicates the amount of fuel in the tank. Be sure to fill up the tank before running out of fuel.




27. Throttle opening position indicator

<Applicable machine models 185100001 or later>



<Applicable machine models 190200001 or later>



This gauge displays the load condition of the work. When the gauge is in the green range, the work load is light to medium. When the gauge is in the red range (75% or more), the work load is high. When the button (C) (Bar meter key) is pressed in a normal screen, the display is changed from the engine load factor to the throttle opening position, the lift load factor, and the PM accumulation amount (only for machine models of 185100001 or later), in this order


Note: The machine is not faulty if the gauge is in the red range. Operating the machine with the gauge being in the green range is energy-saving and will help conserve the global environment.

- The lift load factor is displayed if there is no change in the throttle opening position for five seconds after the lift alarm switch is turned on.
- The throttle opening position is displayed if the highland mode switch is turned on or there is a change in the throttle opening position.



28. Auxiliary 1st flow rate indicator lamp

This lamp lights up to indicate which flow rate setting is selected in the auxiliary 1st.



Refer to “Auxiliary 1st flow rate setting” on page 2-26 or 2-32.

29. Air conditioner indicator lamp

Lights up while the air conditioner is operating.

30. Working light indicator

Lights up when the working light is turned on.


31. Date and time indicator



Displays the date and time set.
Refer to “Date and time setting” on page 2-28 or 2-35.

32. Hour meter/Trip meter

• Hour meter



Displays the total engine running time in hours.
The rightmost digit indicates tenths of

hours (6 minutes).

Set the inspection and maintenance intervals according to the time displayed on the hour meter.


• Trip meter

Three patterns of desired operating hours can be displayed.

Refer to “Trip meter setting” on page 2-26 or 2-31.



SCREEN CONTROL KEY



Note: Do not press the symbol keys on the display. The LCD could be damaged if the symbol keys are pressed hard. For actual operation, press the push button keys located at the bottom of the screen.

A. Menu key

Use this key to switch between the Home screen and the Menu screen. This key is also used to cancel changes made in each setting. The screen returns to the Home screen if this key is pressed in the information screen.

B. Hour meter key

This hour meter symbol is displayed in the initial screen. Pressing this key changes the meter display in the following order. Trip meter 1, Trip meter 2, Trip meter 3, Hour meter.

Down (↓) key

Use this key to move the cursor ► downward and to decrease the value in each setting. Press and hold this key for one second to rapidly decrease the value.

C. Bar meter key

This bar meter symbol is displayed in the initial screen. Pressing this key changes the meter display in the following order. Throttle opening position, Lift load factor, PM accumulation amount

Up (↑) key

Use this key to move the cursor ► upward and to increase the value in each setting. Press and hold this key for one second to rapidly increase the value.

D. Auxiliary 1st key

The auxiliary 1st symbol is displayed in the initial screen. Pressing this key changes the symbol display in the following order. Auxiliary 1st setting 1, Auxiliary 1st setting 2, Auxiliary 1st setting 3.

Enter key

Use this key to confirm or execute the setting made by each key.

To clear the trip meter being displayed, press and hold this key for three seconds.




E. Camera image key (If equipped)



WARNING

Do not look at the images produced by the camera when traveling in reverse. Move in reverse while visually looking at the direction of travel.



AW6C0211

1. Press the Camera key in the Main screen to display the images taken by the rear camera.
2. Press the Camera key again or other key to return to the Main screen.




SCREEN NAVIGATION

• Menu screen

<Applicable machine models 185100001 to 185103969>

<Applicable machine models 190200001 to 190200671>



AQQB018


Press the Menu key to go the Menu screen while in the Home screen.

- (1) Trip meter setting
- (2) Auxiliary line flow rate display
- (3) Auxiliary 1st flow rate setting
- (4) Auxiliary 2nd/4th flow rate setting
- (5) Date and time setting
- (6) Data display
- (7) Error code display
- (8) LCD setting

Move the cursor ► with the Up (↑) or Down (↓) key to go to the desired item to be set, and then press the Enter key to confirm. To return to the Menu screen, press the Menu key. The wrench symbol indicates the "setting is possible state" and the (i) mark indicates information only.



(1) TRIP METER SETTING



Six patterns of desired operating hours can be set.

To start setting, press the Enter key. The value flashes while being set.

Up (↑) key: Increases the value or moves the cursor ► upward. Rapidly increases the value when pressed and held for one second.


Down (↓) key: Decreases the value or moves the cursor ► downward. Rapidly decreases the value when pressed and held for one second.

Enter key: Confirms setting

Menu key: Cancels setting or returns to the Menu screen.

Pressing and holding the Enter key for three seconds clears the trip meter pointed by the cursor.


(2) AUXILIARY LINE FLOW RATE DISPLAY



Displays the flow rate of the Auxiliary 1st, 2nd and 4th.

The flow rate cannot be changed.

(3) AUXILIARY 1ST FLOW RATE SETTING




Three flow rate patterns can be set in the auxiliary 1st.

Refer to the trip meter setting for the key operation. To move the cursor ► in the direction of the arrow, use the Down (↓) key. To move the cursor ► in the opposite direction of the arrow, use the Up (↑) key.

Initial condition	A/B common, standard flow	Variable range
Auxiliary 1st-1	100%=71L/min (18.9 US gpm)	10 to 100%
Auxiliary 1st-2	75%=54L/min (14.2 US gpm)	10 to 100%
Auxiliary 1st-3	50%=36L/min (9.4 US gpm)	10 to 100%

Maximum flow rate	A/B common, high-flow	Variable range
Auxiliary 1st-1, 2, 3	140%=100L/min (26.4 US gpm)	101 to 140%

The table shows the 1-way flow rate when there is no load.



Pressing the Enter key while the cursor ● is at “Select ATT” goes to the attachment select screen.


Pressing the Down (↓) key will move the blue flashing light in the direction of the arrow.

Pressing the UP (↑) key will move the blue flashing light in the opposite direction of the arrow.

Move the blue flashing light to the desired symbol or the number, and then press the Enter key to confirm.

The selected symbol will appear at the lower left of the Home screen.

(4) AUXILIARY 2ND/4TH FLOW RATE SETTING



One pattern of the auxiliary 2nd/4th flow rate can be set.

Initial condition	Standard flow	Variable range
Auxiliary 2nd	C/D 100%=55L/min* (14.5 US gpm)	10 to 100%
Auxiliary 4th	G/H 100%=55L/min* (14.5 US gpm)	10 to 100%


The table shows the 1-way flow rate when there is no load.

*: For the machine models with the serial numbers of 185103838 or later and 190200654 or later, 60.6L/min (16 US gpm) may apply depending on the specifications. Contact our distributor for any further clarification.

Refer to the trip meter setting for the key operation. To move the cursor ► in the direction of the arrow, use the Down (↓) key. To move the cursor ► in the opposite direction of the arrow, use the Up (↑) key.



(5) DATE AND TIME SETTING



The year, month, date, hour and minute can be set. (Effective year range: 2010 to 2099)


- Move the cursor ► to the clock symbol, and then press the Enter key. The cursor ▼ will be shifted to the place for setting the year.

Press the Enter key again, and then enter the year. (The year display keeps flashing during editing.)

Press the Enter key to confirm. The month, date, hour and minute can be set using the same procedure for the year.

- Move the cursor ► to the calendar symbol, and then press the Enter key to change the format of “Year-Month-Date” to “Date-Month-Year” or “Month-Date-Year”. Refer to the trip meter setting for the key operation.

(6) DATA DISPLAY




Displays various data. The setting cannot be changed.

Display items

- Engine RPM
- Coolant temperature
- —
- Battery voltage
- PM accumulation amount <Applicable machine models 185100001 or later>

(7) ERROR CODE DISPLAY



⚠Vehicle error code

Displays four error codes, with the latest code in the upper left.

Refer to “Vehicle error code list” on pages 6-12 to 6-13.

🔧ECM error code

Engine ECM (Engine Control Module) error code

Displays three error codes, with the latest code at the top.


Refer to “Engine error code list” on pages 6-14 to 6-24.

IMPORTANT: If an error code appears, immediately stop the operation and contact a Takeuchi sales or service outlet for help.



(8) LCD SETTING

• Background color setting



Move the cursor ► to the background color symbol, and then press the Enter key. The blue flashing light moves from blue gray to gray, blue and black, in this order. Move the blue flashing light to the desired color position, and then press the Enter key to confirm.

The background color can be changed in this screen, regardless of mode (day or night).


• Unit setting

Switch between SI unit and US units.

Move the blue flashing light to the desired unit position, and then press the Enter key to confirm.

Menu key: returns to the Menu screen.

Pressing the Menu key again returns to the Home screen.



- The brightness of the LCD is set to between 0 and 100%. The brightness changes each time the adjustment is made.

Day mode: initial setting value is 50%

Night mode: initial setting value is 50%

While in the day (night) mode, adjustment is possible only for the brightness set to the night (day) mode.

Refer to the trip meter setting for the key operation.




SCREEN NAVIGATION

- Menu screen

<Applicable machine models 185103970 or later>

<Applicable machine models 190200672 or later>



Press the Menu key to go the Menu screen while in the Home screen.


- (1) Trip meter setting
- (2) Auxiliary line flow rate display
- (3) Machine settings
- (4) Date and time setting
- (5) Data display
- (6) Error code display
- (7) LCD setting

Move the cursor ► with the Up (↑) or Down (↓) key to go to the desired item to be set, and then press the Enter key to confirm. The screen returns to the Home screen if the Menu key is pressed on the Menu screen.

The wrench symbol indicates the “setting is possible state” and the (i) mark indicates information only.



(1) TRIP METER SETTING




Six patterns of desired operating hours can be set.

Press the Menu key to return to the Menu screen.

Move the cursor ► with the Up (↑) or Down (↓) key, and press and hold the Enter key for three seconds to clear the flashing trip meter pointed by the cursor.

(2) AUXILIARY LINE FLOW RATE DISPLAY




Displays the flow rate of the Auxiliary 1st, 2nd and 4th.

The flow rate cannot be changed.

(3) MACHINE SETTINGS

• Machine setting screen



The settings made to the machine can be changed. Move the cursor ► with the Up (↑) or Down (↓) key to go to the desired item to be set, and then press the Enter key to confirm.


To return to the Menu screen, press the Menu key.

Note: When the auxiliary flow rate locking is set to “enabled”, the “Lock” symbol is added to the upper right of the “auxiliary flow rate setting” symbol.

You are requested to enter the password when setting the auxiliary flow rate, locking/unlocking the auxiliary flow rate or changing the password.




• Requesting password screen



When the “closed-lock” symbol is displayed, it is necessary to enter the password to set the auxiliary flow rate, lock/unlock the auxiliary flow rate or change the password. Move the cursor ► with the Up (↑) or Down (↓) key, and press the Enter key to enter a 4-digit number password. Enter the existing password. If it is correct, “OK” will be displayed followed by the setting screen. If it is not, “NG” will be displayed followed by the machine setting screen. It is not necessary to enter the password again unless you want to change it or until you turn the ignition switch to OFF.

1. Auxiliary 1st flow rate setting




For the auxiliary 1st flow rate, there are four patterns to choose from. The three patterns shown on the display can be selected from the Home screen. For the preset, select from 1 through 4. To return to the machine setting screen, press the Menu key. Use the Up (↑) or Down (↓) key to move the cursor ►, and then press the Enter key to flash the number to be edited. To cancel editing, press the Menu key. Use the Up (↑) or Down (↓) key to change the value, and then press the Enter key again to complete editing.

Initial condition	A/B common, standard flow	Variable range
Auxiliary 1st-1	100%=71L/min (18.9 US gpm)	10 to 100%
Auxiliary 1st-2	75%=54L/min (14.2 US gpm)	10 to 100%
Auxiliary 1st-3	50%=36L/min (9.4 US gpm)	10 to 100%

Maximum flow rate	A/B common, high-flow	Variable range
Auxiliary 1st-1, 2, 3	140%=100L/min (26.4 US gpm)	101 to 140%

The table shows the 1-way flow rate when there is no load.



Pressing the Enter key while the cursor ► is at “ATT” goes to the attachment select screen.


Pressing the Down (↓) key moves the cursor ● in the direction of the arrow.

Use the Up (↑) key to move the cursor ● in the opposite direction of the arrow.

Move the cursor ● to the desired symbol or the number, and then press the Enter key to confirm.

The selected symbol will appear at the lower left of the Home screen.

2. Auxiliary 2nd/4th flow rate setting



One pattern of the auxiliary 2nd/4th flow rate can be set.

Initial condition	Standard flow	Variable range
Auxiliary 2nd	C/D	10 to 100%
	100%=55L/min* (14.5 US gpm)	
Auxiliary 4th	G/H	10 to 100%
	100%=55L/min* (14.5 US gpm)	


The table shows the 1-way flow rate when there is no load.

*: For the machine models with the serial numbers of 185103838 or later and 190200654 or later, 60.6L/min (16 US gpm) may apply depending on the specifications. Contact our distributor for any further clarification.

Refer to the trip meter setting for the key operation. To move the cursor ► in the direction of the arrow, use the Down (↓) key. To move the cursor ► in the opposite direction of the arrow, use the Up (↑) key.



3. Setting the auxiliary flow rate locking



It is possible to request the user to enter a password when setting the auxiliary flow rate.

To return to the machine setting screen, press the Menu key.

Use the Up (↑) or Down (↓) key to move the cursor ►, and then press the Enter key to turn on or off the “Lock” symbol.


Lock symbol is lit: Locked

Lock symbol is off: Unlocked

Note: If the password is set to “0000”, the auxiliary flow rate locking cannot be set to “enabled”.

Upon setting the locking to “enabled”, the screen asking for the password appears every time the ignition switch is turned to OFF or the password is changed.

4. Changing the password



The password can be changed. Use the Up (↑) or Down (↓) key to move the cursor ► to the password field, and then press the Enter key to enter a 4-digit number password. Once the password is entered, the display of “New Password” is change to “Confirm Password”.


The password change is successful when “Complete” appears after entering the same password for confirmation. If the password reentered does not match the one entered earlier, the notification of “Failed” appears asking for entering the password again in the first entry field.

To cancel editing, press the Menu key.

Note: If the password is set to “0000”, the auxiliary flow rate locking cannot be set to “enabled”.



5. ON/OFF setting




The auto back camera mode can be set to ON or OFF.

Press the Enter key to turn on or off the blue circle.

Blue circle is lit : ON

Blue circle is off : OFF

(4) DATE AND TIME SETTING



The year, month, date, hour and minute can be set. (Effective year range: 2010 to 2099)

- Move the cursor ► to the clock symbol, and then press the Enter key. The cursor ▼ will be shifted to the place for setting the year.


Press the Enter key again, and then enter the year. (The year display keeps flashing during editing.)

Press the Enter key to confirm. The month, date, hour and minute can be set using the same procedure for the year.

- Move the cursor ► to the calendar symbol, and then press the Enter key to change the format of "Year-Month-Date" to "Date-Month-Year" or "Month-Date-Year". For the key operations, refer to "Screen control key" on page 2-23.



(5) DATA DISPLAY




Displays various data. The setting cannot be changed.

Display items

- Engine RPM
- Coolant temperature
- Hydraulic oil temperature
- Battery voltage
- PM accumulation amount

(6) ERROR CODE DISPLAY



AVehicle error code

Displays four error codes, with the latest code in the upper left.

Refer to “Vehicle error code list” on pages 6-12 to 6-13.

DECM error code

Engine ECM (Engine Control Module) error code


Displays three error codes, with the latest code at the top.

Refer to “Engine error code list” on pages 6-14 to 6-24.

IMPORTANT: If an error code appears, immediately stop the operation and contact a Takeuchi sales or service outlet for help.




(7) LCD SETTING



The display settings can be changed. Use the UP (↑) or Down (↓) key to move the cursor ►.

Press the Menu key to return to the Menu screen.


• Background color setting



Move the cursor ► to the background color symbol, and then press the Enter key. The blue flashing light moves from blue gray to gray, blue and black, in this order. Move the blue flashing light to the desired color position, and then press the Enter key to confirm.

The background color can be changed in this screen, regardless of mode (day or night).

• Brightness setting



The brightness of the LCD is set to between 20 and 100%.

The brightness changes each time the adjustment is made.

Pressing the Enter key upon selecting the brightness setting symbol causes the value to flash for editing. To cancel editing, press the Menu key.

Use the Up (↑) or Down (↓) key to change the value, and then press the Enter key to complete editing.


(1) Day mode: initial setting value is 50%

(2) Night mode: initial setting value is 50%

Adjustment to the night (day) mode while in the day (night) mode cannot be synchronized.

For the key operations, refer to “Screen control key” on page 2-23.

• Unit setting




Switch between SI unit and US units.


Move the blue flashing light to the desired unit position, and then press the Enter key to confirm.



SWITCHING IMAGES



- Changing the background color (day/night)




Turn on the light switch on any screen to decrease the display brightness and to enter the “evening mode”.



SWITCHES

STARTER SWITCH




IMPORTANT: Do not repeatedly switch the key from OFF to ON and ON to OFF over a short period. Doing so will cause engine breakdown.

OFF Position for stopping the engine and inserting or removing the key.

ON Position in which the engine is running. At this position, all the electrical equipment is functional. When the coolant temperature is too low, the engine is automatically preheated.

START Position for starting the engine. When the key is released, the switch automatically returns to the ON position.


ENGINE SHUTDOWN SWITCH



This switch is used to shutdown the engine if it fails to stop, due to machine failure or breakage, when the starter switch is set to the OFF position.

1. Press the switch (1).
2. After use, reset the switch (1).

THROTTLE CONTROLLER




This controls the engine speed.

- (A) Low idling
(B) Medium speed
(C) Maximum speed



HORN BUTTON




Press the button situated on the right operating lever to blow the horn.

DECELERATION BUTTON

WARNING

Before operating the deceleration button, set the operating lever to the neutral position and take your foot off the pedals. If the deceleration button is pressed while driving, the machine's operating speed will abruptly change to result in a dangerous situation.




Press this button on the right operating lever to lower the engine speed to low idling. Press the button again to return to the engine speed set with the throttle controller. For safety reasons, it is designed that the deceleration function is activated to set the engine revolutions to low idling whenever the engine is started. Cancel the deceleration mode by pressing the deceleration button as necessary.

Note: This deceleration button is capable of decreasing the engine speed and reducing the fuel consumption, with a simple operation, in a situation such as when little engine output is required and thus the operating or the travel levers are in neutral.

TRAVEL SPEED BUTTON

WARNING

When a load greater than a set value is applied during traveling in 2nd (high) speed, the speed will automatically slow down to 1st (low) speed. When the load becomes lighter, the speed will increase and return to 2nd (high) speed. It should be noted that the travel speed changes depending on the load condition (for machines with the automatic travel shift-down system).




Press this switch to set the travel speed to 2nd (high) speed. Press it again to return to 1st (low) speed.



AUXILIARY 1ST SWITCHES

Auxiliary hydraulic buttons




Press those buttons to control the flow of the oil in the first auxiliary hydraulic lines.

- Proportional control of the auxiliary hydraulic circuit is not possible.
- (A).....Hydraulic oil flows to the left auxiliary line (a).
(B)Hydraulic oil flows to the right auxiliary line (b).

Slider switch (Proportional control)

Proportional control allows for slow-to-fast/ fast-to-slow movement of attachment.

Example: If you move the slider switch half way, the attachment will move at approximately one-half the speed.



Move this switch to control the flow of the oil in the first auxiliary hydraulic lines.

- (A).....Hydraulic oil flows to the left auxiliary line (a).
(B)Hydraulic oil flows to the right auxiliary line (b).


Refer to “Auxiliary hydraulic lines” on pages 2-76 to 2-81.

AUXILIARY 2ND/4TH SWITCH (IF EQUIPPED)

Slider switch (Proportional control)


Proportional control allows for slow-to-fast/ fast-to-slow movement of attachment.

Example: If you move the slider switch half way, the attachment will move at approximately one-half the speed.



Move this switch to control the flow of the oil in the second auxiliary hydraulic lines.

- (C):Hydraulic oil flows to the left auxiliary line (c).
(D):Hydraulic oil flows to the right auxiliary line (d).



To use the auxiliary 4th hydraulic line, press the auxiliary 2/4 select button to change to the operation of the auxiliary 4th.


Refer to “Auxiliary hydraulic lines” on pages 2-76 to 2-81.



SWING/SECOND BOOM SELECT BUTTON

WARNING

It is dangerous to turn on this switch while the boom swing/second boom pedal is depressed, as the attachment may move unexpectedly. Always set the boom swing /second boom pedal back to the neutral position before operating this select switch.



This switch is used to select either the boom swing operation or the second boom operation.



..... (a) swing display

..... (b) second boom display

When the switch is turned on, the second boom display (b) appears on the LCD to indicate that the second boom operation is enabled. When the switch is turned off, the display is changed to the boom swing to indicate (a) that the boom swing operation is enabled.

The actual boom swing operation is performed with the boom swing pedal. Refer to "Boom swing/Second boom pedal" on page 2-50.

THIRD AUXILIARY HYDRAULIC SWITCH AND BUTTON (IF EQUIPPED)

Refer to "Third auxiliary hydraulic switch and button" on page 2-79.

AUXILIARY 2/4 SELECT BUTTON (IF EQUIPPED)

Refer to "Auxiliary 2/4 select button" on 2-81.

THIRD AUXILIARY HARD-LOCK SWITCH (IF EQUIPPED)

Refer to "Third auxiliary hard-lock switch (if equipped)" on page 2-80.




DPF MANUAL REGENERATION/INHIBIT SELECT SWITCH <APPLICABLE MACHINE MODELS 185100001 OR LATER>

WARNING



- The DPF and the exhaust gas emitted from the exhaust line can be very hot while the engine is running or the regeneration is under way, as well as immediately after the engine is stopped. Be careful not to accidentally touch them; doing so could cause burns.
- Do not perform the DPF regeneration if the machine is surrounded by flammable items such as plants, trees, dry grass, wastepaper, oil and waste tires. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF.
- Do not perform the DPF regeneration in poorly-ventilated indoor spaces, as smoke could be generated during the DPF regeneration or carbon monoxide poisoning could result.
- Do not perform regeneration when the engine hood is open. There is a risk of fire due to the high-temperature exhaust gas emitted from the DPF.




IMPORTANT: Press the manual regeneration side on the DPF manual regeneration/inhibit select switch to burn the particulate matter (PM), when the DPF manual regeneration lamp flashes and an alarm sounds. If the machine continues to be operated without performing the manual regeneration, the engine power will decrease and eventually the engine will stop running. The ECM warning display will also flash if the DPF needs to be repaired. A number appears on the engine error code screen. Refer to the “Engine error code list” and contact a Takeuchi sales or service dealer for repair.

• DPF manual regeneration

When the DPF manual regeneration symbol on the display starts flashing and an alarm starts sounding, perform the DPF manual regeneration by following the procedure below.

1. Park the machine in a safe place where there is no fire hazard.
2. Raise the safety lock lever to the lock position.
 - Do not lower the safety lock lever and move the control levers during regeneration. Doing so interrupts the regeneration.
3. Decrease the engine speed to low idling.
4. Press and hold the manual regeneration side on the DPF manual regeneration/inhibit select switch.



5. The manual regeneration symbol stops flashing and remains lit to indicate that the engine RPM is automatically increased and the DPF (1) regeneration (PM burning) has started.
6. Release the switch. Do not leave the machine during regeneration. It takes approximately 25 to 30 minutes, depending on the ambient temperature, to complete the regeneration operation.
7. The manual regeneration symbol goes off to indicate the end of manual regeneration.

Note:

- Since the exhaust gas is cleaned through the catalyst fitted inside the DPF, it has a smell different from that of the conventional diesel engine.
- In some cases smoke may be emitted from the tail pipe while the DPF regeneration is being performed. This is not a failure; it is due to burning of the particulate matter (PM).
- It is normal that a sound is produced when the DPF regeneration is started or completed; This is to adjust the air-intake throttle and EGR opening position.
- In some cases the noise associated with the DPF regeneration operation or cancel operation may change; this is not a failure.
- The DPF manual regeneration can be completed faster while the machine engine is warm rather than cold. Note that the manual regeneration does not start unless the coolant temperature is higher than a set value. The coolant temperature may increase while manual regeneration is being performed.

- Since the DPF regeneration is designed to work only when the accumulated particulate matter (PM) in the filter exceeds a certain amount, it will not start otherwise, even if you attempt to perform manual regeneration.

• **DPF regeneration inhibit (cancel)**


To cancel the DPF regeneration currently being processed (manual or auto), press the regeneration inhibit symbol side.

The DPF regeneration inhibit symbol appears on the display, and the regeneration operation must be performed again. Start the manual regeneration procedure from Step (1) above, as soon as possible. Do not press the DPF regeneration inhibit switch unless there is a risk of fire.

To cancel, press the switch again. Turning the starter switch to OFF will also cancel the operation.

Refer to “DPF auto regeneration/inhibit indicator lamp” and “DPF manual regeneration under way/regeneration promoting indicator lamp” on page 2-19.

LIGHT SWITCH



When this switch is turned while the starter switch is at ON, the lights turn on as follows:

OFFOff

ONSwitch lamps, front light, boom light, side lights and tail lamps will be lit.
(switch lamp is lit)




WIPER SWITCH

IMPORTANT: If no washer fluid is discharged, do not operate the washer. Doing so may damage the pump.

IMPORTANT: Operating the wiper with no moisture on the windshield will scratch the glass. Use water or washer fluid when operating the wiper.

IMPORTANT: In cold climates, the wiper blade may freeze to the glass. Operating the wiper forcibly may damage the wiper motor.




OFFOff

INTIntermittence operation


ONContinuous operation

WASHER SWITCH



ONPressing the ON side of the switch causes the washer to spray washer fluid. To stop spraying, release the switch.

AUTOMATIC DECELERATION SWITCH




When the ON side of the switch is pressed, the deceleration lamp in the instrument cluster flashes. This flashing stops when the deceleration function starts working, and the lamp remains lit while in the deceleration mode. The engine speed automatically drops to low idle (deceleration mode) four seconds after the control levers are set to neutral, to reduce fuel consumption. Moving the control levers will cause the speed to return to the original engine speed.

Switching from the deceleration button to the auto-deceleration switch will first return to the engine speed set with the throttle controller. Then, the engine will automatically enter the deceleration mode (low idling) if the control levers are not operated within four seconds.



POWER/HIGHLAND MODE SWITCH



• Power mode

- Pressing the PWR symbol side of the switch turns on the Power mode indicator lamp on the instrument cluster. The maximum engine output is obtained.
- STD mode: Pressing the PWR symbol side of the switch again turns off the power mode indicator lamp.


• Highland mode

This switch is used to reduce the engine load due to the hydraulic pump. When the machine is operated at a high-altitude site, the engine output is decreased due to thin air. In such cases, the hydraulic horse power is automatically adjusted to prevent the engine from stalling. Use this switch when the machine is operated at a high-altitude site.

- Pressing the PWR symbol side of the switch turns on the Power mode indicator lamp on the instrument cluster.
- To cancel the highland mode, press the PWR symbol side halfway to set to the neutral position. The highland mode indicator lamp goes out and enters the lowland mode. Refer to “Multi-information display” on page 2-16.

DETENT MODE SWITCH (AUXILIARY 1ST)


IMPORTANT: Do not operate the machine in the detent mode for a long time. Doing so will increase the hydraulic oil temperature and shorten the service life of the hydraulic units.



This switch is used to change the operation mode of the auxiliary 1st button (A). Pressing the ON side of the switch causes the auxiliary button (A) to enter the detent mode. Pressing the OFF side changes to the momentary mode.



AUXILIARY 1ST AUTO TANK SWITCH (IF EQUIPPED)




Use this switch to change the direction of hydraulic oil flow in the Aux. 1st line.

- (1) When using a hydraulic breaker (1-way flow)
- (2) When using a reversible attachment (2-way flow)
- (3) The one-way flow can be set only when the button "A" of the Aux. 1 is pressed. (The tank circuit is automatically opened.)

lift overload warning switch is turned on.)
OFFOff
ONOn

BEACON LAMP SWITCH




When this switch is turned on while the starter switch is at ON, the lamp turns on as follows:

OFFOff
ONBeacon lamp is lit

LIFT OVERLOAD WARNING SWITCH

WARNING

If the overload is not removed after the overload warning horn is sounded, the machine may tip over or the emergency shut-off valve may be activated. If the horn starts sounding, stop operating the machine and lighten the load.



If a weight greater than the lifting capacity is applied or lifted, the overload warning device is activated and the horn sounds. (When the




LEVERS AND PEDALS

SAFETY LOCK LEVER

WARNING

- Before standing up from the operator's seat to open/close the window or remove/install the lower window, lower the working equipment to the ground, raise the safety lock lever to engage the lock and stop the engine. If any controls should be accidentally touched when the safety lock lever is lowered (unlocked), the machine will suddenly move and cause serious injury or death.
- Be careful not to touch the operating levers when raising or lowering the safety lock lever.
- Before leaving the operator's seat, lower the working equipment to the ground, raise the safety lock lever to engage the lock and stop the engine. Also, be sure to remove the key, lock the door and covers, take it with you and store it in a specified place.



This device is for locking the operations of hoe attachment, slewing, auxiliary, dozer blade and traveling. When the lever is raised, the lever stand springs up to lock the lever.

Safety start function

<Applicable machine models 185104996 or later>


<Applicable machine models 190200924 or later>

When the lever is in the unlock position, the engine cannot be started.

OPERATING LEVERS

WARNING

- Before starting operation, carefully check which lever pattern you are going to use.
- It is described using the ISO pattern in this manual.




Use these levers to operate the boom, arm, bucket and upperstructure.

Refer to "Lever pattern" on pages 3-8 and 3-9.

Refer to "Operating the working equipment" on pages 3-16 and 3-17.



BLADE LEVER



Use this lever to operate the dozer blade.

(A).....Blade up

(B)Blade down

Refer to “Operating the dozer blade” on page 3-17.


Machines with the float button (USA specification)



WARNING

- Do not press the float button while the machine is raised by the blade. Doing so will cause the machine to fall. If you must work beneath the raised machine, always use a secure support to keep the machine raised.
- Do not press the float button while the blade is raised. Doing so will cause the blade to fall. Lower the blade to the ground before pressing the float button.
- Do not travel forward while the blade is in the float mode.

Float operation



Button (C). Float mode

Press the float button (C) to set the dozer blade to the float mode.


To cancel the float mode, press the float button (C) again. The float mode is temporally cancelled when the blade lever is tilted backward. To return to the float mode, tilt the blade lever back to the neutral position. Take caution when returning to the float mode.



TRAVEL LEVERS/PEDALS

WARNING

- Before operating the travel levers/pedals, make sure that the dozer blade is to the front of the operator's seat. Remember that when the dozer blade is to the rear of the operator's seat, the travel levers/pedals must be operated in the reverse direction from when it is to the front.
- Do not rest your foot on the pedal unless operating it for traveling. If the pedal is accidentally stepped while working, the machine may suddenly move and cause serious injury or death.




Use these levers/pedals to move forward or backward and to change directions. Refer to "Operating the travel levers/pedals" on page 3-12.

BOOM SWING/SECOND BOOM PEDAL

WARNING

Keep the pedal cover to the locked position when not using the pedal. Stepping on a pedal accidentally when it is not locked may cause accidents.




Use this pedal to operate the boom swing. If the 2-piece boom select switch is pressed, the operation will change to the second boom.

(A).....Boom swing right /Second boom lower

(B)Boom swing left /Second boom raise
Refer to "Operating the boom swing" on page 3-17.

Pedal lock



Set the pedal cover over the pedal to lock it. Open the pedal cover from the pedal to unlock it.



ACCESSORIES

AIR CONDITIONER

CAUTIONS ON USE

Ventilate periodically

- When using the air conditioner over an extended period of time, open the windows about once each hour to let in fresh air.
- Your eyes may become irritated if you smoke while using the air conditioner. If this happens, open the windows to let in fresh air. Smoking particularly irritates the eyes when the air conditioner is being used. Since the humidity in the cab drops, the cornea becomes dry.
- If the outside air is dirty, set the air conditioner to the circulation mode.

Always maintain good visibility

Working with dirty windows or fogged windows restricts visibility and is dangerous. Always clean dirt and moisture off the windows before working.

- The windows tend to get foggy when the humidity is high. If this happens, turn on the air conditioner to use outside air and the defroster to get rid of the fog.
- If the air conditioner is set to high when using the defroster, the difference between the external and internal temperatures increases, resulting in frost on the outside of the windows. If this happens, either turn the air conditioner off or turn the temperature control dial clockwise to increase the internal temperature.
- Mist may blow out of the air outlets. This is not a malfunction. When moist air passes through the evaporator on the air conditioner unit, water particles in the air freeze and are emitted as mist.

Do not overcool

For health reasons, the air inside the cab should be kept at a temperature at which you feel a little cool when entering the cab from outside (a difference of 5 to 6°C (9 to 12°F)). Remember to adjust the temperature properly.

Do not turn on the air conditioner until the engine is started

To avoid placing an excessive load on the compressor, wait until the engine is started and is running smoothly before turning on the air conditioner.

Let hot air out first

If the machine has been parked in the sun, open the windows and door to let the hot air out of the cab before using the air conditioner.

Caution on refrigerant (gas)


If the refrigerant comes in contact with skin or eyes, it may cause frostbite or eye damage. Never touch the refrigerant or loosen the parts on the cooling circuit. If the refrigerant gas leaks, keep flames away.

Off-season inspection


Even off season, run the air conditioner for 3 to 5 minutes at least once a week to maintain oil in the various parts of the compressor.



NAMES OF COMPONENTS



1. Defroster
2. Condenser
3. Receiver dryer
4. Outlets
5. Compressor
6. Air conditioner unit
7. Circulation filter
8. Ventilation filter




Control panel

9. Air conditioner switch
10. Temperature control dial
11. Fan dial
12. Outlet select dial
13. Ventilation/Circulation select switch



Air conditioner switch

IMPORTANT: To avoid placing an excessive load on the compressor, wait until the engine is started and is running smoothly before turning on the air conditioner.



Use this switch to turn on or off the cooling/dehumidifying function. When this switch is pressed while the engine is running with the fan dial set to ON, the lamp lights up and the cooling/dehumidifying function is turned on. Press this switch again or turn the fan dial to OFF to turn off the cooling/dehumidifying function.


Lamp is offOFF

Lamp is onON

Note: To prevent leakage of refrigerant gas from the compressor's seal, operate the air conditioner at least once a week, regardless of the season.

Note: The air conditioner will not function if the temperature in the cab is low (3°C (38°F) or lower).

Fan dial




Use this switch to adjust the fan speed in five steps. Turning this switch to the OFF position turns off the air conditioner.

AUTO The airflow rate can be automatically adjusted based on the position of the temperature control dial.

OFF Turning off the fan and the air conditioner.

1 to 5 A larger number indicates larger airflow rate.

Temperature control dial




Use this dial to adjust the air temperature.

Turn the dial clockwise to increase the temperature. Turn the dial counterclockwise to decrease the temperature.

Note: No warm air is emitted if the temperature of the engine coolant is low.




Outlet select dial



Use this dial to select the desired outlet depending on the purpose of use.

-Air comes from the front and rear outlets.
 -Air comes from the front, rear and foot outlets.
 -Air comes from the foot outlet.
- Arrange the air direction at each outlet.

Ventilation/Circulation select switch



Use this switch to select between Ventilation and Circulation.

Press this switch once to turn on the lamp and set to Circulation. Press this switch again to turn off the lamp and set to Ventilation.


Lamp is onCirculation

- Cool or heat the cab quickly
- When external air is dirty

Lamp is offVentilation

- Lets in fresh air
- Removes frosting from the windows
- Ventilates while cooling or heating



Outlets



Move the louvers up and down or left and right to adjust the air flow direction and amount.

Operation

Dehumidifying and Heating (in cold climates or when the humidity is high)



Arrange the foot outlets and the defroster so that they are directed to the front window. Let the dehumidified warm air blow on the front window, to prevent frosting.


1. Set the desired temperature by turning the temperature control dial to between the center and the right end.
2. Set the fan dial to the desired position.



Cooling


CAUTION

- When the air conditioner is set to the circulation mode, the air in the cab gradually becomes dirty. Switch to the “ventilation” to ventilate once a comfortable temperature is obtained.
- Excessive cooling can be harmful to your health. It is best to keep the air inside the cab only about 5 to 6°C (9 to 12°F) cooler than the outside air.
- If the machine has been parked in the sun, open the windows and door to let the hot air out of the cab before using the air conditioner.



1. Turn the air outlet dial to the FACE or FULL position.
2. Set the desired temperature by turning the temperature control dial to between the center and the left end.
3. Set the fan dial to the desired position.

Quick cooling



1. Turn the air outlet dial to the FACE or FULL position.
2. Turn the temperature control dial to the left end.
3. Set the fan dial to “5”.
4. Press the Ventilation/Circulation select switch to set to circulation.


Heating

1. Turn the air outlet dial to the FOOT position.
2. Set the fan dial to the desired position.
3. Set the temperature control dial to the desired position.
For the highest temperature, turn the dial all the way to the right.
4. Turn the fan dial to the OFF position to turn off heating.



Defrosting or defogging the windows

Note: If the air conditioner fan is set to High when using the defroster, the difference between the external and internal temperatures increases, resulting in frost on the outside of the windows. If this happens, either turn off the air conditioner or turn the temperature control dial clockwise to increase the internal temperature.




1. Set the desired temperature by turning the temperature control dial to between the center and the right end.
2. Set the fan dial to the desired position.
3. Press the Ventilation/Circulation select switch to set to ventilation.
4. Arrange the foot outlets and the back outlets of the defroster so that they are directed to the front window.

CUP HOLDER

CAUTION

- Drinks may be spilled due to vibration when the machine is operating or traveling. Be particularly careful not to burn yourself with hot drinks.
- Note that the cigarette lighter or other electric parts may be damaged if drinks are spilled on them.



Use to hold cups or bottles.

To warm or cool the cup, turn the cup holder in counterclockwise. Warm or cool wind blows from the bottom of the cup holder.




CIGARETTE LIGHTER

WARNING

- Do not leave the cigarette lighter knob pushed in for a long time. Doing so heats up the lighter, and could be dangerous.
- If the lighter knob does not pop out 30 seconds after it was pushed in, it may be broken. Pull it out by hand.
- Do not use any other cigarette lighters than Takeuchi's. They could be stuck in the middle and not pop out.
- Use only those electric products which comply with the specifications of this socket.
- Do not touch the metallic parts of the lighter. Doing so could cause burns.

This is the cigarette lighter and internal power supply socket.

When using, be careful not to exceed 12V/5A.




1. Push the lighter in.
2. Release the lighter and wait for it to pop out. The lighter pops out automatically when the heater becomes red hot.
3. Once the lighter pops out, pull it out.

ASHTRAY

WARNING

- Be sure to extinguish cigarettes and matches completely before putting them in the ashtray, and close the ashtray after each use.
- Do not overfill the ashtray with cigarette butts or put in paper or other easily burnable objects. Doing so could cause fire.




Pull the ashtray out towards you to use it. To clean, press the ash discharge button (1) and pull out the ashtray.



INTERIOR LIGHT

IMPORTANT: The battery capacity decreases if the interior light is left on for a long time when the engine is stopped.



OFFRemains off all the time.

ONLights up all the time.




EXTERNAL POWER SOCKETS




WARNING

Use only those electric products which comply with the specifications of these sockets.



For beacon



Use these sockets to connect the external power supply. When using, be careful not to exceed 12V/5A.

To use, open the cap (1).




RADIO

If the radio installed on the machine is a Bluetooth-equipped one, refer to “Radio (Bluetooth equipped)” on page 2-64.

CAUTIONS ON USE

- To ensure safe operation of the machine, always be sure to keep the volume of the radio down to a level where you can easily hear sounds from outside the machine.
- Do not use the radio for a long time when the engine is stopped. Doing so will drain the battery and make it difficult or impossible to restart the engine.
- Be careful not to allow water or other liquids to come into contact with the radio. Otherwise, it may result in malfunction.

NAMES OF COMPONENTS



(1) POWER button

Use this button to turn on or off the radio.

(2) LCD

Displays the time/the receiving frequency and the operation mode.

(3) Display button (DISP)

Pressing this button while the frequency is displayed on the LCD changes the display to the clock. Pressing the button again returns to the frequency. If the button is not pressed for five seconds, the display returns to the frequency.

(4) Auto store/Auto seek station (AST)

Press this button to automatically assign receivable radio stations to preset buttons (1 to 6).

(5) Tuning button (TUNE)

Press and hold this button (or) for one second or more to start seeking the receivable stations. The seeking stops when a station is found. To cancel tuning halfway, press the button again. Pressing the TUNE button starts seeking stations with higher frequency. Pressing the TUNE button starts seeking stations with lower frequency. The frequency changes as either button is pressed in one second intervals.



(6) Preset buttons (1 to 6) (PRESET STATION)

Each button can store three FM stations (FM1, FM2, FM3) and one MW (AM) station. For how to set these buttons, refer to "Presetting stations".

(7) Band button (BAND)

Pressing this button changes the band from FM1 to FM2, FM3 and MW (AM) in this order. The received band and its frequency appear on the display.

(8) VOL buttons

Use these buttons to control the sound volume. Press the button  to increase the volume and the button  to decrease the sound volume. Press and hold each button to continuously increase/decrease the volume.

(9) Clock zero set button (ZERO)

Use this button to set the minute to "00" when it is between "55" to "59" or "01" to "05".

The LCD returns to the frequency display if no more operation is performed for five seconds.

(10) Auxiliary input select button (AUX)

Pressing this button changes the input source to the external device connected to the AUX-IN (11) jack. The display of "AUX" appears on the LCD. Pressing the button again returns to the radio.

(11) Auxiliary input jack (AUX-IN)

Use this jack to connect an external audio source such as a portable music player. Pull off the rubber cap and connect the output terminal (headphone jack) of the portable player to the AUX-IN with the stereo mini-plug (3.5 mm) cord.

Be sure that jack is closed with the rubber cap when not in use.

Playing the radio

1. Turn the starter key to the ACC or ON position, and then press the power button (1) to turn on the radio.
2. Select the band, FM or MW (AM) by pressing the BAND button.
3. Select the station with the preset button or the tuning button, and adjust the volume with the volume button.
4. To turn off the radio, press the power button.

Selecting a station-auto select

Press and hold the TUNE button  for one second or more to start seeking stations in the higher frequencies direction. Press and hold the TUNE button  for one second or more to start seeking stations in the lower frequencies direction. The radio will stop seeking when it finds an receivable station and start playing.

Selecting a station-manual select

The selection can be done manually. Press the tune  button to seek stations with higher frequencies. Press the tune  button to seek stations with lower frequencies.



Presetting stations

1. Press the BAND button to select a band (MW (AM) or FM), and then select the station by pressing the TUNE button for seeking.
2. To assign the selected station to a preset button, press and hold the button to be assigned for one second or more. The number of the preset button appears on the LCD.
3. For more stations to preset, repeat the steps 1 and 2 above.
 - If the preset button on which a station has been assigned is pressed and held for one second or more, the preset information will be modified.
 - If the stored information is erased during battery replacement on the vehicle, assign the stations again to the preset buttons.
 - Each preset button (1 to 6) can store three FM stations (one from each FM1, FM2, FM3) and one AM station.

Auto storing (AST)


Press the AST button while playing the radio. The radio automatically starts seeking the receivable stations within the band currently selected and assign each preset button (1 to 6) a station.

Note: The previous stations stored will be cleared (cancelled) by the auto storing. If the station stored in the preset button is not desirable, try to preset the station manually.

Auxiliary input (AUX)

- Connect a portable audio player and listen to your favorite music.
- Plug a patch cord (without resistor) into the headphone jack of the audio player.
- Plug a stereo mini plug (3.5 mm) into the AUX-IN jack on the radio.
- To listen to an external portable audio player, press the AUX button. (The “AUX” display appears on the LCD and the frequency display is changed to the clock display.)
- To return to the radio, press the AUX button again.
- When connecting, adjust the sound volume level of the audio player so that it is same as that of the radio.
- Adjust the sound volume of the audio player by using the volume control buttons on the radio.
- Do not connect a device with a larger output compared with a portable audio player.

Setting the clock



- If a frequency is displayed on the LCD, press the AUX button (auxiliary input) to display the clock.
- Use the tune (M) button to set the minute. Use the tune (H) button to set the hour.
- To set the minute digits to “00” when they are from “55” to “59” or from “01” to “05”, press the ZERO button.



Resetting (North, Central and South America)

If there are any problems, such as the abnormal display of frequency or failure of selection, reset the radio by pressing the “3” button* while pressing the AST button and the AUX button together. Then, “US”** and the clock display appear on the LCD, indicating that the radio is turned off. Note that the memory stored in the preset button is cleared.

*: “6” button – (Europe, Asia, Oceania)

“5” button – (China)

** : EU – (Europe, Asia, Oceania)

CH - (China)

Switching the volume mode when the radio is on

Switch the modes between SU and FI by pressing the (1) button while pressing the AST and AUX buttons together, when the radio is on.

The SU or FI display appears on the LCD, followed by the radio turning off by itself.

SU mode:The volume at power-off is retained.

FI mode:The volume at power-off is reset.

SPECIFICATIONS

Power source: 12/24 VDC (negative ground)

Maximum power consumption:

..... 3A or less (at max. volume, 24 V)

Maximum output power:

..... 16 W + 16 W (4Ω) (at 28.8 VDC input)

5W+5W (4Ω) (at 14.4 VDC input)

Rated output power:

..... 12 W + 12 W (10% distortion, 4Ω) (at 28.8 VDC input)

3.5 W + 3.5 W (10% distortion, 4Ω) (at 14.4 VDC input)

Dimensions: 178 (W) x 50 (H) x 65 (D) mm (excluding protrusions)

Receiving frequency:

..... MW (AM) 531 to 1602 kHz (Europe, Asia), 530 to 1710 kHz (North, Central and South America)
FM 87.5 to 108 MHz (Europe, Asia), 87.9 to 108 MHz (North, Central and South America)

Practical sensitivity:

..... MW (AM) 32 dB or less (S/N 20 dB)
FM 12 dB or less (S/N 30 dB)

S/N ratio: MW (AM) 40 dB or more
FM 50 dB or more

AUX-IN: Stereo mini jack (3.5 mm); rated input, 90 mV; 20 kΩ impedance

Note: Specifications and dimensions may be changed without notice.




RADIO (BLUETOOTH EQUIPPED)

If the radio installed on the machine is not a Bluetooth-equipped one, refer to “Radio” on page 2-60.

CAUTIONS ON USE

- To ensure safe operation of the machine, always be sure to keep the volume of the radio down to a level where you can easily hear sounds from outside the machine.
- Do not use the radio for a long time when the engine is stopped. Doing so will drain the battery and make it difficult or impossible to restart the engine.
- Be careful not to allow water or other liquids to come into contact with the radio. Otherwise, it may result in malfunction.

NAMES OF COMPONENTS



AP1C004




(1) POWER button

Use this button to turn on or off the radio.

(2) LCD

<Home screen>



(1) Operation mode

USB: USB audio mode


BT: Bluetooth mode

AUX: Auxiliary in mode

(2) Volume level

(3) Audio control (For USB audio or Bluetooth mode only)

<Radio mode screen>



(1) Radio band display

FM1, FM2 FM3: FM band (Six stations can be preset to each band.)

MW: AM band

(2) Stereo display

Turns on when receiving stereo.

(3) Preset station

(4) Display of frequency/clock

Displays the time/the receiving frequency and the operation mode.

(3) Clock button (CLOCK)

Pressing this button changes the display to the clock. Pressing the button again displays the frequency. If the button is not pressed for three seconds, the display returns to the frequency. Pressing and holding the button enters the clock setting mode.

(4) Auto store/Auto seek station (SCAN)

Press this button to automatically assign receivable radio stations to preset buttons (1 to 6).

(5) Tuning button (TUNE

Press and hold this button (TUNE  or TUNE  for two seconds or more to start seeking the receivable stations. The seeking stops when a station is found. To cancel tuning halfway, press the button again.

Pressing the TUNE  button starts seeking stations with higher frequency. Pressing the TUNE  button starts seeking stations with lower frequency.

(6) Preset buttons (1 to 6) (PRESET STATION)

Each button can store three FM stations (FM1, FM2, FM3) and one MW (AM) station.

(7) Band button (BAND)

Pressing this button changes the band from FM1 to FM2, FM3 and MW (AM), in this order.



(8) Volume control button (VOL $\oplus \Rightarrow$)

Press the VOL $\oplus$ button to increase the volume and the VOL $\Rightarrow$ button to decrease the volume.

(9) Bluetooth button (B)

Press this button to connect to the already paired and most recently connected Bluetooth-enabled device.

(10) Bluetooth LED

Lights up when a Bluetooth-enabled device is connected. Flashes while in the pairing standby mode.

(11) Operation mode select button (MODE)

Pressing this button changes the operation mode from FM or MW (AM) to Bluetooth, USB and AUX, in this order.


(12) Auxiliary input jack (AUX)

Open the rubber cap and connect to an earphone jack of a smartphone or portable audio player with a commercially available stereo mini-plug (3.5 mm) cable. Be sure that jack is closed with the rubber cap when not in use.

(13) USB jack

Open the rubber cap and connect to a USB flash drive with a commercially available USB extension cable. Be sure that jack is closed with the rubber cap when not in use.

Setting the clock



1. Press and hold the CLOCK button for at least two seconds to enter the clock setting mode. (The time display starts flashing.)
2. Use the tune $\uparrow$ button to set the minute. Use the tune $\downarrow$ button to set the hour.
3. Press the CLOCK button again to return to the clock display.



Playing the radio

1. Select the band, FM or MW (AM) by pressing the BAND button.
2. Select the station with the preset button or the tuning button.
3. Adjust the volume with the VOL (⇐ or ⇒) button.

Seeking stations (auto)

Press and hold the TUNE (⬆) button for two seconds or one to start seeking stations in the higher frequencies direction. Press and hold the TUNE (⬇) button for two seconds or more to start seeking stations in the lower frequencies direction. The radio will stop seeking when it finds a receivable station and start playing.

Manual tuning

Press the TUNE (⬆) button to increase the frequency by one step. Press the TUNE (⬇) button to decrease the frequency by one step.

Presetting stations

1. Press the BAND button to select a band (MW (AM) or FM), and then select the desired station.
2. To assign the selected station to a preset button, press and hold the button to be assigned for three seconds or more. The number of the preset button appears on the LCD to indicate that it is stored in the preset memory.
3. For more stations to preset, repeat the steps 1 and 2 above.
 - Each preset button (1 to 6) can store three FM stations (FM1, FM2, FM3) and one MW (AM) station.

Auto storing stations (SCAN)

Press the SCAN button while playing the radio. The radio automatically starts seeking the receivable stations in the band currently selected and assign each preset button (1 to 6) a station.

Note: The previous stations stored will be cleared (cancelled) by the auto storing. If the station stored in the preset button is not desirable, try to preset the station manually.



Playing back audio content stored on a USB flash drive

To enter the USB playback mode, first insert the USB flash drive while playing the radio and then press the MODE button. (The LCD changes to the time display and “USB” appears on the LCD.)

When playing back audio content stored on the USB drive, the following operations are available using the buttons (1) to (5).

(1) Backward (⏮) button

Moves one track backward and starts playing back from the beginning of it.

(2) Playback/Pause (⏮⏭) button

Pauses playback when pressed during playback. When pressed again, starts playback from the point where the playback was paused.

(3) Stop (⏻) button

Stops playback when pressed during playback. When the Play/Pause button is pressed, the unit starts playing back the stopped track from the beginning.

(4) Forward (⏭) button

Moves one track forward and starts playing back from the beginning of it. Pressing and holding the button will fast forward the current track.

(5) Repeat (🔄) button

When pressed during playback, the unit repeats the current track.
To cancel repeating, press the button again.

Notes:

- When in the USB playback mode, do not insert or remove the USB drive.
- ESPERIA makes no warranty that the unit is compatible with every USB storage device.
- To connect the USB flash drive to the unit, use a commercially available USB extension cable.
- Do not connect any device other than a USB flash drive. The USB jack cannot be used to charge a device such as a smartphone.
- Please be advised that ESPERIA bears no responsibility for any damage to or loss of data on the USB drive arising from the use of the unit.

Using the Bluetooth wireless technology

You can use your Bluetooth-enabled mobile phone or audio device by connecting it to the unit.

When a mobile phone is connected, incoming calls will be announced.

Note: Since the unit is not equipped with a microphone, the unit cannot be used for phone calls.

To use the Bluetooth device, certain profiles must be able to interpreted.

The unit is compatible with the following profiles:



Incoming mobile phone call

HFP (Hands-Free Profile)

Bluetooth audio

A2DP (Advanced Audio Profile)

AVRCP (Audio Video Remote Control Profile)

Note: The Bluetooth® word mark and logos are owned by the Bluetooth SIG, Inc. and any use of such marks by ESPERIA is under license.

Pairing a Bluetooth-enabled device

When pairing the unit with a Bluetooth device for the first time, you have to pair with each other.

Once pairing is done, the unit and the paired Bluetooth device can recognize each other.

Note: Before pairing with the unit, turn on the Bluetooth feature on the Bluetooth device. Refer to the instruction manual of the Bluetooth device for further instructions.

1. Press the MODE button to switch to the Bluetooth mode.
2. Turn on the Bluetooth feature on the Bluetooth-enabled device.
3. Press and hold the Bluetooth button until two short beeps are heard, indicating the unit has entered the pairing standby mode.
4. Select "CAR RADIO" on the Bluetooth-enabled device.

Note: Only one Bluetooth-enabled device can be paired and used at a time. To use a different device, follow the steps 1 to 4 for pairing again.

Note: At power-up, the unit automatically reconnects to the device most recently connected. When you leave the machine, cancel pairing by pressing and holding the Bluetooth button until two short beeps are heard, to avoid misconnection.

Playing back audio content stored on a Bluetooth-enabled device

When a Bluetooth-enabled device has been paired with the unit, check if the Bluetooth LED is lit, and then press the MODE button to enter the Bluetooth mode.

While the Bluetooth device is connected, the following operations are available using the buttons (1) to (5).

(1) Backward (⏮) button

Starts playing back from the beginning of the track currently playing. Pressing and holding the button will skip backward to the desired track.

(2) Playback/Pause (⏮⏭) button

Pauses playback when pressed during playback. When pressed again, starts playback from the point where the playback was paused.

(3) Stop (⏻) button

Stops the currently playing audio.

(4) Forward (⏭) button

Moves one track forward and starts playing back from the beginning of it.

(5) Repeat (🔄) button

Disabled in the Bluetooth mode.

Note: If no sound is heard from the unit, check to see that the output destination of the music from the Bluetooth device is set to "CAR RADIO".



Receiving an incoming call on the Bluetooth-enabled device

If a Bluetooth-enabled device has been connected, the unit enters the standby mode and waits for a call. When an incoming call arrives, "CALL" appears on the display, the volume of the car stereo is set to mute and the ringtone is heard from the speaker.

Auxiliary input (AUX)

- Connect a portable audio player and listen to your favorite music.
- Plug a stereo mini plug (3.5 mm) into the AUX-IN jack on the radio.
- Press the MODE button and select "AUX" to switch to the AUX mode. (The "AUX" display appears on the LCD and the frequency display is changed to the time display.)
- To return to the radio, press the MODE button again.
- When connecting, adjust the sound volume level of the audio player so that it is same as that of the radio.
- The sound volume can be adjusted with the volume control buttons on the unit.
- Do not connect a device with a larger output compared with a portable audio player.

Resetting the radio

If there is a problem such as display of incorrect frequency or failure in selecting, reset the unit by pressing the POWER button while pressing the Bluetooth button [B]. (In this case, the preset memory stations and clock are cleared.)

If you cannot reset the unit, please contact your sale or service dealer for help.



SPECIFICATIONS

Power source: 12/24 VDC (negative ground)
Max. power consumption: 2 A or less (at max. volume, 24 V)
Max. output power: .. 16 W + 16 W (4Ω)
Rated output power: 14 W + 14 W (10% distortion, 4Ω)
Dimensions: 178 (W) x 50 (H) x 91 (D) mm (without projections)
Receiving frequency: MW (AM) 522 to 1629 kHz
FM 76.0 to 95.0 MHz
Practical sensitivity: .. MW (AM) 20 μV (S/N 20 dB)
FM 30 μV (S/N 30 dB)
S/N ratio: FM 50 dB
AUX IN: Stereo mini jack (3.5 mm); max. input, 1 V; rated input, 90 mV
Bluetooth standard: .. Ver. 2.1 + EDR
Output: Class 2 (max. communication range 10 m)
Receiving frequency: 2.4 to 2.48 GHz
Supported profile: HFP V 1.5, A2DP V 1.2, AVRCP V 1.0
USB standard: USB 2.0/1.0
Supported file
• MP3: MPEG 1/2/2.5
..... Audio Layer 2/3
• WMA: Windows Media™ Audio
Supported format: FAT16/FAT32 file system
Max. output power: .. 0.5 A

TROUBLESHOOTING

For symptoms not included in the table below or if the problem persists after the proper remedies have been taken, consult your sales or service dealer.

Note: The appearance and specifications are subject to change for improvement without prior notice.



General

Symptoms	Major causes	Remedies
Radio does not operate or the display is inaccurate when the button is pressed.	• CPU malfunction due to noises, etc.	• Reset the unit by referring to “Resetting the radio”. Note that once reset, all settings are cleared; set the unit again.
The clock is not displayed.	• Backup power supply (orange cable) is not connected.	• Consult your sales or service dealer for help.

Radio

Symptoms	Major causes	Remedies
Sound is noisy.	• Incorrect frequency for the station • Antenna (pillar antenna) is not extended. • Antenna is not grounded or properly installed. • The antenna is not connected to the power supply	• Tune to the correct frequency for the station. • Be sure to extend the pillar antenna when using the radio. • Consult your sales or service dealer for help. • The power supply must be connected to the antenna with a built-in booster. For details on the connection, contact your sales or service dealer.
Unrealistic frequency is displayed.	• CPU malfunction due to noises, etc.	• Reset the unit by referring to “Resetting the radio”. Note that once reset, all settings are cleared; set the unit again.



USB

Symptoms	Major causes	Remedies
No sound is heard.	• The USB flash drive has no MP3/WMA files. • The files on the drive are not MP3/WMA.	• Write the MP3/WMA files correctly on the USB flash drive. • Use the MP3/WMA files properly encoded.
Sound skipping occurs. Noises are heard.	• The MP3/WMA files are not properly encoded.	• Use the MP3/WMA files properly encoded.
A USB device is not recognized.	• The USB flash drive is damaged. • The USB connector is not properly connected. • The USB flash drive is not formatted to FAT32/16.	• Disconnect the USB flash drive from the unit, and then reconnect it. If the drive is still not recognized, replace it with a new one. • Format the USB flash drive to FAT32/FAT16, and then rewrite the MP3/WMA file. Be sure to back up the files on the drive before formatting it.



Bluetooth

Symptoms	Major causes	Remedies
A Bluetooth device cannot be connected.	• The Bluetooth device is not connected. • Another Bluetooth device is connected.	• Some Bluetooth devices require longer time for connection and cannot be reconnected automatically. Check if the Bluetooth button is lit. If it does not turn on after a while, re-pair the device by referring to “Pairing a Bluetooth-enabled device”. • If another Bluetooth device is connected, re-pair the device by referring to “Pairing a Bluetooth-enabled device”.
A Bluetooth device cannot be remote controlled.	• The AVRCP profile is not connected. • The connection link between the unit and the device may be corrupted. • AVRCP is not supported	• Remove all Bluetooth devices connected to the Bluetooth-enabled device, and then re-pair the device by referring to “Pairing a Bluetooth-enabled device”. • Pair the Bluetooth device again with the unit by referring to “Pairing a Bluetooth-enabled device”. • Check the profiles supported by the Bluetooth-enabled device.



Bluetooth

Symptoms	Major causes	Remedies
No sound is heard from the Bluetooth audio.	• The volume on the Bluetooth-enabled device is too low. • Output destination of the Bluetooth device is not set to "CAR RADIO".	• The volume of the Bluetooth audio playback is dependent on the volume level set on the Bluetooth device. Set the volume on the Bluetooth device to a proper level. • Check to see that the output destination of the music from the Bluetooth device is set to "CAR RADIO".
Phone function is not available.	• The unit does not support phone calls. Some mobile phone models may connect to the unit via the "phone call" profile.	• Change the microphone setting from the unit to the mobile phone microphone by referring to the instruction manual of the mobile phone being used.
The Bluetooth audio is interrupted after receiving an incoming call.	• Some mobile phones cannot resume the Bluetooth audio after a phone call interruption.	• After the phone call, re-pair the mobile phone with the unit by referring to "Pairing a Bluetooth-enabled device".

Regional limitation

To use a Bluetooth-equipped radio, "radio wave authentication" must be obtained in the country where the radio is to be used.


It can be used in the countries listed below, as of August 2017. To use it in other countries, please contact your service or sales dealer for assistance.

Countries where a Bluetooth-equipped radio can be used

Ireland, Italy, UK, Estonia, Austria, Holland, Cyprus, Greece, Croatia, Sweden, Spain, Slovakia, Slovenia, Czech, Denmark, Germany, Hungary, Finland, France, Bulgaria, Belgium, Poland, Portugal, Malta, Latvia, Lithuania, Rumania, Luxemburg, Iceland, Norway, Liechtenstein, Switzerland, Turkey, USA, Canada, Japan



AUXILIARY HYDRAULIC LINES



AM1C026



WARNING

Oil may spurt out if pipes disconnected before releasing the pressure in the hydraulic system.

- Immediately after the engine is stopped and while the safety lock lever is still in the unlock position, turn the starter switch to ON and press each auxiliary hydraulic switch several times to release the pressure from the auxiliary hydraulic circuit.
- Press the air breather button to relieve the tank pressure.
- When disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.

These lines deliver the hydraulic oil necessary for operating a hydraulic breaker, crusher or other attachments.

- (1).....First auxiliary hydraulic lines
- (2).....Second auxiliary hydraulic lines
- (3).....Third auxiliary hydraulic lines
- (4).....Fourth auxiliary hydraulic lines

Stop valve

(S) : Close

(O) : Open



Connecting the hydraulic circuits

To connect the attachment hydraulic lines, observe the following procedures:


1. Release the pressure remaining in the lines, and then close the stop valve.
Refer to “Releasing the residual pressure” on page 2-78.
2. Remove the plugs.
3. Connect the attachment hydraulic lines to ports (a/c) and (b/d). When installing a hydraulic breaker, connect the supply circuit to the port (a) and the return circuit to port (b).
4. Open the stop valves. When installing a hydraulic breaker, open the selector valve (1).
Refer to “Selector valve” on page 2-79.
5. When connecting is complete, purge air from the hydraulic lines.
 - a. Start the engine and run it at a low idle speed with no load for 10 minutes.
 - b. With the engine running in low idle, operate the auxiliary hydraulic switches repeatedly (approx. 10 times) to purge air from the hydraulic lines.
 - c. Stop the engine and wait for at least 5 minutes until bubbles escape from the hydraulic oil in the tank.

IMPORTANT: Follow the procedures for purging air as instructed by the attachment manufacturer, if applicable.

6. Check for oil leaks.

Disconnecting the hydraulic circuits

1. Release the pressure remaining in the lines, and then close the stop valve.
Refer to “Releasing the residual pressure” on page 2-78.
2. Disconnect the lines from the ports (a/c) and (b/d).
3. Install the plugs.



Operating

Press those buttons to control the flow of the oil in the first/second auxiliary hydraulic lines.

- (A).....Hydraulic oil flows to left auxiliary line (a).
- (B)Hydraulic oil flows to right auxiliary line (b).
- (C)Hydraulic oil flows to left auxiliary line (c).
- (D)Hydraulic oil flows to right auxiliary line (d).

Releasing the residual pressure


After the auxiliary hydraulic circuits have been used, pressure remains in the circuits. This is called the residual pressure. Release this residual pressure before disconnecting the lines.

Perform the residual pressure releasing within 10 minutes after the engine stopping.

1. Park the machine on a flat, rigid and safe ground.
2. Stop the engine.
3. Lower the safety lock lever to the unlocked position.
4. Turn the starter switch to the ON position.
5. Press the auxiliary hydraulic switches several times to release the residual pressure in the auxiliary hydraulic circuitry.



Selector valve



Open..... When using a hydraulic breaker
(1-way flow)


Close..... When using a reversible
attachment (2-way flow)

Change the direction of the hydraulic oil flow
by opening or closing the selector valve (1)
inside the fuel lid.

For the machine with the auxiliary 1st auto
tank switch, use the switch to select the
flow.

Refer to “Auxiliary 1st auto tank switch (If
equipped)” on page 2-47.

Third auxiliary hydraulic switch and button




The third auxiliary hydraulic lines are normally
used to control the “quick attachment”
installed to connect/disconnect the bucket.
When the engine is started, hydraulic oil
flows into the pipe (e). This allows the
pressure in the (e) side to increase and to
prevent the pin inserted on the bucket from
coming out. If the pressure in the (e) side
drops, the alert that the bucket may come
out is indicated by the warning lamp and the
alarm. For a safety reason, the bucket can
be disconnected only when the button (1)
and the switch (2) are pressed at the same
time. When they are pressed, the hydraulic
oil flows into the line (f) to increase the
pressure there. As the result, the pin on the
bucket comes out and the bucket is
removed from the machine.

- Bleeder unit for simultaneous use with the
auxiliary 1st and 2nd (if equipped)
Pressing both the auxiliary 3rd button (1)
and the switch (2) makes it possible to
release internal pressure from the auxiliary
3rd (e side), auxiliary 1st and auxiliary 2nd
at the same time. (The pressure is kept
drawn for six seconds after the button and
the switch are released.) This enables
faster attachment change.



Third auxiliary hard-lock switch (if equipped)

IMPORTANT: For handling of the attachment, follow the instructions provided in the attachment manual.




The third auxiliary hard-lock switch should be installed in the third auxiliary if the attachment to be installed on the piping of the third auxiliary is capable of hard locking. When operating the third auxiliary, this switch is used.

The third auxiliary is mainly used to control the “quick attachment” that connects/ disconnects the bucket.

After the engine is started, hydraulic oil flows into the pipe (e) if the switch is off. This allows the pressure in the (e) side to increase, preventing the pin inserted into the bucket from coming off.

When the switch is turned on by pressing the switch (1) while pulling the orange portion (2), the warning lamp starts flashing. The hydraulic oil flows into the line (f) to increase the pressure there. As a result, the pin on the bucket comes off and the bucket is removed from the machine.

Third auxiliary hydraulic warning lamp




This lamp illuminates and an alarm sounds when the third auxiliary hydraulic pressure drops abnormally, when the safety lock lever is fully lowered to the unlocked position while the engine is running.

For the machine with the hard lock feature, the lamp lights up and an alarm is sounded only when the third auxiliary hard-lock switch is turned on.



Auxiliary 2/4 select button



This button is used to change from the second auxiliary operation to the fourth auxiliary operation.

Pressing this button displays the second auxiliary on the LCD to indicate that the second auxiliary operation is enabled.

Pressing this button again displays the auxiliary 4th on the LCD to indicate that the auxiliary 4th operation is enabled.

The actual operation is performed with the auxiliary 2nd/4th switch (slider switch).

Refer to “Auxiliary 2nd/4th switch (If equipped)” on page 2-41.

Setting the flow rate

The flow rate in the auxiliary 1st, 2nd and 4th can be set to the desired values.

For details, refer to “Auxiliary 1st flow rate setting” on page 2-26 and “Auxiliary 2nd/4th flow rate setting” on page 2-27.

IMPORTANT: The set values are not the guaranteed values. They should be used as rough guides.



OPERATING THE MACHINE WITH AN ACCUMULATOR

WARNING

Be sure to handle the high-pressure nitrogen gas enclosed in the accumulator with care. If handled incorrectly, it could explode and cause serious injury. Strictly observe the following precautions:

- Do not disassemble.
- Do not allow flame near or throw it into a fire.
- Do not drill, weld or fuse.
- Do not subject it to physical shock such as hitting, rolling or dropping.
- Before disposing of the unit, the sealed gas must be drained. Contact a Takeuchi service agent for help.


For a machine with an accumulator, the residual pressure in the auxiliary hydraulic circuit or the working equipment circuit can be released even after the engine is stopped.

Releasing residual pressure

Residual pressure refers to the pressure that remains in the hydraulic circuit after the operation. Release the residual pressure as necessary by using the following steps.

Perform the residual pressure releasing within 10 minutes after the engine stopping.

1. Return the throttle controller to idle the engine at low speed.
2. Lower the bucket and dozer blade to the ground.
3. Check that the safety lock lever is in the released position.
4. Stop the engine.
5. Turn the starter switch to the ON position.



6. Move or press the auxiliary hydraulic switches several times to release the residual pressure in the circuitry.
7. Move all the control levers and pedals several times in all directions to release the pressure from the working equipment circuitry.
8. Raise the safety lock lever to engage the lock.

Lowering the boom when the engine has stopped

Perform this operation within 10 minutes after the engine stopping.

1. Sit at the operator's seat.
2. Turn the starter switch to the ON position.
3. Lower the safety lock lever to the unlock position
4. Slowly push the operating lever forward to lower the boom.



LOAD SAFETY DEVICE (IF EQUIPPED)

The load safety devices include an emergency shut-off valve and an overload warning device.

Emergency shut-off valve




WARNING


- If the boom or arm stops due to the breakage of hose, immediately move away from the load being lifted and go to a safe location.
- Since the emergency shut-off valve (1) and (2) is a safety device, you must not disassemble it and/or replace or adjust its internal part. Takeuchi shall not be held responsible for any injuries, accidents or product malfunction caused by disassembly.

The emergency shut-off valve (1) or (2) prevents the boom or arm from falling rapidly in case the hydraulic hose is broken.


Boom




2-Piece boom



Second boom



Arm (option)



If the hose breaks and the emergency shut-off valve (1) or (2) is activated to stop the operation of boom or arm, lower the boom or arm by slowly operating the lever while ensuring safety. Ask your sales or service dealer for repair.




Overload warning device



WARNING

If the overload is not removed after the overload warning horn is sounded, the machine may tip over. If the horn starts sounding, stop operating the machine and lighten the load.

If a weight greater than the lifting capacity is applied or lifted, the overload warning device is activated and the horn sounds. (When the lift overload warning switch is turned on.)



Lift overload warning switch

OFFOff

ONOn



FUEL SUPPLY PUMP (IF EQUIPPED)



DANGER


Do not use the fuel supply pump for gasoline or hydraulic oil. Doing so could result in explosion or damage. Only use the fuel supply pump for diesel fuel.



CAUTION

Do not fill the tank with additional fuel after the fuel supply pump stops. Doing so could cause the fuel to spurt out.

This device automatically supplies fuel to the fuel tank and stops automatically when the fuel tank is full.



1. Open the side cover.
2. Insert the pump's nozzle (1) in the fuel supply tank.
3. Press the switch (2).
The pump stops automatically once the fuel tank is full.
4. Turn off the switch.
5. Store the nozzle.

ENGINE AUTO STOP

<Applicable machine models 185104996 or later>



WARNING

Do not leave the machine when the attachment is raised.

The term “engine auto stop” refers to a function that automatically stops the engine. When the engine auto stop function is on, the machine engine automatically stops to reduce fuel consumption, under the conditions listed below.

When the following conditions are met, the buzzer sounds and the engine stops in three minutes.

1. Safety lock lever is raised
2. Vehicle error code is not generated.
3. Engine error code is not generated.

For details about turning on or off this function, ask your sales or service dealer for help.

IMPORTANT: If the certain conditions are met when the engine auto stop is on, the buzzer sounds once every minute. The buzzer continues to sound once every minute even after the engine stops. Leaving the starter switch at the ON position will deplete the battery. Be sure to turn the switch to the OFF position after the engine is stopped.

Note: The engine auto stop does not function during the DPF auto regeneration.





MIRRORS


WARNING

**Adjust the mirrors before operating the machine.
If the visibility is poor, death or serious injury could result.**


The mirror can be adjusted by moving it by hand. If it is too hard to move by hand or too loose, use a tool to adjust it. Set the machine to the travel posture, and then adjust the mirrors by following the instructions in this manual.



- Adjust the mirrors (1) and (3) so that you can see the view behind the machine.



AM3C001



AM3C002

- Adjust the mirror (2) so that you can see the portions obstructed by the arm and boom: forward right portion on the circumference of the 12-meter radius circle centered at the operator and the forward right portion 1 meter (3.3 ft.) away from the machine.
- Adjust the mirror (4) so that you can see the view of the portion obstructed by the cabin: rear left portion 1 meter (3.3 ft.) away from the machine.
- Adjust the mirror (5) so that you can see the view of the portions obstructed by the machine: rear right portion on the circumference of the 12-meter radius circle centered at the operator and the rear side portion 1 meter (3.3 ft.) away from the machine.




CAMERA



WARNING

Adjust the cameras before operating the machine.


If the visibility is poor, death or serious injury could result.




The images being taken by the camera (1) can be shown on the multi information display. While operating the machine, use the camera (1) to check the blind spots from the operator's seat.

Refer to "Camera image key" on pages 2-24. If the images are not correctly displayed, adjust the camera installation angle.


Adjusting the installation angle



1. Loosen the right and left bolts (2) securing the camera (1).



2. Adjust the angle while checking the screen so that the portion (3) of the machine can be displayed.
3. Tighten the right and left bolts (2) evenly.
 - Tightening torque: 0.5 N·m (0.4 ft·lb.)



4. Check if the images are shown on the multi-information display.
 - A: The blind spot area, 1 meter (3.3 ft.) away from the machine.
 - B: The blind spot area, on the circumference of the 12-meter (39.4 ft.) radius circle centered at the operatorIf the blind spot area A or B is not shown after adjustment, contact your service or sales dealer for assistance.



AUTO CAMERA MODE

When the machine is driven in reverse, the display is automatically switched to the image taken by the rear view camera. When the machine stops driving in reverse, the display returns to the Home screen.

This function can be manually turned on or off. For setting the auto camera mode, refer to “ON/OFF setting” on page 2-35.

OPERATION






BEFORE STARTING OPERATION

GETTING ON OR OFF THE MACHINE



WARNING

- Do not jump on or down from the machine. Never attempt to get on or off the moving machine.
- When getting on or off the cab, first fully open the door to the locked position and check that it does not move.



- Climb up/down the steps holding the handrail to support your weight in a three point secure stance (hand and feet).
- Never use the safety lock lever or control levers as hand holds.

WALK-AROUND INSPECTION

Perform the walk-around inspections once a day before starting the engine for the first time that day.

Refer to "MAINTENANCE, Walk-around inspection", on pages 5-18 and 5-19.

DAILY INSPECTION


Perform the daily inspections once a day before starting the engine for the first time. Refer to "MAINTENANCE, Daily inspection", on pages 5-20 to 5-25.




STARTING AND STOPPING THE ENGINE

BEFORE STARTING THE ENGINE


1. Adjust the seat for a comfortable operating position.
2. Fasten the seat belt.




3. Check that the safety lock lever is in the locked position.



4. Check that all levers and pedals are in the neutral position.



5. Insert the key into the starter switch, turn it to the ON position, then perform the following inspections:



- All warning lamps flash and an alarm is sounded for two seconds. The meters also start functioning. After two seconds, the deceleration lamp (3) stops flashing and remains lit, while the battery charge warning lamp (1) and engine oil pressure warning lamp (2) remain flashing. (If the auxiliary 3rd is selected, it is also flashing.) The other lamps go out.
- Turn on the light switch to check that the boom light, front light, side lights and tail lamps turn on.
- Check the fuel level.

If a lamp does not light or the alarm is not sounded, the display or a wire may be damaged. Ask your sales or service dealer for repair.



STARTING THE ENGINE




WARNING

- Clear all personnel from the work area.
- Sound the horn to warn people around the machine.

IMPORTANT: Do not run the starter motor for more than 15 consecutive seconds. If the engine fails to start, wait for 30 seconds, and then try again to start the engine.

IMPORTANT: If the engine stalls due to fuel shortage, add fuel, turn the key to the ON position for 60 seconds, and then turn it to the START position. Running the starter for a long time before there is enough fuel is going through can cause the starter to fail.

Normal starting



1. Turn the starter key to the START position and start the engine.

When the machine is equipped with the safety start function: The engine does not start unless the safety lock lever is in the locked position at this point.

Refer to “Safety lock lever” on page 2-48.

2. Once the engine starts, release the key. The key automatically returns to the ON position.
3. Check that the warning lamps are off. For safety reasons, it is designed that the deceleration function is activated to set the engine revolutions to low idling whenever the engine is started.

Cancel the deceleration mode by pressing the deceleration button as necessary.

4. Warm up the engine.

Refer to “Warming up the engine” on page 3-6.


5. After the completion of the warming up, press the deceleration button to cancel the deceleration mode.

Starting in cold climates




WARNING

Never use starting fluid on this engine, as the starting fluid could cause an explosion.



1. Turn the throttle controller to the middle position.



2. Turn the starter key to the ON position, and confirm that the glow lamp is lit. (The glow lamp stays lit when the coolant temperature is -10°C (14°F) for 15 seconds (Applicable machine models 185100001 or later) or 12 seconds (Applicable machine models 190200001 or later).)



3. After the glow lamp goes out, press the deceleration button (to cancel the deceleration mode), and then turn the key to the START position to start the engine.

When the machine is equipped with the

safety start function: The engine does not start unless the safety lock lever is in the locked position at this point.

Refer to "Safety lock lever" on page 2-48.

4. Once the engine starts, release the key.
The key automatically returns to the ON position.
5. Check that the warning lamps are off.
6. Return the throttle controller to the original position and warm up the engine.
Refer to "Warming up the engine".

Note: If the engine is started at -15°C (5°F), the revolution speed is controlled to 1500 min^{-1} (rpm). After 10 seconds, the throttle controller operation becomes available.

<Applicable machine models 185100001 or later>


Note: The glow lamp turns on if the coolant temperature is low after the engine is started.



WARMING UP THE ENGINE

IMPORTANT: Avoid racing the engine until it has warmed up.


Do not warm up the engine for a long time (20 minutes or more). When idling is required, occasionally place a load or run the engine at medium speed.




1. Return the throttle controller, and then run at a low idle with no load for 5 minutes.

STOPPING THE ENGINE

IMPORTANT: Do not stop the engine suddenly when operating with heavy loads or at the maximum speed. Doing so may cause the engine to overheat or seize. Never stop running the engine suddenly except in emergency.



1. Return the throttle controller.
2. Idle the engine for about 5 minutes to gradually let it cool.



3. Turn the starter key to the OFF position to stop the engine.




OPERATING THE MACHINE

LEVER PATTERN (ISO PATTERN)

WARNING

- Before starting operation, carefully check which lever pattern you are going to use.
- It is described using the ISO pattern in this manual.




	Left crawler forward		Right crawler forward
	Left crawler reverse		Right crawler reverse
	Arm out		Boom lower
	Arm in		Boom raise
	Upperstructure slew left		Bucket load
	Upperstructure slew right		Bucket dump
	Boom swing left Second boom raise (2-piece boom)		Dozer blade lower
	Boom swing right Second boom lower (2-piece boom)		Dozer blade raise



LEVER PATTERN (G PATTERN) (IF EQUIPPED)

WARNING

- Before starting operation, carefully check which lever pattern you are going to use.
- It is described using the ISO pattern in this manual.



	Left crawler forward		Right crawler forward
	Left crawler reverse		Right crawler reverse
	Boom lower		Arm out
	Boom raise		Arm in
	Upperstructure slew left		Bucket load
	Upperstructure slew right		Bucket dump
	Boom swing left Second boom raise (2-piece boom)		Dozer blade lower
	Boom swing right Second boom lower (2-piece boom)		Dozer blade raise

Refer to "Selecting a lever pattern" on page 8-5.




WARMING UP THE MACHINE (HYDRAULIC OIL)

WARNING


Operating the working equipment without warming up the machine (hydraulic oil) is dangerous, as the working equipment cannot respond to controls quickly or may move in unexpected ways, and the safety devices may not operate properly. Be sure to sufficiently warm up the machine.

IMPORTANT: Do not operate the levers too quickly when the hydraulic oil temperature is below 20°C (68°F). The proper hydraulic oil temperature during operation is 50 to 80°C (122 to 176°F). If operations must be performed at lower temperatures, heat up the hydraulic oil to at least 20°C (68°F).


Normal warm-up




1. Turn the throttle controller to the middle position, and then run the engine at medium speed for about five minutes with no load.




2. Fully lower the safety lock lever to disengage the lock and lift the bucket from the ground.



3. Extend and retract each of the cylinders slowly several times with no load.




4. Slew slowly to the left and the right several times.



5. Travel slowly forward and in reverse several times.

Warm-up in cold climates


1. Perform the normal warm-up procedure.




2. Set the bucket cylinder at the stroke end and keep it there.
Do not keep this condition for more than 30 seconds.
3. Repeat Step 2 until the bucket operating speed becomes normal.

INSPECTION AFTER WARM-UP

After warming up the engine and machine (hydraulic oil), perform the checks and inspections described below, and repair if necessary.



1. Check that the warning lamps and meters are as follows:
 - Are all warning lamps off?
 - Is the water temperature level within the green range?
2. Check that there are no irregularities in the exhaust color, sound and vibrations.




3. Raise the safety lock lever to the locked position, and then check that the operating and travel levers are locked.



OPERATING THE TRAVEL LEVERS/ PEDALS


WARNING

- Never allow anyone to enter the machine's slewing radius and path.
- Signal your intention to move by sounding the horn.
- There is a blind spot in the rear of the machine. Before traveling in reverse, as necessary, swing the cab around in reverse to check that the area is safe and clear.




- Before operating the travel levers/pedals, make sure that the dozer blade is to the front of the operator's seat. Remember that when the dozer blade is to the rear of the operator's seat, the travel levers/pedals must be operated in the reverse direction from when it is to the front.
- Clear all obstacles from the path of the machine.


Moving the machine forward and backward




1. Turn the throttle controller and increase the engine speed.



2. Fully lower the safety lock lever to disengage the lock.




3. Fold the hoe attachment and lower it 30 to 40 cm (12 to 16 in.) above the ground.
4. Lift the dozer blade.
5. Operate the left and right travel levers as below.



When the dozer blade is in front of the operator's seat:

- ➔ To move forward:
Tilt the levers forward.
- ⇨ To move backward:
Tilt the levers backward.




When the dozer blade is behind the operator's seat:

- ➔ To move forward:
Tilt the levers backward.
- ⇨ To move backward:
Tilt the levers forward.

Traveling in 2nd (High) speed

WARNING


When a load greater than a set value is applied during traveling in 2nd (high) speed, the speed will automatically slow down to 1st (low) speed. When the load becomes lighter, the speed will increase and return to 2nd (high) speed. It should be noted that the travel speed changes depending on the load condition (for machines with the automatic travel shift-down system).



Press the travel speed switch to set to the 2nd (high) speed, and press it again to return to the 1st (low) speed.



Pivot turn




AG7D027

Turning to the left when stopped:

- ➔ To turn forward to the left:
Tilt the right lever forward.
- ⇨ To turn backward to the left:
Tilt the right lever backward.

To turn to the right, operate the left lever in the same way as for the right lever.




AG7D028

Turning to the left while traveling:

- ➔ To turn left while traveling forward:
Set the left lever to neutral.
- ⇨ To turn left while traveling backward:
Set the left lever to neutral.

To turn to the right while traveling, operate the right lever in the same way as for the left lever.

Spin turn



AG7D029

- ➔ To spin left:
Tilt the left lever backward and the right lever forward.
- ⇨ To spin right:
Tilt the right lever backward and the left lever forward.



STOPPING TRAVEL




WARNING

- Park the machine on a flat, rigid and safe ground. Set the parking brake. If you must park on a slope, chock the tracks to block the machine.
- If any control is accidentally touched when the safety lock lever is not locked, the machine may suddenly move and cause serious injury or death.



CAUTION

Never stop running the machine suddenly except in emergency. Stop in good time, if possible.



AG7D030


1. Set the left and right travel levers slowly to the neutral position. The machine stops.



OPERATING THE WORKING EQUIPMENT

WARNING

- Before starting operation, carefully check which lever pattern you are going to use.
- It is described using the ISO pattern in this manual.



Use the right operating lever to operate the boom and bucket.

Use the left operating lever to operate the arm and slewing.


Return the operating levers to the neutral position to stop the hoe attachments.

1. Lower the safety lock lever to the unlocked position.
2. Set the pedal cover to the unlocked position.

Slewing


WARNING

Check the surrounding area for safety before slewing.



- ➔ Upperstructure slew left:
Tilt the left operating lever to the left.
- ➔ Upperstructure slew right:
Tilt the left operating lever to the right.

Operating the boom




- ➔ Boom lower:
Tilt the right operating lever forward.
- ➔ Boom raise:
Tilt the right operating lever backward.



OPERATION OPERATING THE MACHINE


Operating the arm



AG7D034

- ➔ Arm in:
Tilt the left operating lever backward.
- ⇒ Arm out:
Tilt the left operating lever forward.


Operating the bucket



AG7D035

- ➔ Bucket load:
Tilt the right operating lever to the left.
- ⇒ Bucket dump:
Tilt the right operating lever to the right.


Operating the boom swing



AM1D012

- ➔ Boom swing left:
Step on the left side of the pedal.
- ⇒ Boom swing right:
Step on the right side of the pedal.


Operating the second boom



AM1D0131

- ➔ Second boom raise:
Step on the left side of the pedal.
- ⇒ Second boom lower:
Step on the right side of the pedal.

Operating the dozer blade



AG7D037

- ➔ Dozer blade lower:
Tilt the lever forward.
- ⇒ Dozer blade raise:
Tilt the lever backward.




OPERATING PROCEDURES

PROHIBITED OPERATIONS

WARNING


- Do not operate on bedrock (hard or soft).
- Do not slew/swing while traveling. If you must operate the hoe attachment while traveling, operate at speeds slow enough so you have complete control at all times.

Do not perform demolition or leveling using slew force




Do not demolish walls or level ground using slew force. Also, do not dig the bucket teeth into the ground during slewing. Doing so will damage the hoe attachment.

Do not dig while traveling




Do not dig the bucket into the ground and use the traveling force to dig.

Be gentle when using the hydraulic cylinder



Do not extend the hydraulic cylinders to the stroke ends. Operate them with leeway.



Do not support the machine body with the hoe attachment when the body is lowering with the arm cylinder fully extended. Doing so concentrates the load on the arm cylinder and could damage the arm cylinder.




OPERATION OPERATING PROCEDURES

Do not drive piles with the bucket or dig by banging the bucket




Doing so will shorten the service life of the hoe attachment. Use the hydraulic force to dig.

Do not perform operations using the machine's dropping force




Putting excessive strain on the machine will shorten its service life. When digging, use the hydraulic force of the cylinders and the shallow and long strokes.

Digging bedrock



For hard base rock, break the rock up into small pieces with a breaker, etc., before digging. This prevents damage to the machine and is thus more economical in the end.

Caution on exposing the dozer blade to shocks



Hitting the dozer blade against rocks, etc., could damage the dozer blade or the blade cylinder.




Caution on folding the hoe attachment




Be careful not to let the bucket hit the dozer blade when the hoe attachment is being folded.

Do not use the dozer blade as an outrigger




Pay attention to the dozer blade when digging



When digging deeply with the dozer blade positioned at the front, be careful that the boom cylinder and bucket do not hit the dozer blade.

Operate with the dozer blade at the rear whenever possible.

Caution on digging down with the dozer blade




This dozer blade is designed for simple earth pushing. Do not dig down deeply with the dozer blade. Doing so could damage the dozer blade and undercarriage.




CAUTIONS ON OPERATING

Cautions on traveling



Traveling over obstacles (rocks, stumps, etc.) may put a great load on the machine body and may cause damage to it. Avoid crossing over obstacles whenever possible. If you must do so, keep the hoe attachment near the ground, travel at a low speed, and go over the obstacle at the center of the crawler.


Cautions on traveling in 2nd (High) speed




- On uneven ground, maintain the low speed and avoid starting, stopping or changing directions abruptly.
- When a load greater than a set value is applied during traveling in 2nd (high) speed, the speed will automatically slow down to 1st (low) speed. When the load becomes lighter, the speed will increase and return to 2nd (high) speed. It should be noted that the travel speed changes depending on the load condition (for machines with the automatic travel shift-down system).

- When traveling in 2nd speed, do so with the dozer blade at the front.

Cautions on using machine in water



If the rear of the machine is submerged in water as shown in the figure above, it causes the radiator fan to turn in water, resulting in damage to the fan. The rear of the machine must not be submerged.




- Allowable water depth
Use the machine in water only when the water is up to the bottom of the carrier roller (1).
- For those parts used in water for a long time, apply enough grease until the old grease is expelled.
- Never submerge the slew bearing or main body in water or sand. If submerged, contact a Takeuchi service agent for inspection.



CAUTIONS ON TRAVELING ON SLOPES

WARNING


- Never travel on slopes that are too steep for the machine to maintain its stability. (maximum gradeability: 35°, lateral tipping angle: 15°) Note that in reality, the machine's stability becomes lower than the above values depending on the working condition.
- When traveling on slopes, lower the bucket to a height of 20 to 30 cm (8 to 12 in.) above the ground. When climbing a steep slope, extend the hoe attachment to the front. In emergencies, lower the bucket to the ground and stop the machine.
- When traveling on slopes or grades, drive slowly in 1st (low) speed.
- When climbing a hill, keep the operator's seat facing the hillside. When descending a hill, keep the operator's seat facing the downhill direction. In either case, travel must be done while paying attention to the ground in front of the machine.
- Do not descend slopes in reverse.



- Do not change directions on slopes or traverse slopes. First return to a flat surface, and then take an alternative path.


- The machine may slip sideways even on a slight slope if they are covered with grass or dead leaves, or when traveling on a wet metal plate or frozen surfaces. Do not allow the machine to position sideways to slopes.

Traveling posture on slopes Climbing slopes



When climbing slopes of 15° or more, maintain the machine posture as shown in the figure above.


Descending slopes



When descending slopes of 15° or more, slow down the engine speed and maintain the machine posture as shown in the figure above.




Braking when descending slopes




When descending slopes, the brakes are applied automatically once the travel levers are returned to the neutral position.

If the crawler slips



If the crawler slips while climbing a slope and impossible to travel, use the pulling force of the arm to climb the slope.

If the engine stops



If the engine stops when descending a slope, set the travel levers to the neutral position, stop the machine, then start the engine.

Do not open the door while traveling on slopes




Opening the door while traveling on slopes is dangerous, as the force required to open and close the door changes abruptly. Always keep the door closed when traveling on slopes.



GETTING OUT OF MUD


If the machine gets stuck in mud, use the procedure below to get it out.

If one crawler is stuck



1. Swing the bucket to the side of the crawler being stuck.
2. Set the arm and boom to an angle of 90 to 110°.
3. Press the bottom of the bucket (not the teeth) against the ground.
4. Place a plank or the like under the lifted crawler.
5. Lift the bucket and slowly move the machine out of the mud.


If both crawlers are stuck



1. Perform the steps 1 to 4 above for both crawlers.
2. Dig the bucket into the ground in front of the machine.
3. Pull with the arm while traveling forward to slowly move the machine out.


OPERATIONS POSSIBLE WITH THIS MACHINE

Excavating



1. Set the dozer blade on the side opposite to the side you want to dig on.
2. Use the arm and bucket and dig with shallow, long strokes. The maximum digging force can be obtained when the boom and arm angle is 80 to 120°. Use this angle for effective digging.


Digging ditches



Install a bucket suited for digging ditches and set the crawlers parallel to the ditch to be dug for greater efficiency. When digging wide ditches, dig the sides first, and then dig the center.




Digging side drains



AM1D014

Use the boom swing function to dig side ditches as shown in the figure.

Loading




AG7A040

When loading dirt onto a truck bed, load from the back of the truck, as it is easier and able to load more load than doing it from the front.

Also, use a small slewing angle for greater efficiency.

Leveling



AG7E025

1. Bring the hoe attachment close to the body.
2. Gradually remove the dirt from the side of the mound.
3. Once the mound is low, remove the dirt from the top. If the load becomes too heavy for the machine body, adjust by raising or lowering the dozer blade.




PARKING THE MACHINE

PARKING




WARNING



AG7A058

- **Park the machine on a flat, rigid and safe ground. Set the parking brake.**



AG7A059PE

If you must park on a slope or incline, park the machine securely and block the movement of the machine.

- When parking on a street, use barriers, caution signs, lights, etc., so that the machine can easily be seen even at night to avoid collision with other vehicles.
- Before leaving the operator's seat, raise the safety lock lever to engage the lock and stop the engine. Also, be sure to remove the key, lock the door and covers, take it with you and store it in a specified place.

3. Lower the bucket and the dozer blade to the ground.
4. Raise the safety lock lever to the locked position.
5. Stop the engine and remove the key. Refer to "Stopping the engine" on page 3-6.


For machines equipped with accumulator:
Refer to "Operating the machine with an accumulator" on page 2-82.

INSPECTION AND CHECKS AFTER STOPPING THE ENGINE

1. Check for oil or water leak and inspect the working equipment, covers and undercarriage. If any irregularities are found, repair.
2. Fill up the fuel tank.
Refer to "Inspecting the fuel level" on page 5-23.
3. Remove any paper scraps or dirt from the engine room.
4. Remove any mud from the undercarriage.

Locking

Be sure to lock the following places:



AG7A009

- Cab door
- Engine hood
- Covers

1. Set the left and right travel levers to the neutral position.
2. Return the throttle controller to set the engine to low idling.



HANDLING IN COLD CLIMATES

PREPARING FOR COLD CLIMATES

Starting engine in cold climates is not easy, and it becomes more difficult if the coolant freezes. Prepare for cold-climate problems as follows.

Replacing the fuel and lubricant

Replace the hydraulic oil, engine oil and fuel with those intended for cold climates. Refer to “Fuel and lubricant table” on page 5-4.

Engine coolant



WARNING

The engine coolant is combustible. Keep away from flame.

Use long-life coolant (antifreeze) and tap water for the engine coolant.

Note: New machines are delivered with JIS Type 2 long-life coolant (antifreeze) at a concentration of 50%.

Refer to “Fuel and lubricant table” on page 5-4.

Battery

As the temperature drops, the battery performance decreases.

Inspect the battery. If it is discharging, contact a Takeuchi service agent to have the battery recharged.

Refer to “Inspecting the battery fluid level and replenishing” on page 5-32.

CAUTIONS AFTER OPERATIONS

Observe the following cautions to prevent mud, water, or the undercarriage from freezing and making it impossible for the machine to move.

- Remove all mud and water from the machine body. In particular, wipe the hydraulic cylinder rod clean to prevent damage to the seal caused by mud or dirt on the rod surface getting inside the seal together with drops of water.
- Park the machine on hard and dry ground. If this is impossible, park the machine on a wooden board placed on ground.
- Drain any water in the fuel tank to prevent it from freezing.

Refer to “Draining the water from the fuel tank” on page 5-31.

- As the battery capacity drops markedly in low temperatures, cover the battery or remove it from the machine and keep it in a warm place.

If the electrolyte level is low, add distilled water in the morning before beginning work. To prevent the battery electrolyte from freezing in the night, do not add water after the day's work.

AFTER THE COLD CLIMATE

When the climate becomes warmer, do as follows:

- Replace the fuel and oil for all parts with those specified in the “Fuel and lubricant table”.
Refer to “Fuel and lubricant table” on page 5-4.
- If a coolant of “one season type” is used, drain the cooling system completely, clean out the inside of the cooling system thoroughly, and fill with tap water.
Refer to “Cleaning the engine cooling system” on page 5-50 or page 5-55.



HANDLING RUBBER CRAWLERS

Rubber crawlers have an inherent weakness, lack of strength, due to their use of rubber. Be sure to observe the prohibitions and cautions below to prevent the crawlers from being damaged or coming off.


PROHIBITIONS

Do not travel or operate the machine in the following places:




AG7E031

- Traveling and slewing on crushed rock, extremely rough hard rock, steel beams, scrap iron, or near the edges of steel plates will cause damage to the rubber crawlers.



AG7E032

- Traveling on riverbeds or places where there are large numbers of boulders may cause the stones to get caught and damage the crawler or make the crawler come off.
- Do not use the machine on the seashore. The salt may corrode the steel core.



AG7E033

- Do not let fuel, oil, salt or chemical solvents get on the crawlers. These substances may corrode the bonding of the steel cores on the crawlers, resulting in rust or peeling. If any of these substances gets on the crawler, immediately clean it off with water.




AG7E034

- It will cause an irregular wear or damage to the lugs, if the machine travels on irregular surfaces such as recently paved with asphalt, exposed to a bonfire or of hot iron sheets under the blazing sun.
- Do not move earth in places where the rubber crawlers may slip. Doing so may speed up lug wear.




CAUTIONS

Observe the following cautions when operating the machine:



AG7E035

- Do not turn the undercarriage with the front of the machine body lifted using the hoe attachment (the upperstructure is not turned). Doing so will twist the crawlers with the load concentrated on a single point on the crawler belt, causing rapid damage to the crawlers.
- Avoid changing course abruptly or spin-turning on concrete surfaces whenever possible. Doing so may wear or damage the rubber crawlers.
- Avoid drops that may expose the rubber crawlers to strong shocks.
- Salt, potassium chloride, ammonium sulfate, potassium sulfate, and triple superphosphate of lime can damage the crawler belts. If any of these substances gets on the crawler belts, wash it off thoroughly with water.
- Do not let the sides of the rubber crawlers rub against concrete or walls.
- Do not damage the rubber crawlers by hitting the bucket against them.
- Be especially careful on snowy or frozen surfaces in winter, as the crawler belts tend to slip in such conditions.
- Use rubber crawler belts at temperatures between -25°C to $+55^{\circ}\text{C}$ (-14°F to 131°F).
- When storing the rubber crawlers for long periods of time (three months or more), do so indoors in a place not exposed to direct sunlight or rain.



AG7E036

- Rubber crawler belts are not as stable as steel crawler belts since the entire lugs are made of rubber. Be very careful when slewing and swinging sideways.

PREVENTING THE RUBBER CRAWLERS FROM COMING OFF

Observe the following cautions to prevent the crawler from coming off:

- Always keep the crawlers at the proper tension.




AG7E0371

- When traveling over a large step such as a cobblestone or rock (20 cm (8 in.) or deeper), climb up the step at the right angle and do not change courses on top of the step.



OPERATION HANDLING RUBBER CRAWLERS



AG7E0381

- When climbing in reverse, do not change directions at the point where the slope starts.




AG7E041

- Do not change directions when the crawler belts are slack as shown in the figure.




AG7E039

- Avoid traveling by setting one crawler on a slope or projecting portion and the other crawler on a flat surface (with the machine at a tilt of 10° or more). Travel with both crawlers set on flat surfaces.




AG7E042

- The rubber crawler belts will come off if the machine travels backward in this condition.



AG7E040



AG7E043

- The rubber crawler belts will come off if the machine turns in this condition.



HANDLING THE ENGINE

PROHIBITIONS

Do not modify the exhaust gas control system. Any usages other than described in this manual are prohibited.

CAUTIONS

- To maintain the engine's exhaust performance, operate or use the machine and perform inspection and maintenance by following this manual.
Incorrectly operating or using the machine or performing inspection and maintenance could cause machine failure.
- If the exhaust gas control system is not properly functioning, the ECM error warning lamp turns on or flashes and an error code appears.
If an error code appears, immediately repair the fault detected, or consult your sales or service dealer for help. Refer to "Exhaust gas control system error" on page 6-32.
- If the ECM error warning is ignored, the operator inducement system activates. Since the system limits the engine output, there is a possibility that machine becomes unable to move.

DIESEL FUEL

The diesel fuel used must meet the requirements specified in the region where the machine is operated.

Refer to "Service data" on page 5-4.

TRANSPORT




LOADING AND UNLOADING

WARNING



The machine may roll or tip over or fall while being loaded or unloaded. Take the following precautions:

- Select a firm, level surface and keep sufficient distance from road shoulders.
- Secure the ramps of adequate strength and size to the truck bed. The slope of the ramps must not exceed 15°. If the ramps are bowed down too low, support them with poles or blocks.
- Never use the working equipment to load or unload the machine. Doing so may result in tipping over or falling down of the machine.
- Keep the truck bed and loading ramps clean of oil, soil, ice, snow, and other materials to prevent the machine from sliding sideways. Clean the crawlers.
- Chock the transporter wheels to prevent movement.
- Turn off the deceleration switch and auto-deceleration switch. Otherwise, the engine speed may suddenly increase to cause troubles.
- When being loaded or unloaded, travel slowly in 1st (low) gear by following the signal from the signal person.
- Never change courses on the ramps.
- Do not slew/swing on the ramps. The machine may tip over.
- When slewing/swinging on the truck bed, do it slowly as the footing should be unstable.
- Lock the cab door after being loaded, if applicable. Otherwise, the door may open during transport.
- Chock the tracks and secure the machine to the truck bed with wire rope or chain.

When loading or unloading the machine, be sure to use ramps or a platform and follow the procedure below.



1. Set the parking brake on the transporter and chock the wheels.
2. Fix the ramps securely to the truck bed. The slope of the ramps must not exceed 15°.
3. Align the center of the truck bed with the center of the machine, and of the ramp with the center of the crawler.
4. Make sure the dozer blade does not hit the ramps.
5. Lower the hoe attachment as far as possible without letting it touch the transporter.
6. Decrease the engine speed.





7. Drive the machine straight toward the ramps and travel up or down the ramps at 1st (low) speed, by following the signal from the signal person.
8. Load the machine at the specified position on the transporter.
Refer to "Transporting posture" on page 4-6.



HOISTING THE MACHINE



WARNING

- Know and use the correct crane signals.
 - Check the hoisting equipment for damaged or missing parts on a daily basis and replace as necessary.
 - When hoisting, use a wire rope capable of lifting the machine mass.
 - Hoist the machine in only as manner described in the procedure below. Do not do it in any other manner. Doing so is dangerous as it may result in the machine losing its balance.
 - Do not hoist the machine with an operator on it.
 - When hoisting, hoist slowly so that the machine does not tip.
 - Keep everyone out of the area when hoisting. Do not move the machine over the heads of the persons.
-


IMPORTANT: This hoisting method applies to machines with standard specifications. The center of gravity differs according to the attachments and optional equipment installed. Contact your Takeuchi service agent for details.

Hoisting

1. Slew the upperstructure so that the dozer blade is at the rear of the machine (set the upperstructure parallel to the track frame).
2. Raise the dozer blade fully.
3. Extend the bucket cylinder and arm cylinder fully to raise the boom to its uppermost position.
4. If the boom is swung to either the left or right side, set it in the neutral position.
5. Raise the safety lock lever to the locked position.
6. Stop the engine, remove the starter key and get off the machine.
7. Install the wire ropes as shown on the figure below. Install the wire ropes and hoisting attachment without letting them touch the machine body.
8. Hoist the machine slowly until it leaves the ground.
9. Stop hoisting until the machine becomes stable, and then start hoisting the machine slowly again.



TRANSPORT HOISTING THE MACHINE






SECURING THE MACHINE

After loading the machine at the specified position, secure it as described below.

Transporting posture



1. Lower the dozer blade.
2. Extend the bucket cylinder and arm cylinder fully, and then lower the boom.
3. Raise the safety lock lever to the locked position.
4. Stop the engine, remove the starter key and lock all locks.
5. Place the stoppers (chocks) in front and behind the crawlers.
6. Install a chain or wire rope over the lower frame of the machine and fasten it securely to prevent the machine from slipping sideways.
7. Secure the bucket with a chain or wire rope.

IMPORTANT: Place a wooden block under the bucket to protect the floor from damage caused by the bucket.

Precautions to be taken during transportation



WARNING

- Know and follow the applicable safety rules, vehicle code and traffic laws when transporting the machine.
- Select the best transport route by considering the length, width, height and weight of the truck with the machine loaded on it.
- Never abruptly start or stop or run at a high speed at the sharp curves during transport. Doing so will move or lose the balance of the loaded machine.

MAINTENANCE





GENERAL

MAINTENANCE OVERVIEW

To keep the machine in good condition and use it for a long period, perform the inspection and maintenance properly and safely following the procedures recommended by this manual.

The inspection and maintenance items are divided into groups according to the machine's total operating time: every 10 hours (walk-around and daily inspection), every 50 hours, every 250 hours, etc. Refer to the hour meter readings to determine when to schedule an inspection and maintenance. Items for which it is not possible to determine the inspection and maintenance interval are included under "When Required".

When operating the machine in extremely harsh environments (with high dust levels or high temperatures), inspection and maintenance should be performed earlier than the times specified on the Maintenance List.

CAUTIONS ON MAINTENANCE

Do not perform any other inspection and maintenance works than those listed in this manual.

For works not listed in this manual, ask your sales or a service dealer for help.

Keep the machine clean

- Clean the machine before performing inspection and maintenance and try to keep it clean.
- Stop the engine before washing the machine. Cover the electrical parts so that water cannot enter. Water on electrical parts could cause short-circuits or malfunctions. Do not use water or steam to wash the battery, electronic control components, sensors, connectors or the operator's compartment.

Fuel, lubricant and grease

- Choose fuel, lubricant and grease by following to the "Fuel and lubricant table".
- Use fuels, lubricants and greases which do not contain water, and be careful to keep dirt out when changing or replenishing fuel, lubricant or grease.
- Store fuels, lubricants and greases in the prescribed places and in such a way that no water or dirt can get in them.

Cautions on refueling

- If the port includes a strainer, do not remove the strainer when fueling.
- After fueling, be sure to securely tighten the fuel filler cap.
- Do not add more than the specified amount of fuel.

Do not use fuel to clean parts

Do not use fuel to clean parts. Use a non-combustible cleaning agent.

Keep dirt out

When mounting and removing parts, do so in a place where there is no dust, clean the working area and the part, and keep dirt out.




Clean the installation surfaces

When installing and removing parts, be sure that the surfaces of contact of the parts are clean. If the sealing grooves of the surface of contact are damaged, consult your sales or service dealer for repair or release.

Seals and split pins

- Be sure to replace all seals and cotter pins with new ones.
- When installing, be careful not to damage or twist the seal.

Sealing tape



- When wrapping the plug with sealing tape, remove any old sealing tape from the threads and clean the threads.
- Wrap the thread tight with seal tape starting 1 or 2 threads away from the thread end.

Disposing of wastes

- Always collect oil that is drained from the machine in containers. Improperly disposed waste oil can cause environmental harm.
- Follow appropriate laws and regulations when disposing of harmful objects such as oil, fuel, cooling water, coolant, filters and batteries.

Check after maintenance

- Gradually increase the engine speed from a low idle to maximum speed and check that there is no oil or water leaking from serviced parts.
- Operate each control lever and check that the machine is operating properly.

Cautions on handling of battery wiring

- Disconnect the wiring from the both terminals (+ and -) on the battery before working on the electrical system or doing electric welding.
Always disconnect it from the earth side (-). When connecting, connect the earth side last.
- Do not disconnect the battery wiring while the engine is moving. Otherwise, the electric circuits of the rotary converter or others may be damaged.



SERVICE DATA

FUEL AND LUBRICANT TABLE

Select the appropriate fuel, lubricant and grease according to the temperature by referring to the table below.

- Regardless of the specified time, change the oil if it becomes too dirty or degraded.
- When refilling, never mix oils of different brands. If a brand is to be changed, replace the whole fuel/oil.

Fuel

Diesel fuel specifications

Diesel fuel should comply with the following specifications. The table lists several worldwide specifications for diesel fuels.

Diesel fuel specification	Area	Diesel fuel specification	Area
ASTM D975 No.1-D S15 No.2-D S15	USA Canada	BS2869-A1 or A2	United kingdom
Bio-diesel fuel Biodiesel blends up to B7 ASTM D6751, D7467			
EN590: 2009	European union	ISO 8217DMX	International
Bio-diesel fuel Biodiesel blends up to B7 EN14214, EN590		JIS K2204 Grade No.2 Bio-diesel fuel Biodiesel blends up to B7 JIS K2390	Japan



Fuel tank	Diesel fuel	To maintain the performance and service life of the engine, always use clean and high-quality fuel. • To avoid freezing in cold climates, use a diesel fuel that still functions when the temperature is at least 12°C (21.6°F) below the lowest expected ambient temperature. • Use a diesel fuel that has a cetane number of 45 or higher. When operating at a very low temperature or at a high altitude, a higher cetane number fuel will be required. • Use fuel with sulfur content of less than 15 ppm by volume. Especially in the U.S.A. and Canada, ultra-low sulfur fuel should be used. A higher sulfur content fuel may cause sulfuric acid corrosion in the cylinders of the engines. • Never mix kerosene, used engine oil, or residual fuel with the diesel fuel. Use of kerosene is prohibited. • Poor quality fuel can reduce engine performance and / or cause engine damage. • Fuel additives are not recommended. Some fuel additives may cause poor engine performance. • Use zinc- and sodium-free fuel. • Do not use the fuel that has been in storage for a long time. • Do not use the fuel purchased from a non-authorized dealer. • In the EU, use fuel that satisfies the following conditions · Sulfur content is 10 mg/kg (10 ppm) or less, and 15 mg/kg (15 ppm) or less at the final distribution point. · Cetane number is 45% or more. · Fatty acid methyl ester (FAME) content is 7% v/v or less. Precautions when using bio-diesel fuel The warranty of the engine manufacturer may be voided by using a bio-diesel fuel that does not meet the standard or that is deteriorated.
-----------	-------------	---



Lubricant

Location	Type	Type by air temperature														When to replace
		-4	14	32	50	68	86	104°F	-20	-10	0	10	20	30	40°C	
Engine oil pan	Diesel engine oil API: CJ-4 class or higher ACEA: E6 class	SAE 10W-30 SAE 15W-40														Every 250 hrs.
Hydraulic oil tank	Takeuchi genuine hydraulic oil 46	ISO VG46														Every 4000 hrs.***
	Anti-wear hydraulic oil	ISO VG32 ISO VG46 ISO VG68														Every 2000 hrs.***
Engine cooling system	Cooling water (water + coolant)** SAE: J814C or J1034 ASTM: D3306 JIS: K2234	Mixture of 50% coolant Mixture of 30% coolant														Every 2000 hrs. or every two years (whichever comes first) <Applicable machine models 185100001 or later>
Travel reduction gear	Gear oil API: GL-4	SAE 90														Every 1000 hrs after the initial 250 hrs*.
Slew bearing	Lithium based grease EP-2 NLGI No.2	—														Every 50 hrs.
Working equipment																Daily or every 10 hrs.

* : If the ratio of traveling time to total operating time is high, replace the gear oil earlier than the specified time.

** : For water, use tap water (soft). Do not use well or river water. When the ambient temperature drops below 0°C (32°F), add coolant (antifreeze). Follow the coolant manufacturer's instructions to determine the mixture ratio.

*** : The hydraulic oil replacement interval depends on the type of hydraulic oil being used. New machine are delivered with Takeuchi genuine hydraulic oil 46, and the hydraulic oil replacement intervals indicated in this manual assume that Takeuchi genuine hydraulic oil 46 is being used. When using conventional antiwear hydraulic oil, the hydraulic oil should be replaced every 2000 hours.

API standard: American Petroleum Institute

ACEA standard: Association des Constructeurs Européens d'Automobiles

SAE standard: Society of Automotive Engineers



Volume

<Applicable machine models 185100001 or later>

Engine oil pan	Engine cooling system	Hydraulic oil tank	Fuel tank	Travel reduction gear
Upper limit 10.2 L (10.8 US qt.) Lower limit 5.7 L (6.0 US qt.)	14 L (14.8 US qt.)	System 140 L (37 US gal.) Tank 73 L (19.3 US gal.)	Level capacity 128 L (33.8 US gal.) 120 L (31.7 US gal.)*	1.1L X 2 (1.16 US qt.) X 2

*: When the auto fuel supply pump is stopped

<Applicable machine models 190200001 or later>

Engine oil pan	Engine cooling system	Hydraulic oil tank	Fuel tank	Travel reduction gear
Upper limit 15 L (15.9 US qt.) Lower limit 11 L (11.6 US qt.)	16 L (16.9 US qt.)	System 140 L (37 US gal.) Tank 73 L (19.3 US gal.)	Level capacity 128 L (33.8 US gal.) 120 L (31.7 US gal.)*	1.1L X 2 (1.16 US qt.) X 2

*: When the auto fuel supply pump is stopped

<Applicable machine models 185100001 or later>

Note: On the DPF-equipped engines, part of the fuel may get mixed with engine oil during the regenerating process.

This may dilute the oil and increase its quantity. If the oil rises above the upper limit of the oil level gauge, it means the oil has been diluted too much, resulting in a trouble. In such case, immediately replace the oil with new one.



REGULARLY REPLACE THE HYDRAULIC OIL


When a hydraulic breaker is used, the oil deteriorates more quickly than that used for a usual excavation operation. Be sure to replace the hydraulic oil and the return filter elements.

- Failure to replace these in time can lead to damage to the machine and the breaker hydraulic system. To prolong the service life of the hydraulic devices, properly replace the hydraulic oil and the return filter elements according to the table below.
- When replacing the hydraulic oil, clean the suction strainer.

Replacement interval (hours)

Item	Hydraulic oil	Filter element
1st time	—	25
2nd time	—	100
Periodically	1200 (600)	200

When the breaker operating ratio is 100%.
Refer to “Hydraulic breaker” on page 8-6.



(): When a conventional antiwear hydraulic oil is used.



LIST OF CONSUMABLES

Periodically replace consumables such as filters and elements according to the table below.

System	Item	Part name	Part No.	When to replace
Hydraulic system	Hydraulic oil return filter	Element	15511-03900	Every 1000 hrs after the initial 250 hrs.
	Pilot line filter		15512-00601	
	Air breather filter		Applicable machine models 185100001 to 185102919 190200001 to 190200485 15520-02715 Applicable machine models 185102920 or later 190200486 or later 15520-05002	Every 1000 hrs.
Engine lubrication system	Engine oil filter	Cartridge	Y129150-35153 *	Every 250 hrs.
		Element	I8-98018-8580 **	
Fuel system	Fuel filter	Cartridge	Y129A00-55800 *	Every 500 hrs.
	Water separator filter	Cartridge	Y129A00-55730 *	
	Pre-fuel filter	Element	15520-02910 **	
	Main fuel filter		I8-98143-0410 **	
	Feed pump filter	Repair kit	I8-98173-1650 **	
Air cleaner system	Air cleaner	Primary (Outer) element	19111-13001	Every 1000 hrs. or after 6 cleanings (whichever comes first)
		Secondary (Inner) element	19111-13002	When the primary elements are replaced.
AC system	Receiver dryer		19115-13660	Every 2 years
	Ventilation filter	Element	19115-13680	Once a year or if clogging remains after cleaning

* : Applicable machine models 185100001 or later

** : Applicable machine models 190200001 or later



LIST OF TOOLS (IF EQUIPPED)

Code	Part name	Part No.	Remarks
1	Spanner	Y28110-100120* 16900-01012**	10 - 12
2	Spanner	Y28110-140170* 16900-01417**	14 - 17
3	Screwdriver	Y104200-92350* 16902-20205**	(+) (-) replaceable shank
4	Filter wrench (for engine oil filter)	Y119640-92750* 16919-03560**	
	Filter wrench (for fuel filter)	19103-47081**	
5	Hammer	16903-00330	3/4
6	Monkey wrench	16904-00250	250 mm
7	Pliers	16905-00200	200 mm
8	Spanner	16900-01013	10-13
9	Spanner	16900-01922	19-22
10	Spanner	16900-02427	24-27
11	Spanner	16900-02730	27-30
12	Spanner	16900-03236	32-36
13	Single-ended wrench	16901-00041	41
14	Hex. wrench	16906-00500	5 mm
15	Hex. wrench	16906-00600	6 mm
16	Hex. wrench	16906-00800	8 mm
17	Hex. wrench	16906-01000	10 mm
18	Hex. wrench	16906-01200	12 mm
19	Tool case	16914-00005	
20	Case	16919-00001	
21	Grease gun	16910-60610	600 cc
22	Drain connector	15545-12601	

* : Applicable machine models 185100001 or later

** : Applicable machine models 190200001 or later





LIST OF TIGHTENING TORQUES

Nuts and Bolts (for ISO strength category 10.9)

Tighten nuts and bolts at the torques shown on the table below, unless otherwise specified.

- The tightening torques used for the mounted plastic covers are not listed in the table below. Consult your sales or service dealer for details. They will be damaged if over tightened.
- When replacing nuts and bolts, replace them with nuts and bolts of the same size and standards.
- Tighten nuts and bolts alternately (top, bottom, left then right) or in 2 or 3 times so that they are evenly tightened.



Classification	Head width (b)	Size (a) x pitch	Tightening torque	
			General connection points	
			N·m	ft·lb.
Coarse	10	M6 x 1.0	9.8±0.5	7.2±0.4
	12, 13	M8 x 1.25	22.6±1.1	16.6±0.8
	14, 17	M10 x 1.5	47.1±2.4	34.7±1.7
	17, 19	M12 x 1.75	83.4±4.1	61.5±3.0
	19, 22	M14 x 2.0	134.4±6.7	99.1±4.9
	22, 24	M16 x 2.0	207.9±10.4	153.3±7.7
	27, 30	M20 x 2.5	410.9±20.5	303.1±15.1
Fine	12, 13	M8 x 1.0	24.5±1.2	18.1±0.9
	14, 17	M10 x 1.25	50±2.5	36.9±1.8
	17, 19	M12 x 1.5	87.3±4.3	64.4±3.2
	19, 22	M14 x 1.5	135.3±6.8	99.8±5.0
	22, 24	M16 x 1.5	220.6±11	162.7±8.1
	27, 30	M20 x 1.5	452.1±22.6	333.4±16.6



SAFETY-CRITICAL PARTS

To use the machine safely, periodically perform inspection and maintenance. The safety-critical parts listed below must be periodically replaced for an increased safety. Serious injury or a fire could result if they are worn or damaged.

List of safety-critical parts

Unit		Safety-critical parts to be replaced periodically	When to replace
Fuel system		Fuel hoses	Every 2 years
		Packing on fuel filler cap	
Cooling system		Rubber hoses	
Heater & AC systems		Heater hoses	
		Air conditioner hoses	
Hydraulic system	Main body	Hydraulic hoses (pump - delivery)	
		Hydraulic hoses (pump - suction)	
		Hydraulic hoses (slew motor)	
		Hydraulic hoses (travel motor)	
	Working equipment	Hydraulic hoses (boom cylinder piping)	
		Hydraulic hoses (second boom cylinder piping)	
		Hydraulic hoses (arm cylinder piping)	
		Hydraulic hoses (bucket cylinder piping)	
		Hydraulic hoses (swing cylinder)	
		Hydraulic hoses (blade cylinder)	
		Hydraulic hoses (angle blade cylinder)	
		Hydraulic hoses (tension cylinder)	
		Hydraulic hoses (pilot valve)	
		Hydraulic hoses (auxiliary piping)	
		Seat belt	Every 3 years
		Non-slip sheet	



The material of the safety-critical part listed above tends to change over time and cause wear or deterioration. It is difficult to determine the degree of deterioration at the periodic inspection, and thus they need to be replaced with new ones after a certain time to maintain their proper performance even if they appear in good condition. Note that regardless of the replacement schedule, replacement must be performed immediately if a symptom of wear is found. If a hose clamp is deformed or cracked, replace it together with the hose immediately. When replacing the safety-critical parts, ask your sales or service dealer.

In addition to the safety-critical parts, inspect the hydraulic hoses and retighten or replace as necessary. When replacing the hydraulic hoses, replace the O-rings and seals at the same time.

Check the fuel and hydraulic hoses according to the periodic schedule described below.

Refer to "Maintenance".

Type of inspection	Inspection item
Daily inspection	Leakage from the connecting parts of hydraulic or fuel hoses Damage to cab - replace*
Monthly inspection	Leakage from the connecting parts of hydraulic or fuel hoses Damaged hydraulic or fuel hoses (cracks, wear and tear)
Annual inspection	Leakage from the connecting parts of hydraulic or fuel hoses Deteriorated, twisted, damaged hydraulic or fuel hoses (cracks, wear and tear) or hoses in contact with other parts of the machine

*: Cab parts No. 05686-00128



MAINTENANCE LIST

<APPLICABLE MACHINE MODELS 185100001 OR LATER>

Inspection and maintenance item	Page
Walk-around inspection	
Inspecting by opening the engine hood and covers	5-18
Inspecting by walking around the machine	5-19
Inspecting while sitting in the operator's seat	5-19
Daily inspection (every 10 hours)	
Inspecting and replenishing the coolant	5-20
Inspecting and replenishing the engine oil	5-21
Inspecting the water separator and the fuel filters	5-22
Inspecting the fuel level	5-23
Inspecting the hydraulic oil tank level and replenishing	5-24
Lubricating the working equipment	5-25
After the initial 50 hours (only for new machines)	
Inspecting and adjusting the fan belt	5-26
Inspecting and adjusting the compressor belt (AC)	5-28
Every 50 hours	
Inspecting the crawler belt tension	5-30
Lubricating the slew bearing	5-30
Draining the water from the fuel tank	5-31
Inspecting the battery fluid level and replenishing	5-32
After the initial 250 hours (only for new machines)	
Replacing the hydraulic oil return filter	5-34
Replacing the pilot line filter	5-35
Replacing the travel motor gear oil*	5-36
Every 250 hours	
Inspecting and adjusting the fan belt	5-37
Inspecting and adjusting the compressor belt (AC)	5-37
Replacing the engine oil and the oil filter	5-38
Cleaning the air cleaner	5-40
Cleaning the radiator fins and the oil cooler fins	5-41
Cleaning the air filters (AC)	5-42
Cleaning the condenser (AC)	5-43
Inspecting the refrigerant (gas) level (AC)	5-44

*: If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.

AC: Air Conditioner



Inspection and maintenance item	Page
Every 500 hours	
Replacing the fuel filter	5-46
Replacing the water separator filter	5-47
Inspecting the slew pinion gear	5-48
Every 1000 hours	
Replacing the hydraulic oil return filter	5-50
Replacing the pilot line filter	5-50
Replacing the travel motor gear oil*	5-50
Replacing the air cleaner element	5-52
Replacing the air breather filter	5-53
Inspecting and adjusting the engine valve clearance	5-53
Every 1500 hours	
Inspecting the crankcase breather system	5-54
Every 2000 hours	
Cleaning the engine cooling system	5-55
Every 3000 hours	
Inspecting the turbocharger (blow wash as necessary)	5-56
Inspecting, cleaning and checking operation of the EGR valve	5-56
Cleaning the EGR lead valve	5-56
Cleaning the EGR cooler (cleaning the water side and exhaust air passage blower)	5-56
Inspecting the operation of the air intake throttle valve	5-56
Inspecting and cleaning the fuel injector	5-56
Every 4000 hours	
Replacing the hydraulic oil and cleaning the suction strainer	5-57
When Required	
Replacing the bucket teeth and the side cutters	5-62
Replacing the bucket	5-64
Adjusting the gap between the bucket and arm (If equipped)	5-66
Inspecting and replenishing the windshield washer fluid	5-67
Inspecting and cleaning the DPF soot filter	5-67
Draining the water from the water separator	5-68
Lubricating the levers and pedals	5-70
Inspecting the rubber crawlers	5-71
Replacing the rubber crawlers	5-72
Every 2 years	
Replacing the receiver dryer	5-74

*: If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.



MAINTENANCE LIST

<APPLICABLE MACHINE MODELS 190200001 OR LATER >

Inspection and maintenance item	Page
Walk-around inspection	
Inspecting by opening the engine hood and covers	5-18
Inspecting by walking around the machine	5-19
Inspecting while sitting in the operator's seat	5-19
Daily inspection (every 10 hours)	
Inspecting and replenishing the coolant	5-20
Inspecting and replenishing the engine oil	5-21
Inspecting the water separator and the fuel filters	5-22
Inspecting the fuel level	5-23
Inspecting the hydraulic oil tank level and replenishing	5-24
Lubricating the working equipment	5-25
After the initial 50 hours (only for new machines)	
Inspecting and adjusting the fan belt	5-26
Inspecting and adjusting the compressor belt (AC)	5-28
Every 50 hours	
Inspecting the crawler belt tension	5-30
Lubricating the slew bearing	5-30
Draining the water from the fuel tank	5-31
Inspecting the battery fluid level and replenishing	5-32
After the initial 250 hours (only for new machines)	
Replacing the hydraulic oil return filter	5-34
Replacing the pilot line filter	5-35
Replacing the travel motor gear oil*	5-36
Every 250 hours	
Inspecting and adjusting the fan belt	5-37
Inspecting and adjusting the compressor belt (AC)	5-37
Replacing the engine oil and the oil filter	5-38
Cleaning the air cleaner	5-40
Cleaning the radiator fins and the oil cooler fins	5-41
Cleaning the air filters (AC)	5-42
Cleaning the condenser (AC)	5-43
Inspecting the refrigerant (gas) level (AC)	5-44

*: If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.

AC: Air Conditioner



Inspection and maintenance item	Page
Every 500 hours	
Replacing the fuel filter	5-46
Cleaning the feed pump filter	5-48
Inspecting the slew pinion gear	5-48
Inspecting and cleaning the supply pump strainer	5-49
Every 1000 hours	
Replacing the hydraulic oil return filter	5-50
Replacing the pilot line filter	5-50
Replacing the travel motor gear oil*	5-50
Cleaning the engine cooling system	5-50
Replacing the air cleaner element	5-52
Replacing the air breather filter	5-53
Inspecting and adjusting the engine valve clearance	5-53
Inspecting the engine compression pressure	5-53
Inspecting and cleaning the engine starter and the alternator	5-53
Every 1500 hours	
Inspecting and replacing the air filter case for cracking	5-54
Inspecting and cleaning the EGR cooler	5-54
Every 3000 hours	
Inspecting the turbocharger (blow wash as necessary)	5-56
Inspecting and cleaning the EGR valve	5-56
Inspecting the engine controller (ECM)	5-56
Inspecting and cleaning the fuel injector	5-56
Every 4000 hours	
Replacing the hydraulic oil and cleaning the suction strainer	5-57
When Required	
Replacing the bucket teeth and the side cutters	5-62
Replacing the bucket	5-64
Adjusting the gap between the bucket and arm (If equipped)	5-66
Inspecting and replenishing the windshield washer fluid	5-67
Draining the water from the water separator	5-69
Lubricating the levers and pedals	5-70
Inspecting the rubber crawlers	5-71
Replacing the rubber crawlers	5-72
Every 2 years	
Replacing the receiver dryer	5-74

*: If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.




WALK-AROUND INSPECTION

Perform the following inspections every day before starting the engine for the first time.

WARNING

- Before operating, perform the walk-around inspections and make repairs immediately where necessary.
- Be sure to secure the engine hood or cover before working the inside. Do not keep the hood or cover open on a windy day or if the machine is parked on a slope.

Before starting the engine, look around the machine and clean any combustibles from the surroundings of the engine. Also, inspect if oil or water is leaking and any nuts, bolts or electric wiring are loosened or damaged.



AM1G0011

INSPECTING BY OPENING THE ENGINE HOOD AND COVERS

1. Check for any twigs, leaves, oil or other combustible materials around the engine and battery.
2. Check for oil or engine coolant water leakage around the engine.

3. Check for oil leakage from the hydraulic oil tank, hydraulic devices, hoses or connections.



INSPECTING BY WALKING AROUND THE MACHINE

4. Check lights for dirt, damage and burnt out bulbs.
5. Check attachments and hoses for damage.
6. Check the bucket, bucket teeth and side cutter for wear, damage and looseness.
7. Check the hook, slip stopper and hook mount of buckets with hooks for damage. (Option)
8. Check the handrail, the steps and the slip-resistant surfaces for damage and loose bolts.
9. Check the crawlers, carrier rollers, track rollers, idlers and sprockets for damage, wear and loose bolts.
10. Check for oil leakage from the travel motor, carrier rollers, track rollers and idlers.
11. Check the cab and guard for damage and loose nuts and bolts.
12. Check the mirrors for dirt or damage, and adjust them.
13. Check the labels for dirt and damage.

INSPECTING WHILE SITTING IN THE OPERATOR'S SEAT

14. Check the windshield for dirt or damage.
15. Check the seat and seat belt for dirt or damage.
Check the operator's seat for dirt, oil or other combustible materials.
16. Check the monitor, instruments and switches for dirt or damage.



DAILY INSPECTION (EVERY 10 HOURS)

Perform the following inspections every day before starting the engine for the first time.



WARNING

- Before operating, perform the daily inspections and make repairs immediately where necessary.
- Be sure to secure the engine hood or cover before working the inside. Do not keep the hood or cover open on a windy day or if the machine is parked on a slope.


INSPECTING AND REPLENISHING THE COOLANT



WARNING

- Do not remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine and wait until the engine and the radiator cool before slowly loosening the radiator cap and the drain plug to remove them.
- Always wear the protective goggle and gloves when handling coolant (antifreeze). If any coolant (antifreeze) comes in contact with eyes or skin, wash it off with clean water. Otherwise, it could result in injuries.


Inspection



1. Open the fuel lid.
2. Inspect the cooling water level in the reserve tank (1).
The level should be between the upper limit (H) and the lower limit (L).
If it is below the lower limit (L), replenish.

Replenishing

1. Open the engine hood.
2. Remove the cap (2) of the reserve tank (1).
3. Add cooling water up to the upper limit (H) of the reserve tank (1).



If the reserve tank (1) is found empty at the inspection, check for water leakage and then the water level in the radiator (3). Add water to the radiator (3) as required, and then to the reserve tank (1).

4. Install the cap (2).

Note: Use only clean water (soft water), such as tap water, to replenish the coolant loss due to evaporation. If the coolant loss is due to leakage, replenish the mixture of antifreeze and clean water (soft water) prepared using the same mixing ratio used for the current coolant.




INSPECTING AND REPLENISHING THE ENGINE OIL

WARNING


Stop the engine and allow the machine to cool down before performing maintenance.

Inspection

<Applicable machine models 185100001 or later>



<Applicable machine models 190200001 or later>



1. Open the engine hood.
2. Take out the dipstick (1) and wipe the oil off with a rag.
The dipstick of the machines with a model number of 190200001 or later is attached to the oil filler cap.

3. Fully reinsert the dipstick (1), and then pull it back out.

For the machines with a model number of 190200001 or later, do not screw the cap portion of the dipstick into the oil fill hole, but leave it on the lip of the hole and pull out the dipstick.

4. Check the oil on the dipstick (1).
The level should be between the upper limit (H) and the lower limit (L).
If it is below the lower limit (L), replenish.

Replenishing

1. Remove the oil filler cap (2).
For the machines with a model number of 190200001 or later, oil can be replenished through the oil fill hole of the dipstick (1).
2. Add oil up to between the upper limit (H) and the lower limit (L) of the dipstick (1).
Problems could arise if the oil level is either too low or too high.
3. Tighten the oil filler cap (2).
4. Start the engine, run it at low idle for about 5 minutes, then stop it.
5. After about 15 minutes, inspect the oil level.




INSPECTING THE WATER SEPARATOR AND THE FUEL FILTERS

WARNING


- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.

Water separator



1. Turn the starter switch to the ON position.
2. Inspect the water separator warning lamp.
3. If the warning lamp is flashing, drain the water.
Refer to “Draining the water from the water separator” on pages 5-68 and 5-69.

Fuel filters <Applicable machine models
190200001 or later>



1. Open the fuel lid or the side cover.
2. Check if there is water in the pre-fuel filter (1) and the main fuel filter (2).
If water collects in the filter, the float (red ring) (3) goes up. Be sure to drain water before the float (3) goes up to the element (4).
3. Loose the vent plug (5) and then the drain plug (6) to discharge water collected inside.
4. After drainage of water, tighten each plug and bleed air from the fuel system.
Refer to “Bleeding air from the fuel system” on page 6-8.




INSPECTING THE FUEL LEVEL



WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Do not spill fuel on the hot surface of the machine.
- Fill the fuel tank in a well ventilated place.
- Clean up spilled fuel immediately.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Securely tighten the fuel filler cap.
- Use the correct grade of fuel for the operating season.



1. Check the fuel level using the fuel gauge (1).
F: Tank is full.
E: Tank is empty.
2. If the fuel level is low, open the fuel lid.
3. Add fuel from the fuel filler port (2) while watching the sight gauge (3).
Refer to "Fuel filler port" on page 2-5.



INSPECTING THE HYDRAULIC OIL TANK LEVEL AND REPLENISHING

WARNING


Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.

- Press the air breather button to relieve the internal pressure from the tank.

Inspection


The oil level changes with the oil temperature. Inspect the oil by maintaining the machine at posture shown in the figure at the next.

- Machine posture for inspecting the hydraulic oil level



1. Start the engine and run it at low speed.
2. Fully retract the cylinders (arm and bucket), and lower the bucket to the ground.
For the 2-piece boom, fully retract the cylinders (adjust, arm and bucket), and lower the bucket to the ground.
3. Lower the dozer blade, and then stop the engine.
4. Open the fuel lid.
5. Inspect the oil level using the sight gauge (1).
 - When the oil temperature is about 20°C (68°F):
The level should be between the upper limit (H) and the lower limit (L).
If it is below the lower limit (L), replenish.
 - When the oil temperature is about 50 to 80°C (122 to 176°F):
The level should be slightly below the upper limit (H).

Replenishing




IMPORTANT: Do not fill up to the level higher than the upper limit (H). It will damage the hydraulic circuits or result in oil spurring. If accidentally done, stop the engine and wait the hydraulic oil to cool, and then let the excessive oil to drain from the drain plug.

1. Open the side cover.
2. Press the air breather button (2) to relieve the internal pressure from the tank.
3. Remove the plug (3).
4. Add the hydraulic oil up to the middle point of the sight gauge (1).
5. Tighten the plug (3).



LUBRICATING THE WORKING EQUIPMENT



1. Keep the machine configuration as shown in the diagram above, lower the working equipment to the ground, and then stop the engine.
2. Use the grease gun to lubricate the grease fittings.
3. Wipe off the excess grease.



AFTER THE INITIAL 50 HOURS (ONLY FOR NEW MACHINES)

INSPECTING AND ADJUSTING THE FAN BELT



WARNING

Stop the engine and allow the machine to cool down before performing maintenance.

- The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.


IMPORTANT: The loose belts could result in bad battery charge, overheat of engine or early wear of belt. Too tight belts could damage the water pump or bearing and belt used to drive the alternator.

IMPORTANT: Do not let any oil or grease get on the belt.


Inspection

1. Open the engine hood.

<Applicable machine models 185100001 or later>



<Applicable machine models 190200001 or later>



2. Press the fan belt (1) at the midpoint between the fan pulley (2) and alternator pulley (3) to check the tension (approx. 98 N or 22 lbf).

<Applicable machine models 185100001 or later>

The slack (A) should be 7 to 10 mm (0.28 to 0.4 in).


<Applicable machine models 190200001 or later>

The slack (A) should be 6.6 to 7.4 mm (0.26 to 0.29 in).


3. Inspect the fan belt (1) and replace if it is as follows.
 - There are cuts or cracks.
 - The belt is worn and touches the bottom of the V groove in the pulley.
 - The belt stretched too loose to be adjusted.

**Adjustment**

<Applicable machine models 185100001 or later>



<Applicable machine models 190200001 or later>



1. Loosen the bolt (5) and locking nut (4).
2. Turn the adjustment bolt (6) to move the alternator (7) and to adjust the tension of the fan belt (1).
 - Tighten: Clockwise
 - Loosen: Counterclockwise
3. Tighten the bolt (5) and locking nut (4).
Tightening torque:
<Applicable machine models 190200001 or later>
 - Locking nut (4) 25 N·m (18.1 ft-lb.)
 - Bolt (5) 51N·m (37.6 ft-lb.)

Note: When replacing with a new belt, run the engine at low idle speed for about 3 to 5 minutes to break in the new belt, before adjusting the tension.



INSPECTING AND ADJUSTING THE COMPRESSOR BELT (AC)

WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
 - The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
- The high-pressure pipes of the air conditioner can be very hot (80 to 120°C or 176 to 248°F). Be careful not to burn yourself.


IMPORTANT: Do not let any oil or grease get on the belt. It will cause the belt to slip, decrease the cooling capacity or shorten the service life of the air conditioner.

If the belt is too slack, it will slip and vibrate, resulting in decreased cooling capacity. The service life of the air conditioner also will be shortened. Adjust the belt tension to the standard value.


For the machines with a model number of 185100001 or later, 294 to 392 N or 66 to 88 lbf.

For the machines with a model number of 190200001 or later, 432.2 to 449.8 N or 97.2 to 101.1 lbf.

<Applicable machine models 185100001 or later>




<Applicable machine models 190200001 or later>



Inspection

<Applicable machine models 185100001 or later>



1. Loosen the bolts and remove the under cover (4). <Applicable machine models 185100001 or later>



1. Open the engine hood. <Applicable machine models 190200001 or later>
2. Measure the belt (1) tension using the belt tension gauge. The belt tension is normal if the belt tension gauge indicates the following values.

For the machines with a model number of 185100001 or later, 294 to 392 N or 66 to 88 lbf.

For the machines with a model number of 190200001 or later, 432.2 to 449.8 N or 97.2 to 101.1 lbf.

Adjustment

<Applicable machine models 185100001 or later>

If the belt tension is not normal, adjust it with the adjuster bolt (2).

1. Loosen the locking nut (3).
2. Turn the adjuster bolt (2) as follows.
 - Tighten: Clockwise
 - Loosen: Counterclockwise

3. Tighten the locking nut (3) after adjustment.

Tightening torque:

- Locking nut (4) 31.4 to 45.1 N·m (23.2 to 33.3 ft-lb.)

<Applicable machine models 190200001 or later>

If the belt tension is not normal, tilt the compressor to adjust the tension.

1. Loosen the fixing bolt (5) and fixing nut (6).
2. Turn the adjuster bolt (7) as follows.
 - Tighten: Clockwise
 - Loosen: Counterclockwise
3. Tighten the fixing bolt (5) and fixing nut (6) upon completion of adjustment.

Note: When replacing with a new belt, run the engine at low idle speed for about 3 to 5 minutes to break in the new belt, before adjusting the tension again.

Replacing

Replace the belt in the following cases:

- There are cuts or cracks.
- The belt is worn and touches the bottom of the V groove in the pulley.
- The belt stretched too loose to be adjusted.



EVERY 50 HOURS

INSPECTING THE CRAWLER BELT TENSION

Note: This machine uses a hydraulic cylinder to adjust the tension of the crawler belts. It is not necessary to regularly perform adjustments of the crawler belt tension.


If the tension is too loose and the track comes off, the hydraulic cylinder is likely faulty. Ask your sales or service dealer for repairs.

LUBRICATING THE SLEW BEARING




WARNING


Do not slew while lubricating. Doing so is dangerous, as you may get caught in the machine.



1. Stop the engine with the machine in the posture shown on the figure above.



2. Use the grease gun to grease the grease fitting (1).



3. Start the engine, lift the bucket and slew clockwise 90°.
4. Lower the bucket to the ground, and then stop the engine.
5. Repeat the steps 2 to 4 above three times.
6. Wipe off the grease expelled from the slew bearing and grease fitting.




DRAINING THE WATER FROM THE FUEL TANK

WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Never remove the fuel cap or add fuel when the engine is running or still hot. Do not spill fuel on the hot surface of the machine.
- Fill the fuel tank in a well ventilated place.
- Do not fill the fuel tank to capacity. Allow room for oil expansion.
- Clean up spilled fuel immediately.
- Securely tighten the fuel filler cap.
- Use the correct grade of fuel for the operating season.

Do the draining operation before starting the machine.



1. Open the side cover.
2. Remove the fuel filler cap (2).
3. Place a pan under the drain valve (3).
4. Remove the cap (A), install the connector (B), and then drain the water and sediment buildup in the bottom of the tank (the water comes out when the screw is tightened).
5. Remove the connector (B) and install the cap (A).
6. Add fuel while watching the sight gauge (1).
7. Tighten the fuel filler cap (2).
8. Close the side cover and lock it with the key.

9. Bleed air.

Bleeding air from the fuel system

Refer to "Bleeding air from the fuel system" on page 6-8.

Note: Air in the fuel system causes the engine to fail to start or to have problems. Bleed air when the fuel tank is emptied, using the same procedure above.



INSPECTING THE BATTERY FLUID LEVEL AND REPLENISHING



DANGER

- Do not use the battery when the fluid level is below the lower level limit. Doing so will hasten the deterioration of the internal portions of the battery and shorten the battery life. It also can cause rupturing (explosion).
- Batteries generate flammable hydrogen gas which may explode. Keep away from flame, sparks, fire or lighted cigarettes.
- Use a dampened cloth to clean above the fluid level line and check the fluid level. Do not clean with a dry cloth; otherwise it can cause static electricity to build up, resulting in ignition or explosion.




WARNING

- Wear protective goggle and clothing when working with batteries.
- Do not add the distilled water above the upper level limit. Doing so could cause the fluid to leak. This fluid can cause skin damage if contacted, or can cause the machine components to corrode.
- Batteries contain sulfuric acid which will damage eyes or skin if contacted.
 - If eye contact occurs, flush immediately with clean water and get prompt medical attention.
 - If accidentally swallowed, drink large quantities of water or milk and call a physician immediately.
 - If acid contacts skin or clothing, wash off immediately with a lot of water.

Inspection

IMPORTANT: Check the fluid level of all cells following the steps below, even when the fluid level can be checked using the indicator.

1. Open the engine hood.




2. Inspect the indicator (1).
 - Blue: Good
 - White: Charging needed
 - Red: Insufficient battery fluid
3. Inspect the fluid level.

The fluid level must be between the upper level line (H) and lower level line (L). If not, add distilled water up to the line (H).



MAINTENANCE EVERY 50 HOURS

- If the fluid level cannot be checked by fluid level lines:



Remove the caps (2) and look into the fluid filler holes to check the fluid level. If the fluid is below the sleeve (3), be sure to add distilled water up to the bottom edge of the sleeve (3).

Proper level (A)

If the fluid reaches up to the bottom edge of the sleeve (3), the surface tension causes the fluid to swell and the plate appears as if it is distorted.

Level too low (B)

If fluid does not reach up to the bottom edge of the sleeve (3), the plate looks laminar, not distorted.

4. Check the terminals for looseness and dirt.

Replenishing

When adding distilled water, do so before starting operations in order to prevent freezing.

1. Remove the caps (2), and add distilled water until the upper level (H).
2. Check that the indicator (1) turns blue.
3. Clean the exhaust hole on the cap, then tighten the caps (2) securely.




AFTER THE INITIAL 250 HOURS (ONLY FOR NEW MACHINES)

REPLACING THE HYDRAULIC OIL RETURN FILTER



WARNING

- Stop the engine and allow each part of the machine to cool down before performing maintenance.
 - The engine, the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
 - The hydraulic oil is also hot and under high pressure immediately after the engine is stopped. Be careful not to touch the oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.
 - Press the air breather button to relieve the internal pressure from the tank.
 - When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.



1. Open the side cover.
2. Press the air breather button (2) to relieve the internal pressure from the tank.
3. Loosen the bolts and remove the flange (4).
4. Remove the return filter (5).
5. Install a new return filter.
6. Install the flange (4) on its original position.
7. Inspect the level with the sight gauge (1), and replenish if the level is too low. Refer to "Inspecting the hydraulic oil tank level and replenishing" on page 5-24.




REPLACING THE PILOT LINE FILTER




WARNING

- Stop the engine and allow each part of the machine to cool down before performing maintenance.
 - The engine, the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
 - The hydraulic oil is also hot and under high pressure immediately after the engine is stopped. Be careful not to touch the oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.
 - Press the air breather button to relieve the internal pressure from the tank.
 - When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.



1. Open the side cover.
2. Press the air breather button (2) to relieve the internal pressure from the tank.



3. Open the engine hood.
4. Turn the case (4) counterclockwise and remove it.
5. Remove the element (5) and O-ring (6).
6. Clean the inside of the case (4).
7. Apply a thin layer of oil on the O-ring of the new filter.
8. Install the new element on the filter stand (7).
9. Apply a thin layer of oil on the new O-ring (6).
10. Install the new O-ring (6) and the case (4) on the filter stand (7).
Tightening torque: $78.5 \pm 4.9 \text{ N}\cdot\text{m}$ ($57.9 \pm 3.6 \text{ ft}\cdot\text{lb.}$)
11. Inspect the level with the sight gauge (1) and replenish if the level is too low. Refer to "Inspecting the hydraulic oil tank level and replenishing" on page 5-24.



REPLACING THE TRAVEL MOTOR GEAR OIL




WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
 - The travel motor is hot immediately after the engine is stopped. Touching it will cause burns.
 - The gear oil is also hot and under high pressure immediately after the engine is stopped.
Be careful when loosening the plugs. Working on the machine under these conditions could result in burns or injuries.
- The pressure in the reduction gear case of travel motor may cause oil or the plug to fly out. Loosen the plug slowly to release the pressure.

6. Add oil through the hole of the plug (3) until oil flows out of the hole of the plug (2).
7. Tighten the plugs (2) and (3).
 - Tightening torque: $58.8 \pm 9.8 \text{ N}\cdot\text{m}$ (43.4 $\pm$ 7.2 ft-lb.)

IMPORTANT: If the percentage of the traveling time within the total operating time is high, replace the gear oil earlier than the specified time.



1. Set the travel motor so that plug (1) is at the very bottom.
2. Place a pan under the plug (1).
3. Remove the plugs (1), (2) and (3) and drain the oil.
4. Rewrap the plugs with new sealing tape.
5. Tighten the plug (1).
 - Tightening torque: $58.8 \pm 9.8 \text{ N}\cdot\text{m}$ (43.4 $\pm$ 7.2 ft-lb.)



EVERY 250 HOURS

INSPECTING AND ADJUSTING THE FAN BELT

Refer to “Inspecting and adjusting the fan belt” on page 5-26.

INSPECTING AND ADJUSTING THE COMPRESSOR BELT (AC)

Refer to “Inspecting and adjusting the compressor belt (AC)” on page 5-28.



REPLACING THE ENGINE OIL AND THE OIL FILTER

WARNING

Stop the engine and allow the machine to cool down before performing maintenance.


- The engine, muffler, radiator, hydraulic lines, sliding parts and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
- The engine oil is also hot.

Be careful not to touch the hydraulic oil when loosening the cap or plug.


Working on the machine under these conditions could result in burns or injuries.

Engine oil

<Applicable machine models 185100001 or later>




<Applicable machine models 190200001 or later>



1. Open the engine hood and remove the oil filler cap (2).

For the machines with a model number of 190200001 or later, the oil fill hole of the dipstick (1) can be removed for replenishing.



2. Loosen the bolts and remove the under cover (3).
3. Place a pan for catching the waste oil under the drain plug (4).
4. Remove the cap (A), install connector (B) and drain the oil. (The oil comes out when the screw is tightened.)
5. Remove the connector (B) and install the cap (A).
6. Install the under cover (3).

IMPORTANT: Check the waste oil for metal powder. If it contains large amounts of metal powder, consult your sales or service dealer.




Engine oil filter

<Applicable machine models 185100001 or later>

7. Turn the filter (5) counterclockwise with the filter wrench and remove it.
8. Clean the surface of installation of the filter stand.
9. Apply a thin layer of oil on the packing of the new filter.
10. Install the new filter by hand.
11. Tighten one more turn (with the filter wrench) after the filter packing comes in contact with the surface of installation.
(Torque when tightening with filter wrench: 19.6 to 23.5 N·m or 14 to 17 ft-lb.)
12. Add oil up to between the upper limit (H) and the lower limit (L) of the dipstick (1). Problems could arise if the oil level is either too low or too high. It takes around 10 to 20 minutes for all of the added oil to go down to the oil pan.
13. Tighten the oil filler cap (2).
14. Start the engine, run it at low idle for about 5 minutes, then stop it.
15. After about 15 minutes, inspect the oil level.

<Applicable machine models 190200001 or later>



7. Place a pan for catching the waste oil under the engine oil filter.
8. Remove the drain plug (4) and drain the oil from the filter case (6).
9. Loosen the bolt (5) and remove the filter case (6).
10. Clean the inside of the filter case (6) and install a new element (7).
11. Clean the surface to install the filter stand and coat the new O-rings with thin oil.
12. Install the case (6) and secure it with the bolt (5).
 - Tightening torque: 44.1 N·m (32.5 ft-lb.)
13. Install the drain plug (4).
 - Tightening torque: 24.5 N·m (18.1 ft-lb.)
14. Add oil up to between the upper limit (H) and the lower limit (L) of the dipstick (1). Problems could arise if the oil level is either too low or too high. It takes around 15 minutes for all of the added oil to go down to the oil pan.
15. Tighten the oil filler cap (2).
16. Start the engine, run it at low idle for about 5 minutes, and then stop it.
17. After about 15 minutes, inspect the oil level.



CLEANING THE AIR CLEANER


WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
 - The engine, muffler, radiator and many other parts of the machine are hot immediately after the engine is stopped. Touching it will cause burns.
- Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.


IMPORTANT: Be careful not to scratch the element. Do not use an element if it is damaged.

IMPORTANT: When operating the machine in very dusty places, perform inspection and maintenance operations every day.


IMPORTANT: Be sure to install the element and dust cap securely. If not, dust could be drawn into the cylinder, damaging the engine.



1. Open the engine hood.



2. Loosen the clamps (1) and remove the dust cup (2).
3. Clean the inside of the dust cup (2).
4. Remove the primary element (3).
To prevent dirt from getting inside the engine, do not remove the secondary element (5).
5. Clean the inside of the body (4).



6. Clean the primary element (3) with dried compressed air (294 to 490 kPa or 43 to 71 psi).
First blow the air from the inside of the element along the pleats. Then blow the air from the outside and finally from the inside again.
7. Light up the inside of the primary element (3) with a light bulb, inspect it, and replace it if there are small holes or thin spots.
8. Install the primary element (3).
9. Install the dust cup (2) with its "▲▲▲▲ OBEN/TOP" mark facing up, and then fasten it with the clamps (1).



CLEANING THE RADIATOR FINS AND THE OIL COOLER FINS

WARNING

Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.


IMPORTANT: Be careful not to damage the fins when cleaning.

- When using compressed air or pressurized water, make sure the pressure is no higher than 200 kPa (28 psi) and hold the nozzle sufficiently away from the fins.


IMPORTANT: When using water, cover the electrical system to prevent water from getting in.

IMPORTANT: When operating the machine in very dusty places, perform inspection and maintenance operations every day.

2. Remove the screws (1) and open the condenser.
3. Blow compressed air on the fins to remove mud and dirt stuck on them.



1. Open the engine hood.





CLEANING THE AIR FILTERS (AC)


WARNING

Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.


Clean the filters immediately after operating in dusty places.

If the filters are clogged, the air flow is reduced and a booming sound is heard from the air conditioner unit.

Removing the filters



1. Open the cab door.
 2. Pull out the filter case (1) upward and remove the ventilation filter (2) from the filter case (1).
- Ventilation filter (2): parts No. 19115-13680



3. Open the cover (3).
4. Remove the circulation filter (4).
5. Use compressed air or water to clean the filters, depending on how dirty they are.

Cleaning

1. Blow dry, compressed air (138 kPa or 20 psi or less) directly on the filters from the inside, moving up and down along the pleats.
Be sure to keep the nozzle at an adequate distance from the filters.
2. Wash the filter with neutral detergent if it is very dirty. Dry the filter completely after washing it.

Replacing

Replace the filter with a new one once a year or if it is still clogged after blow-drying with compressed air and washing.



CLEANING THE CONDENSER (AC)




WARNING

Wear required appropriate equipment such as protective goggle and filter mask when using compressed air, as metal fragments or other objects can fly and cause serious injury.

IMPORTANT: Be careful not to damage the fins when cleaning.

- When using compressed air or pressurized water, make sure the pressure is no higher than 200kPa (28 psi) and hold the nozzle sufficiently away from the fins.



1. Open the engine hood.
2. Clean the condenser (1).




INSPECTING THE REFRIGERANT (GAS) LEVEL (AC)

WARNING

- Exposure of the eyes or hands to the cooler's refrigerant could result in blindness or frostbite.
Never touch the refrigerant or loosen the parts of the cooling circuit.
- Keep flames away if the refrigerant gas is leaking.
- The high-pressure pipes of the air conditioner can be very hot (80 to 120°C or 176 to 248°F). Be careful not to burn yourself.

The cooling capacity decreases if the amount of refrigerant is insufficient. Inspect the refrigerant level using the sight glass (2) on the top of the receiver dryer (1).




1. Open the engine hood.
2. Inspect the places for the conditions below.

Places for inspection	Conditions
Cab door	Fully open
Temperature control dial	Set fully to the COOL side
Fan speed	High
Ventilation / Circulation select switch	Circulation
Engine speed	Maximum speed
Air conditioner switch	ON


3. Inspect the refrigerant by watching the flow of air bubbles through the sight glass (2).

Refer to "Check list for refrigerant volume" on page 5-45.

<Applicable machine models 185100001 or later>







<Applicable machine models 190200001 or later>



4. Check the temperature of the compressor's high pressure pipe (1) and low pressure pipe (2).
Refer to "Check list for refrigerant volume" on page 5-45.



Check list for refrigerant volume

Air conditioner	Normal	Abnormal		
High/low pressure pipe temperature	High pressure pipe is hot (80 to 120°C or 176 to 248°F), low pressure pipe is cold (8 to 15°C or 46 to 59°F). Clear difference in temperature between the pipes.	High pressure pipe is warm, low pressure pipe is slightly cool. No significant difference in temperature between the pipes.	Little difference in temperature between the high-pressure pipe and the low-pressure pipe.	High pressure pipe is hot, low pressure pipe is slightly cool. A significant difference in temperature between the pipes.
Pipe connection	Normal	Some places are dirty with oil.	Some places are extremely dirty with oil.	Normal
Sight glass	 AG7G064 Almost transparent with some bubbles. Fully transparent when the engine speed is increased or decreased.	 AG7G065 Flow of bubbles can be seen constantly. Sometimes transparent or white with bubbles.	 AG7G066 Mist-like flow is faintly visible.	 AG7G067 No bubbles is visible, even when the fan is set to High and the engine is idling.
Refrigerant level	Proper level	Refrigerant may be leaking.	Refrigerant has leaked; little is left.	Refrigerant level too high

If the air conditioner is not working

If the air conditioner does not work well, set the fan switch to OFF and contact your sales or service dealer for inspection and/or repairs.

IMPORTANT: Continued use of the air conditioner when it is not working properly will damage its various parts.

IMPORTANT: Using the air conditioner when there is no refrigerant will damage the compressor.

IMPORTANT: Always consult your sales or service dealer for replacing the refrigerant. Be sure to use R134a refrigerant (740 to 820 g or 1.63 to 1.81 lb.).




EVERY 500 HOURS

REPLACING THE FUEL FILTER

WARNING


- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.

<Applicable machine models 185100001 or later>




1. Open the engine hood.
2. Turn the filter (1) counterclockwise with the filter wrench and remove it.
3. Clean the surface of installation of the filter stand.
4. Apply a thin layer of oil on the packing of the new filter.
5. Install the new filter by hand.
6. Tighten one more turn after the filter packing comes in contact with the surface of installation. (Torque when tightening with filter wrench: 19.6 to 23.5 N·m or 14 to 17 ft·lb.)
7. Bleed the air.
Refer to "Bleeding air from the fuel system" on page 6-8.

<Applicable machine models 190200001 or later>



1. Open the side cover.


Pre-fuel filter



2. Place a pan under the pre-fuel filter (1) to catch fuel.
3. Loosen the vent plug (5) and the drain plug (6) to drain the fuel inside.
4. Remove the case (7) by using a filter wrench.
5. Replace the seals with new ones and lubricate the new seals with diesel fuel.
6. Put the new element (length of 150 mm / 5.9 in.) (4) in the case (7) and install by hand until the seal makes contact with the sealing surface.
7. Tighten the case (7) with the filter wrench.
Tightening torque: 30 N·m (22.1 ft·lb.)



Main fuel filter




8. Place a pan under the main fuel filter (2) to catch fuel.
9. Loosen the vent plug (5) and the drain plug (6) to drain the fuel inside.
10. Remove the case (7) by using a filter wrench.
11. Replace the seals with new ones and lubricate the new seals with diesel fuel.
12. Put the new element (length of 131 mm / 5.2 in.) (4) in the case (7) and install by hand until the seal makes contact with the sealing surface.
13. Tighten the case (7) with the filter wrench.
Tightening torque: 29.4 N·m (21.7 ft-lb.)
14. Bleed air.
Refer to "Bleeding air from the fuel system" on page 6-8.

REPLACING THE WATER SEPARATOR FILTER <APPLICABLE MACHINE MODELS 185100001 OR LATER>

WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.



(S): Close

1. Open the side cover.
2. Close the valve (2) of the water separator (1).
3. Place a pan for catching fuel under the drain hose.
4. Loose the air-bleeding plug (8) and the drain plug (7) to discharge fuel from inside.
5. Remove the sensor wiring coupler (3).
6. Remove the case (4) with the filter wrench.
7. Remove the element (5), and then clean the case. When doing the above, be careful not to damage the sensor.
8. Replace the packing with a new one and lubricate it with diesel fuel.
9. Install the new element (5) on the filter stand.
10. Tighten the case (4) by hand. Be sure to do it by hand.
Tightening torque: 27 to 33 N·m (20 to 24.6 ft-lb)
11. Install the sensor wiring coupler (3).
12. Tighten the drain plug (7).
13. Bleed air.
Refer to "Bleeding air from the fuel system" on page 6-8.




CLEANING THE FEED PUMP FILTER <APPLICABLE MACHINE MODELS 190200001 OR LATER>

WARNING


- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.

1. Open the side cover.




2. Place a pan under the feed pump (1) to catch fuel.
3. Remove the wiring from the cover (2).
4. Remove the cover (2) by turning it with a wrench.
5. Remove the filter (3) and the gasket (4).
 - Pinch the outer portion of the gasket, pull it out and remove it.
 - Do not disassemble the piston portion at the inner center of the pump.
6. Clean the filter and use compressed air of 294 to 490 kPa (43 to 71 psi) to blow off any dust.
7. Install the filter and the new gasket.
8. Securely install the cover (2) by using a wrench.
9. Bleed air.
Refer to "Bleeding air from the fuel system" on page 6-8.

INSPECTING THE SLEW PINION GEAR



1. Remove the floor mat (1).



2. Remove the cap (2).
3. Make sure that the gear tooth surface of the slew bearing is well greased.
If the surface is not adequately greased, add grease.
If the grease has turned white due to water or mud entered it, replace the whole grease. Consult your sales or service dealer for help.
Grease full capacity: 10 L (2.6 US gal) or 9.0 kg (20 lbs.)
4. Install the cap (2).
5. Install the floor mat (1).



INSPECTING AND CLEANING THE SUPPLY PUMP STRAINER <APPLICABLE MACHINE MODELS 190200001 OR LATER>




WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.
- Before performing maintenance on top of the work bench, clean the footing and observe the following precautions to prevent falling.
 - Do not spill oil or grease.
 - Do not leave tools scattered around.
 - Watch your step when walking.
- Never jump down from the machine or the work bench. When getting on or off the machine or work bench, use the steps, handrails or work bench to support your body. Your weight should be evenly distributed among the three contact points (one hand and two feet or two hands and one foot).
- Do not stand on the dozer blade and perform maintenance work. Doing so is dangerous because of the unsteady foothold. Use the work bench.

4. Check the strainer (2) inside the joint bolt (1), and clean it if it is dirty.
When cleaning, do not remove the strainer (2) from the joint bolt. (Disassembly prohibited)
If the dirt is persistent or the joint bolt is clogged, replace the joint bolt with the strainer in it.
5. Arrange the joint bolt (1), hose and the new packing (3) together, and then install them on their original positions.
 - Joint bolt (1) tightening torque: 14.6 to 24.6 N·m (11 to 18 ft·lb)
6. Bleed air.
Refer to “Bleeding air from the fuel system” on page 6-8.

Note: Replace the supply pump strainer (integrated with the joint bolt), if the “lowered output” or “engine stopping” cannot be corrected after replacing the fuel filter element. When replacing the strainer, replace the packing on both sides of the hose with the new one at the same time.



1. Open the engine hood.
2. Place a pan under the joint bolt (1) to catch fuel.
3. Loosen the joint bolt (1) and remove it.



EVERY 1000 HOURS

REPLACING THE HYDRAULIC OIL RETURN FILTER

Refer to “Replacing the hydraulic oil return filter” on page 5-34.

REPLACING THE PILOT LINE FILTER

Refer to “Replacing the pilot line filter” on page 5-35.

REPLACING THE TRAVEL MOTOR GEAR OIL

Refer to “Replacing the travel motor gear oil” on page 5-36.

CLEANING THE ENGINE COOLING SYSTEM <APPLICABLE MACHINE MODELS 190200001 OR LATER>



WARNING


- Stop the engine and allow the machine to cool down before performing maintenance.
 - The engine, muffler, radiator and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
 - The engine coolant is also hot and under high pressure immediately after the engine is stopped. Be careful when loosening the caps or plugs. Working on the machine under these conditions could result in burns or injuries due to the hot coolant spurting out.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
 - One person must sit in the operator's seat so that he/she can immediately


stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.

- The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.
- Standing at the back of the machine while the engine is running is extremely dangerous, as the machine could move suddenly. Never stand at the back of the machine while the engine is running.
- Do not remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine and wait until the engine and the cooling water cool. Then, slowly loosen the radiator cap and the drain plug to remove them.


When cleaning, if the temperature of the coolant is low, the thermostat will be closed and the coolant will not circulate in the radiator. Heat the coolant water to at least 90°C (194°F) before cleaning.

1. Open the engine hood and the side cover.





2. Gradually loosen the radiator cap (3) to release the internal pressure, and then remove the cap.



3. Place a pan for catching the waste coolant under the drain plug (4), and then loosen the drain plug (4) to drain the coolant.
4. Tighten the drain plug (4).
5. Add tap water to the radiator through the coolant fill port up to the top of the port. Take time and slowly add water, so that no air enters the radiator.
6. Close the radiator cap (3).
7. Start the engine and run it at a speed slightly above low idling. Raise the water temperature to at least 90°C (194°F), and then run the engine for about 10 minutes with the thermostat open.
8. Stop the engine, wait until the cooling water temperature becomes lower, and then remove the drain plug (4) to drain the water.
9. After draining, clean the cooling system using a cleaning agent. When using the cleaning agent, follow the instructions included with the agent.

10. Repeat the steps 4 to 8 to rinse the cooling system.
11. Tighten the drain plug (4).
12. Take time and slowly add the new coolant (mixture of antifreeze and tap water) to the radiator through the fill port until it is full.
13. Close the radiator cap (3).
14. Warm up the engine. Use the meters to check that there are no irregularities in the cooling system at this time.
15. Increase the water temperature to at least 90°C (194°F). Then, run the engine for about 10 minutes with the thermostat kept open.
16. Stop the engine, wait until the cooling water temperature becomes lower, and then check the level of coolant in the radiator.
If necessary, add cooling water until the radiator is full.
17. Close the radiator cap (3).
18. Clean the interior of the reserve tank (1), and then add coolant to the upper limit (H).
19. When the coolant has been replaced, inspect the coolant level once again after operating the machine.
Once the machine is operated, the coolant is distributed throughout the entire system, resulting in the lower coolant level.
Replenish the cooling water that has been used.



REPLACING THE AIR CLEANER ELEMENT



WARNING

Stop the engine and allow the machine to cool down before performing maintenance.


- The engine, muffler, radiator and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.

IMPORTANT: Do not use an element if its pleats, gaskets or seals are damaged.


IMPORTANT: Be sure to install the element and dust cap securely. If not, dust could be drain into the cylinder, damaging the engine.

7. Install the new elements. Press them firmly into the body (4).

8. Install the dust cup (2) with its "▲▲▲ OBEN/TOP" mark facing up, and then fasten it with the clamps (1).



1. Open the engine hood.



2. Loosen the clamps (1) and remove the dust cup (2).
3. Clean the inside of the dust cup (2).
4. Remove the primary element (3).
Do not remove the secondary element yet.
5. Clean the inside of the body (4).
6. Remove the secondary element (5).




REPLACING THE AIR BREATHER FILTER

WARNING

Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.

- Press the air breather button to relieve the tank pressure.



1. Open the side cover.
2. Press the button (K) to relieve the internal pressure from the tank.
3. Remove the nut (N) on the air breather.
4. Remove the cover (H).
5. Replace the filter (A).
6. Install the cover (H) on the body (B).
7. Install the nut (N).

INSPECTING AND ADJUSTING THE ENGINE VALVE CLEARANCE

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING THE ENGINE COMPRESSION PRESSURE <APPLICABLE MACHINE MODELS 190200001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING AND CLEANING THE ENGINE STARTER AND THE ALTERNATOR <APPLICABLE MACHINE MODELS 190200001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.



EVERY 1500 HOURS

INSPECTING THE CRANKCASE BREATHER SYSTEM <APPLICABLE MACHINE MODELS 185100001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING AND REPLACING THE AIR FILTER CASE FOR CRACKING <APPLICABLE MACHINE MODELS 190200001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING AND CLEANING THE EGR COOLER <APPLICABLE MACHINE MODELS 190200001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.



EVERY 2000 HOURS

CLEANING THE ENGINE COOLING SYSTEM <APPLICABLE MACHINE MODELS 185100001 OR LATER>

Replace the coolant after the two-year operation even if the running time is less than 2000 hours.

Refer to “Cleaning the engine cooling system <Applicable machine models 190200001 or later>” on page 5-50.



EVERY 3000 HOURS

INSPECTING THE TURBOCHARGER (BLOW WASH AS NECESSARY)

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING, CLEANING AND CHECKING OPERATION OF THE EGR VALVE <APPLICABLE MACHINE MODELS: 185100001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

CLEANING THE EGR LEAD VALVE <APPLICABLE MACHINE MODELS 185100001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

CLEANING THE EGR COOLER (CLEANING THE WATER SIDE AND EXHAUST AIR PASSAGE BLOWER) <APPLICABLE MACHINE MODELS 185100001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING THE OPERATION OF THE AIR INTAKE THROTTLE VALVE <APPLICABLE MACHINE MODELS 185100001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING AND CLEANING THE FUEL INJECTOR

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING AND CLEANING THE EGR VALVE <APPLICABLE MACHINE MODELS 190200001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.

INSPECTING THE ENGINE CONTROLLER (ECM) <APPLICABLE MACHINE MODELS 190200001 OR LATER>

This operation requires experience. Ask your sales or service dealer for it.



EVERY 4000 HOURS


REPLACING THE HYDRAULIC OIL AND CLEANING THE SUCTION STRAINER



WARNING


- Stop the engine and allow each part of the machine to cool down before performing maintenance.
 - The engine, the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
 - The hydraulic oil is also hot and under high pressure immediately after the engine is stopped. Be careful not to touch the oil when loosening the cap or plug. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Oil may spurt out if caps or filters are removed or pipes are disconnected before releasing the pressure in the hydraulic system.
 - Press the air breather button to relieve the internal pressure from the tank.
 - When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.

1. Slew 45° clockwise and set the machine to the hydraulic oil level inspection posture. Refer to "Inspecting the hydraulic oil tank level and replenishing" on page 5-24.
2. Open the side cover.



AM1G033

3. Press the button (2) to relieve the internal pressure from the tank.
4. Replace the air breather filter (A). Refer to "Replacing the air breather filter" on page 5-53.
5. Remove the plug (3).
6. Loosen the bolts and remove the flange (4).
7. Remove the return filter (5).
8. Place a pan under the plug (6) to catch the waste oil.
9. Remove the cap (B), install connector (C) and drain the oil. (The oil comes out when the screw is tightened.)




10. Remove the relay and fuse panel (9).
11. Loosen the bolts and remove the flange (7).
12. Remove the suction strainer (8) and clean it.
13. Clean the inside of the hydraulic oil tank.
14. Remove the connector (C) and install the cap (B).
15. Install the suction strainer (8) on the tank and then install the flange (7).
16. Install the new return filter (5) and the flange (4) on the tank.
17. Add hydraulic oil from the hole of plug (3) up to the level between the upper limit (H) and the lower limit (L) in the sight gauge (1).
18. Tighten the plug (3).
19. Install the relay and fuse panel (9).
20. Bleed air from the hydraulic oil circuit following "Bleeding air" below.
21. Set the machine to the hydraulic oil level inspection posture and inspect the oil level after the oil cools.
Refer to "Inspecting the hydraulic oil tank level and replenishing" on page 5-24.

Bleeding air


IMPORTANT: After replacing the hydraulic oil or hydraulic devices, or after performing maintenance of the hydraulic devices, bleed air from the hydraulic circuits and hydraulic devices. Failure to do so may damage the hydraulic devices.

• Hydraulic pump



1. Open the engine hood.
2. Loosen the drain hose (1) of the hydraulic pump.
3. Tighten the drain hose (1) once there are no more air bubbles coming from the elbow (2) joint.

• Slew motor



1. Loosen the air-bleeding plug (1).
2. Tighten the plug (1) once the hydraulic oil overflows from the air-bleeding plug hole (1).



• Cylinders

1. Start the engine, let it run at a low-idling speed for 10 minutes.
2. Maintain the engine at low idle, and then slowly extend and retract each cylinder 4 or 5 times, without letting them reach the stroke end.
3. While running the engine at high speed, slowly extend and retract each cylinder 4 or 5 times, without letting them reach the stroke end.
4. Return the engine speed to low idle, and then slowly extend and retract each cylinder 4 or 5 times to the stroke end.

• Emergency shut-off valve

This operation is dangerous and requires experience. Ask your sales or service dealer for help.

If air is not released, the working equipment could become slow in reacting to the operation of the operator and show unexpected behavior.




WARNING


When removing plugs or screws, or when disconnecting hoses, stand to the side and loosen them slowly to gradually release the internal pressure before removing.

1. Place a pan under the hose (A) or (B) to catch the waste oil.
2. Start the engine and run it at low idle.
3. Fully lower the safety lock lever to the unlock position.

Mono boom




2-Piece boom



4. Hold the hose fitting (A) in place with a wrench and slowly loosen the hose nut (1).
5. Slowly move the boom in the "Boom lower" direction a little until there are no more air bubbles coming from the hose nut (1) joint.
6. Hold the hose fitting (A) in place with a wrench and tighten the hose nut (1).


Second boom






Arm

<Mono boom>



<2-Piece boom>



4. Loosen the hose (B) slowly.
5. Slowly move the arm in the "Arm in" direction a little until there are no more air bubbles coming from the hose (B) joint.
6. Tighten the hose (B).



WHEN REQUIRED

REPLACING THE BUCKET TEETH AND THE SIDE CUTTERS


Replace the bucket teeth if the tooth points are worn. Do not wait until the bucket is damaged.

WARNING

- Before performing maintenance or repairs under the machine, lower all moveable working equipment to the ground or in the lowermost position.
- To prevent unexpected movement, firmly secure the working equipment when repairing or replacing the bucket teeth or side cutter.
- When using a hammer, pins may fly out or metal particles may be scattered. This may lead to serious injury.
 - If hard metal parts such as pins, bucket teeth, side cutter or bearings are hit with a hammer, wear protective gear such as safety goggles and gloves.
 - When hitting pins or bucket teeth, always check that there is no one in the surrounding area.
- Do not allow unauthorized personnel in the work area while working.


Removing

1. Clean the bucket and park the machine on a flat and rigid ground.



2. Place the bucket with its bottom flat on the blocks so that the locking pin can be knocked out.


3. Remove the key, and then check that the bucket is stable.



4. Knock out the locking pin (1) and remove the point (2).

Note: If the drift is set against rubber pin lock (3) when it is hit, the rubber pin lock may break. Set it against the back of the locking pin.

5. Remove the rubber pin lock (3). Check if the rubber pin lock is still usable. Replace it if it is as follows.




AThere are cracks in the rubber and the roller is coming off.


BThe roller is dented when pressed with a finger.




Installation



1. Remove the dirt on the surface of adaptor and the inner part of tooth, make the better contact on the mating part.
2. Push rubber pin lock (3) into the welding adaptor (4).
Do not let the rubber pin lock stick out from the welding adaptor surface.




3. Install the point (2) onto the welding adaptor (4).
Insert the point so that the surface behind the point's pin hole is aligned with the surface behind the welding adapter's pin hole.



4. Knock out the locking pin (1).
Check that the end surfaces of the locking pin just knocked out are aligned with the upper and lower surface of the point. Do not use the worn locking pin.
The life of the teeth can be lengthened and the frequency of its replacement can be reduced by turning it upside down so that it will wear evenly.
Replace the rubber pin lock and locking pin at the same time as replacing the teeth. This makes it possible to prevent the teeth from falling out

• Side cutter Installation



1. Insert the bolts from the inner of the bucket and tighten the side cutter with nuts.
Tightening torque: 475 N·m (350 ft·lb.)
2. Caulk the bolts with a punch at three spots along the periphery of the screw to prevent the nuts from coming loose.




REPLACING THE BUCKET

WARNING

- Before performing maintenance or repairs under the machine, lower all working equipment to the ground or in the lowermost position.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
 - One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
 - The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.
- When using a hammer, pins may fly out or metal particles may be scattered. This may lead to serious injury.
 - If hard metal parts such as pins, bucket teeth, side cutter or bearings are hit with a hammer, wear protective gear such as safety goggles and gloves.
 - When hitting pins or bucket teeth, always check that there is no one in the surrounding area.
- When aligning the pin holes, always do so by checking them visually. Do not insert your finger in the pin hole, or you could lose your finger.


Removing



1. Lower the bucket to the ground as shown on the figure above in a stable position.

Note: When removing pins, set the bucket so that it is barely touching the ground. If the bucket is firmly touching the ground, the resistance will be great and it will be difficult to remove the pin.


2. Set the safety lock lever to the locked position and stop the engine.




3. Remove the bolt (1).
4. Hammer the pin (2) out of the bucket.
5. Remove the bucket.
Inspect the pin seal (3) and replace it if it is deformed or damaged. (See next page.)




Installation




1. Set the O-ring (4) on the bucket as shown on the figure above.



2. Align the pin hole (A) on the bucket with the pin hole on the arm (5), and install the pin (2).
3. Operate the cylinder, align the pin hole (B) on the bucket with the pin hole on the link arm (6), and install the pin (2).



4. Align the turn prevention holes, and then install the bolt (1) and the nut. Be sure to leave a gap of about 0.5 to 1 mm (0.02 to 0.04 in.) between the nut and bucket bush, or the nut will come loose.




5. Adjust the gap between the bucket and the arm.

Refer to "Adjusting the gap between the bucket and arm (If equipped)" on page 5-66.

6. Slide the O-ring (4).

Replacing the pin seal




1. Set the pin seal (3) in the direction shown on the figure above.
2. Use a mallet to slowly press the pin seal in. Be careful not to damage the seal.




ADJUSTING THE GAP BETWEEN THE BUCKET AND ARM (IF EQUIPPED)

WARNING


- Before performing maintenance or repairs under the machine, lower all working equipment to the ground or in the lowermost position.
- To prevent unexpected movement, securely block the working equipment when adjusting the gap.




1. Lower the bucket to the ground as shown on the figure above in a stable position.
2. Check that the bucket does not move, and then set the safety lock lever to the locked position and stop the engine.



3. Move the O-ring (1) to bring the gap (A) into view and measure the width of the gap (A).
The gap (A) should be 0.5 mm (0.02 in.). Swing the upperstructure slightly to the left and lightly press the arm point to the left side of the bucket (the side without an adjuster).



4. Remove the three bolts (2), the end plate (3) and flange (4).



5. Pull out the adjustment shim(s) (5) corresponding to the gap (A) from between the flange (4) and the bucket body.
Adjustment shim thickness : 0.5 mm (0.02 in.)
Be careful that the gap is no less than 0.5 mm (0.02 in.) after adjustment.

Note:

Example (for a gap of 2 mm or 0.08 in.):
2 mm - 0.5 mm (standard value) = 1.5 mm (0.06 in.)

In the above example, three shims (5) should be removed.

6. Insert the adjustment shim(s) (5) removed in step 5 above between the end plate (3) and the flange (4), and then fasten it in place with the three bolts (2).
 - Tightening torque for bolts (2): 83 N·m (61.5 ft·lb.)
7. Return the O-ring (1) to the original position.




INSPECTING AND REPLENISHING THE WINDSHIELD WASHER FLUID

WARNING

Choose ethyl alcohol as washer solution. Do not use methyl alcohol as washer solution. It could damage the eyes.

Use a windshield washer fluid designed specifically for motor vehicles. Follow the instructions included with the washer fluid.



Inspection

1. Open the side cover.
2. Inspect the washer tank (1) and add washer fluid if the level is low.

Replenishing

1. Mix the washer fluid to the prescribed concentration.
2. Remove the cap (2) and add washer fluid. Keep the dust away while replenishing the washer fluid.
3. Install the cap (2).

INSPECTING AND CLEANING THE DPF SOOT FILTER <APPLICABLE MACHINE MODELS: 185100001 OR LATER>

For the inspection and maintenance of the DPF soot filter or oxidation catalyst, follow the procedure below.

This operation requires experience. Ask your sales or service dealer for it.

- Do not modify the DPF without permission. If modified, it may be damaged or malfunction may occur. As a result, an expensive repair work may be required.
- Do not reuse the DPF that has been dropped to the ground. There is catalyst fitted inside the DPF. It can be damaged if strong shocks are applied to it.

- Soot filter

Cleaning:

The soot filter must be cleaned if any of the error codes listed below appears. When cleaning becomes necessary, the ECM error warning lamp or the vehicle and engine emergency lamp starts flashing and an alarm is sounded.

Display the engine error code screen to check the SPN and FMI numbers.

Error code		Classifica- tion	Description
SPN	FMI		
3719	7	Warning	DPF recovery regeneration inhibit
3719	9	Warning	DPF recovery regeneration failure
3720	0	Warning	DPF ash cleaning request 2
3720	16	Caution	DPF ash cleaning request 1
522573	0	Caution	DPF over accumulation
522574	0	Caution	DPF over accumulation

Replacement:

Replace every 9000 hours.

- Oxidation catalyst

Replacement:


Replace every 9000 hours.



DRAINING THE WATER FROM THE WATER SEPARATOR <APPLICABLE MACHINE MODELS 185100001 OR LATER>

WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.



1. Open the side cover.
2. Place a pan under the drain valve (7) to catch fuel.
3. Open the drain valve (7) and drain the water.
If the water does not drain easily, loosen the plug (8).
4. Close the drain valve (7) and tighten the plug (8).
Refer to "Bleeding air from the fuel system" on page 6-8.




DRAINING THE WATER FROM THE WATER SEPARATOR <APPLICABLE MACHINE MODELS 190200001 OR LATER>



WARNING

- Do not smoke or permit open flames while handling fuel or working on the fuel system.
- Stop the engine in a well-ventilated place and allow it to cool down before performing maintenance.
- Clean up spilled fuel immediately.



1. Open the side cover.
2. Place a pan under the drain valve (1) to catch fuel.
3. Open the drain valve (1) and drain the water.
If the water does not drain easily, loosen the plug (2).
4. Close the drain valve (1) and tighten the plug (2).
Refer to "Bleeding air from the fuel system" on page 6-8.




LUBRICATING THE LEVERS AND PEDALS

WARNING


Set the machine to the parking posture, stop the engine, remove the starter key and store it. Failure to do so may result in the machine moving abruptly, leading to serious injury or death.

If the levers or pedals no longer move smoothly, grease them.


Operating levers




Travel levers/pedals



Boom swing pedal



Dozer blade lever



1. Remove the lower mount section of the boot (1) and turn it upward.
2. Wipe off the old grease.
3. Apply grease to points (A) and (B).
4. Set the boot (1) back as it was.




INSPECTING THE RUBBER CRAWLERS

Repair or replace the rubber crawlers if their condition becomes as described below. Consult your sales or service dealer for repair or replacement.

Rubber crawler


Replace the crawler if the entire crawler is stretched and cannot be adjusted.

(1) Lug



Replace if the height of (A) is 5 mm (0.2 in.) or below.


(2) Steel cord



Replace if the steel cord is exposed for two links or more.


Replace if the half or more of the steel cords on one side are cut.

(3) Metal core



Replace if even one metal core is off.

(4) Rubber



Repair if there are cracks of 60 mm (2.4 in.) or greater in length.

If the steel cord is visible, repair as soon as possible, regardless of the length of the crack.



REPLACING THE RUBBER CRAWLERS

WARNING


- If you must work beneath the raised machine or working equipment, always use wood blocks, jack-stands or other rigid and stable supports. Never get under the machine or working equipment if they are not sufficiently supported.
- If maintenance must be performed with the engine running, always work as a two person team communicating each other.
 - One person must sit in the operator's seat so that he/she can immediately stop the engine when necessary. He/she must take care not to touch the lever or pedal unless necessary.
 - The one who performs maintenance must make sure to keep his/her body or clothing away from the moving part of the machine.

IMPORTANT: When replacing the crawler belts, replace the right and left belts at the same time.


IMPORTANT: When the travel speed button is set to the 2nd speed side while the engine is running, the tensioning cylinder rods extend and the crawler belt tension is increased. Keep the engine at the 1st speed when replacing. Do not set to the 2nd unless for increasing tension.

Note: This machine uses a hydraulic cylinder to adjust the tension of the crawler belts. It is not necessary to regularly perform adjustments of the crawler belt tension.


Removal



1. Start the engine and raise the machine body with the hoe attachment and the dozer blade.
2. Stop the engine.




3. Remove the valve cover (1) at the center of one of the crawler frames.
4. Turn the plug (2) counterclockwise and remove it.
5. Turn the stem (3) counterclockwise with a hex wrench to completely loosen the tension of the crawler.
6. Once the crawler belt is completely loose, tighten the stem (3) until it is firm.
 - Tightening torque: 18.6 to 21.6 N·m (13.7 to 15.9 ft-lb.)
7. Tighten the plug (2).
 - Tightening torque: 18.6 to 21.6 N·m (13.7 to 15.9 ft-lb.)
8. Do the same for the other side.




9. Slowly lower the dozer blade side of the machine body. (Do not start the engine.)
10. Lower the machine body until the crawlers contact the ground with the maximum slack.
11. When the crawlers are disengaged from the idlers, slide the crawlers to the outside and remove them.
12. Remove the crawlers from the sprockets, and then remove the crawlers from the crawler frames.

Installation


1. Engage the crawlers around the left and right sprockets.
2. Set the left and right crawlers on the idlers.
3. Start the engine.
4. Press the travel speed button once to set it to the 2nd speed side. The left and right crawler belts are tightened simultaneously.



5. Check that the crawler belts are properly tightened.



6. For rubber crawlers, move the machine so that the "M", "J" or "∞" mark at the joint is at the top center of the crawler frame.



7. Inspect the gap (A or B) between the bottom surface of the frame at the center of the crawler frame and the top surface of the crawler.
The gap (A or B) must be within the following range:

- (A).....Rubber crawler
160 to 180 mm (6.3 to 7.1 in.)
- (B).....Steel crawler
270 to 290 mm (10.6 to 11.4 in.)
- (B).....Segmental rubber crawler
257 to 277 mm (10.1 to 10.9 in.)

Note: When the self-adjusting shoe tension system is properly working, the shoe should have the gap (A or B) as described above, at the time of installation.

When the machine is lowered and driven in 2nd speed, the crawler belts will be stretched to the correct tension. The values of shoe tension (gap values) after the 2nd speed travel are different from those described above.



EVERY 2 YEARS

REPLACING THE RECEIVER DRYER

This operation requires experience. Ask your sales or service dealer for it.



MAINTENANCE DURING EXTENDED STORAGE PERIOD

Storage procedures

If the machine is to be stored for 30 days or more, store it indoors. If it must be stored outdoors, park the machine on a surface laid with lumber on a flat ground, and place a waterproof cover over it so that it stays dry.

1. Clean the machine.
2. Inspect for oil leakage, water leakage, cracks and loose nuts and bolts.
3. Add fuel and replace the hydraulic oil and oil.
4. To prevent rusting and freezing, replace the engine coolant with long-life coolant (LLC).
Refer to "Cleaning the engine cooling system" on page 5-50 or page 5-55.
5. Use the grease gun to lubricate the grease fittings.
6. Fully retract the bucket and arm cylinders and lower the bucket and dozer blade to the ground.
7. Apply rust-inhibiting oil to the hydraulic cylinder rods.
8. Disconnect the negative cable from the battery and cover the battery to prevent freezing.

During storage



WARNING

- **Do not operate the machine in an enclosed area without adequate ventilation.**
- **If natural ventilation is not possible, install ventilators, fans, exhaust extension pipes or other venting devices.**

1. To prevent rusting, operate the machine once a month so that the oil can be circulated throughout the system.
2. Inspect the battery and recharge it as necessary.
Ask your sales or service dealer for recharging.

Starting the machine after storage

IMPORTANT: If the above "Storage procedures" have not been followed during the extended storage periods, **consult your sales or service dealer before starting the machine again.**

1. Wipe off the rust-inhibiting oil that was applied on the piston rods of the hydraulic oil cylinders.
2. Add oil or grease as necessary.

Returning the engine to service


1. Perform the daily checks.
2. The engine should be pre-oiled before startup.
 - a. Crank the engine, leaving the fuel system shut off so the engine will not start, for 15 seconds.
 - b. Then pause for 30 seconds.
 - c. Repeat the procedure until you have cranked the engine for a total of one minute. This will circulate the oil in the engine's lubrication system.
3. Prime the fuel system.
4. Start the engine. Allow the engine to idle for approximately 15 minutes while you check for:
 - Proper oil pressure
 - Fuel, engine oil or coolant leaks
 - Proper operation of the indicators and/or gauges
5. Avoid prolonged operation at minimum or maximum engine speeds and loads for the remainder of the first hour of operation.

TROUBLESHOOTING




SYMPTOMS THAT ARE NOT MALFUNCTIONS

The symptoms listed below are not malfunctions.



AG7J002

- The arm retracting speed momentarily slows down when it reaches an almost vertical position while the engine is running at low speed.



AG7J003

- The bucket teeth moving speed momentarily slows down when it reaches an almost horizontal position while the engine is running at low speed.
- The slew motor produces noise at the beginning and end of the slewing.
- The travel motor produces noise when stopped suddenly from its high speed traveling.
- The control valve produces noise if excessive force is applied to the working equipment or when it moved to the stroke end.

- It becomes less easy to operate the machine when an attachment weighing more than a standard arm or bucket is installed.

Applicable machine models 185100001 or later

- In some cases smoke may be emitted from the tail pipe while the DPF regeneration is being performed. This is not a failure; it is due to burning of the particulate matter (PM).
- In some cases the noise associated with the DPF regeneration operation or cancel operation may change; this is not a failure.




IF THE ENGINE OVERHEATS

WARNING

- Do not open the engine hood when steam is coming from it. The steam or hot water may spurt out and cause burns.
- Do not try to remove the radiator cap or the drain plug when the cooling water is hot. Stop the engine, wait until the engine and the radiator cool, and then slowly loosen the radiator cap to release the internal pressure.
- Before performing maintenance, stop the engine and allow the machine to cool down.

The symptoms listed below indicate overheating.



- An alarm is sounded and the engine emergency lamp and the coolant temperature warning lamp start flashing.
- The water temperature gauge level is in the red zone.
- Steam comes from the engine room.

Remedy procedure

1. Park the machine in a safe place.
2. Check if steam is coming out of the closed engine hood.
3. If there is steam, stop the engine immediately and contact your sales or service dealer for repair. If steam is not coming out run the engine at low idle and let the water temperature cool down.
4. When the water temperature gauge level drops in the green zone, stop the engine.
5. Perform the inspections and the remedies listed below once the engine cools down.
 - Fan belt slack..... Adjust
Refer to page 5-26.
 - Coolant level Add
Refer to page 5-20.
 - Water leakage..... Repair
 - Radiator fins..... Clean
Refer to page 5-41.
 - Sediment in cooling system
..... Clean
Refer to page 5-50
or page 5-55.

If the problem persists after the above remedies, contact your sales or service dealer for repair.



IF THE BATTERY GOES DEAD

The symptoms below indicate that the battery is dead.

- The starter motor does not turn or fails to start the engine.
- The horn is too weak.

Remedy procedure

Start the engine using the booster battery on the other vehicle (booster vehicle) and the jumper cables.



WARNING

- When starting the engine using the jumper cables, be sure to connect the cables by following the proper steps. Improper use of jumper cables can result in battery explosion or unexpected machine motion.
 - Do not allow the booster vehicle and the machine with a dead battery (dead machine) to touch each other.
 - Do not allow the positive (+) and the negative (-) clips of the jumper cables to touch each other.
 - When connecting, attach the jumper cable to the positive (+) terminals first. When disconnecting, remove the cable from the negative (-) terminal (ground) first.
 - Connect the last clip of the jumper cable to a point as far away from the battery as possible.
- Always wear the protective goggle when jump starting the engine by using the jumper cables.


IMPORTANT: Use the jumper cables and clips of a size suited to the capacity of battery. Do not use damaged or corroded jumper cables and clips.

IMPORTANT: Be sure that the battery of the booster vehicle has the same capacity as the battery of the dead machine.

IMPORTANT: Be sure to connect the clips securely.

Connecting the jumper cables

IMPORTANT: Set the starter keys of the booster vehicle and the dead machine to the OFF position.



1. Connect the clip of jumper cable (R) to the positive (+) battery terminal of the dead machine.
2. Connect the other clip of jumper cable (R) to the positive (+) battery terminal of the booster vehicle.
3. Connect the clip of jumper cable (B) to the negative (-) battery terminal of the booster vehicle.
4. Connect the other clip of jumper cable (B) to the engine block of the dead machine. Connect the clip to a place as far from the battery as possible.

Starting the engine


1. Check that the clips are securely connected to the terminals.
2. Start the engine of the booster vehicle and run it at high speed.
3. Start the engine of the dead machine.



TROUBLESHOOTING IF THE BATTERY GOES DEAD

Disconnecting the jumper cables

Once the dead machine is successfully running, remove the jumper cables by following the same steps as for connection in the reverse order.



1. Disconnect the clip of jumper cable (B) from the engine block of the dead machine.
2. Disconnect the other clip of jumper cable (B) from the negative (-) battery terminal of the booster vehicle.
3. Disconnect the clip of jumper cable (R) from the positive (+) battery terminal of the booster vehicle.
4. Disconnect the clip of jumper cable (R) from the positive (+) battery terminal of the dead machine.

Recharging

Ask your sales or service dealer for recharging the dead battery.



IF A FUSE BLOWS


If a light does not come on or the electrical system does not work, a fuse may be blown. Inspect the fuses.

INSPECTING AND REPLACING THE FUSE


WARNING

If the fuse blows again soon after replacement, then the electric system is likely faulty. It may pose a fire hazard if not properly repaired. Contact your sales or service dealer for advice.

1. Turn the starter key to the OFF position to stop the engine.



2. Open the fuse box cover (1).
3. Check for any blown fuses (2).



4. If a fuse is blown, replace it with a spare fuse of the same capacity.

Fuse layout and circuits protected

Capacity	Symbol	Protected circuit
25A		Light
10A		Wiper
20A		Lever lock
15A	CTL 	Controller power supply
20A	CTL (OX) 	OX controller power supply
25A	CAB 	Cab interior power supply
25A	OPT(1)	Option (1)
20A	OPT(2)	Option (2)
10A		Air conditioner compressor
5A		AC motor
10A		Immobilizer
25A		Air conditioner blower motor

Capacity	Symbol	Protected circuit
25A	CAB 	Cab light
5A		Switch lighting
10A		Horn
5A* 10A** 15A***		Starter switch


*: Applicable machine models 185100001 to 185104995

** : Applicable machine models 185104996 or later

***: Applicable machine models 190200001 or later



INSPECTING THE FUSIBLE LINK



If the machine is not turned on after turning the starter switch to the ON position, the cartridge type fusible links (1) is likely blown. Open the side cover and inspect it. If the fusible link is blown, contact your sales or service dealer.

Note: Fusible links are large type fuses used in high current applications. Like a regular fuse, they act as fuses by protecting the electric components and wirings from damage caused by excessive current draw.




RESTARTING AFTER ADDING FUEL

BLEEDING AIR FROM THE FUEL SYSTEM


IMPORTANT: NEVER use the starter motor to crank the engine in order to prime the fuel system. This may cause the starter motor to overheat and damage the coils, pinion gear and/or ring gear.

IMPORTANT: If the engine stalls due to fuel shortage, add fuel, turn the key to the ON position for 60 seconds, and then turn it to the START position. Running the starter for a long time before there is enough fuel is going through can cause the starter to fail.




1. Add fuel.

<Applicable machine models 185100001 or later>




2. Turn the starter key to the ON position and hold it for about 60 seconds.
The automatic air bleeder bleeds air from the fuel system.

<Applicable machine models 190200001 or later>



2. Loosen the vent plug (5) of the main fuel filter (2).



3. Turn the starter key to the ON position and wait for the air to be bled from the vent plug (5).
4. Retighten the vent plug (5) when air bleeding is finished and fuel starts leaking out from around the vent plug (5).
5. Turn and hold the starter key to the ON position for three minutes before turning it back to the OFF position.

Note: Air in the fuel system causes the engine to fail to start or to have other problems. Always bleed air when the fuel tank is emptied or when there is air in the fuel system.



IF A WARNING LAMP FLASHES

If an alarm is sounded or a warning lamp starts flashing during operation, park the machine in a safe place and perform the remedy procedures described below.

Warning lamp	Lamp name	Causes and remedies
 AW4J007	Vehicle and engine emergency lamp	There is a problem in the machine. Refer to the respective warning lamp below. Get the vehicle or engine error code number from the multi-information display and consult your sales or service dealer referring to the “Vehicle error code list” or “Engine error code list”. Refer to “Multi-information display” on pages 2-16 to 2-38. Refer to “Vehicle error code list” on pages 6-12 to 6-13. Refer to “Engine error code list” on pages 6-14 to 6-24.
 AW4J0041	ECM error warning lamp	There is a problem in the engine. If an error code is displayed on the multi-information display, inform your sales or service dealer of the code and ask for help. Refer to “Multi-information display” on pages 2-16 to 2-38. Refer to “Engine error code list” on pages 6-14 to 6-24.
 AG7J019	Battery charge warning lamp	There is a problem with the fan belt or charger. Check the fan belt for slack or breakage and adjust as necessary. If the lamp continues flashing after maintenance, there is likely a problem with the charger. Consult your sales or service dealer for help. Refer to “Inspecting and adjusting the fan belt” on page 5-26.
 AG7J017	Engine oil pressure warning lamp	There is a problem in the engine lubrication system. Check the engine oil level. If the lamp is flashing when the level is normal or even after replenishment of oil or coolant, consult your sales or service dealer. Refer to “Inspecting and replenishing the engine oil” on page 5-21.
 AW4J009	Water separator warning lamp	Water is in the water separator. Drain water. Refer to “Draining the water from the water separator” on pages 5-68 to 5-69.



TROUBLESHOOTING IF A WARNING LAMP FLASHES

Warning lamp	Lamp name	Causes and remedies
 AG7J018	Coolant temperature warning lamp	The coolant temperature is too high and the engine is overheating. Refer to “If the engine overheats” on page 6-3.
 AG7J020	Air cleaner warning lamp	The air cleaner is clogged. Clean it. Refer to “Cleaning the air cleaner” on page 5-40.
 AQ0J008	Fuel filter warning lamp	The fuel filter is clogged. Replace the fuel filter. Refer to “Replacing the fuel filter” on page 5-46.
 AK8J004	NCD warning lamp NCD: NOx Control Diagnostic system	A problem is detected in the exhaust system. Get the engine error code number from the multi-information display and consult your sales or service dealer referring to the “Engine error code list”. Refer to “Multi-information display” on page 2-16. Refer to “Engine error code list” on page 6-14.
 AW4J010	Fuel level warning lamp	The fuel level is too low. Add fuel. Refer to “Inspecting the fuel level” on page 5-23.
 AQ0J004	Third auxiliary hydraulic warning lamp	Pressure in the third auxiliary hydraulic line is too low Consult your sales or service dealer for help.
 AM1J005	Lift overload warning indicator lamp	This lamp starts flashing if the overload warning device is activated. If it occurs, reduce the load to be lifted. Refer to “Lift overload warning switch” on page 2-47.



VEHICLE ERROR CODE LIST

If an error code appears on the display, consult your sales or service dealer.

Error code	Error details
9	Impossible to sense ACC key
19	Parameter version mismatching
402	CAN 0 communication error
502	CAN communication error (EECU)
602	CAN communication error (cluster gauge)
612	CAN communication error (OX024)
822	CAN communication error (TAKEUCHI Security System)
1703	Main power supply voltage error (too high)
1704	Main power supply voltage error (too low)
1713	OX024 power supply voltage error (too high)
1714	OX024 power supply voltage error (too low)
2503	Sensor voltage error (too high) MMC
2504	Sensor voltage error (too low) MMC
3300	Alternator charge faulty
3350	Fuel filter clogged (phase 1) <Applicable machine models 190200001 or later>
3359	Fuel filter clogged (phase 2) <Applicable machine models 190200001 or later>
3401	Engine oil pressure error
3500	Overheat
3600	Air cleaner clogged
3700	Water separator alarm
5303	Accelerator sensor error (too high)
5304	Accelerator sensor error (too low)
5505	Fuel gauge resistance value error (cable break)
5603	Lift alarm sensor error (too high)
5604	Lift alarm sensor error (too low)



TROUBLESHOOTING VEHICLE ERROR CODE LIST

Error code	Error details
6503	AUX1 slide switch voltage value error (too high)
6504	AUX1 slide switch voltage value error (too low)
6509	AUX1 slide switch neutral error
6519	AUX1 (L) switch error
6529	AUX1 (R) switch error
6603	AUX2 slide switch voltage value error (too high)
6604	AUX2 slide switch voltage value error (too low)
6609	AUX2 slide switch neutral error
6709	AUX3 switch error (Foot)
6719	AUX3 switch error (Grip)
8005	Pump PWM output voltage error (too low)
8006	Pump PWM output voltage error (too high)
8015	AUX1 (L) PWM output voltage error (too low)
8016	AUX1 (L) PWM output voltage error (too high)
8025	AUX1 (R) PWM output voltage error (too low)
8026	AUX1 (R) PWM output voltage error (too high)
8035	AUX2 (L) PWM output voltage error (too low)
8036	AUX2 (L) PWM output voltage error (too high)
8045	AUX2 (R) PWM output voltage error (too low)
8046	AUX2 (R) PWM output voltage error (too high)

PWM = Pulse width modulation



ENGINE ERROR CODE LIST

If an error code appears on the display, consult your sales or service dealer.

<Applicable machine models 185100001 or later>

Error code		Error details	DTC
SPN	FMI		
522400	2	Crank speed sensor (Crank signal malfunction)	P0336
	5	Crank speed sensor (No crank signal)	P0337
522401	2	Cam speed sensor (Cam signal malfunction)	P0341
	5	Cam speed sensor (No cam signal)	P0342
	7	Cam speed sensor (Angle offset failure)	P1341
523249	5	No signal on both crank and cam speed sensor	P0008
91	3	Accelerator sensor 1 (Excessive sensor output)	P0123
	4	Accelerator sensor 1 (Insufficient sensor output)	P0122
28	3	Accelerator sensor 2 (Excessive sensor output)	P0223
	4	Accelerator sensor 2 (Insufficient sensor output)	P0222
522624	7	Dual accelerator sensor (closed position) failure	P1646
522623	7	Dual accelerator sensor (open position) failure	P1647
29	3	Accelerator sensor 3 (Excessive sensor output)	P0228
	4	Accelerator sensor 3 (Insufficient sensor output)	P0227
	8	Pulse sensor failure (Pulse communication)	P1227
28	0	Accelerator sensor 3 failure (Foot pedal in open positon)	P1126
	1	Accelerator sensor 3 failure (Foot pedal in closed positon)	P1125
51	3	Intake throttle opening sensor fault (High voltage)	P02E9
	4	Intake throttle opening sensor fault (Low voltage)	P02E8



Error code		Error details	DTC
SPN	FMI		
102	3	EGR low pressure side sensor fault (High voltage)	P0238
	4	EGR low pressure side sensor fault (Low voltage)	P0237
	13	EGR low pressure side sensor fault (Abnormal learning value)	P0236
	10	Detected value error (EGR low pressure side pressure sensor)	P1673
1209	3	EGR high pressure side sensor fault (High voltage)	P0473
	4	EGR high pressure side sensor fault (Low voltage)	P0472
	13	EGR high pressure side sensor (Abnormal learning value)	P0471
	10	Detected value error (EGR high pressure side pressure sensor)	P1679
110	3	Cooling water temperature sensor fault (High voltage)	P0118
	4	Cooling water temperature sensor fault (Low voltage)	P0117
	0	Cooling water temperature sensor temperature abnormal high (Overheat)	P0217
	10	Detected value error (Engine coolant temperature sensor)	P1674
172	3	New air temperature sensor fault (High voltage)	P0113
	4	New air temperature sensor fault (Low voltage)	P0112
174	3	Fuel temperature sensor fault (High voltage)	P0183
	4	Fuel temperature sensor fault (Low voltage)	P0182
	0	Fuel temperature sensor temperature abnormal high	P0168
157	3	Rail pressure sensor fault (High voltage)	P0193
	4	Rail pressure sensor fault (Low voltage)	P0192
3251	3	DPF differential pressure sensor fault (High voltage)	P2455
	4	DPF differential pressure sensor fault (Low voltage)	P2454
	0	DPF differential pressure sensor differential pressure abnormal high	P2452
	13	DPF differential pressure sensor (Abnormal learning value)	P2453
3609	3	DPF high pressure side sensor fault (High voltage)	P1455
	4	DPF high pressure side sensor fault (Low voltage)	P1454
	10	Detected value error (DPF high pressure side pressure sensor)	P167C
4795	31	Removal of DPF substrate (empty-can)	P226D
3242	3	DPF inlet temperature sensor fault (High voltage)	P1428
	4	DPF inlet temperature sensor fault (Low voltage)	P1427
	0	DPF inlet temperature sensor temperature abnormal high	P1436
	10	Detected value error (DPF Inlet temperature sensor)	P167E



TROUBLESHOOTING ENGINE ERROR CODE LIST

Error code		Error details	DTC
SPN	FMI		
3250	3	DPF intermediate temperature sensor fault (High voltage)	P1434
	4	DPF intermediate temperature sensor fault (Low voltage)	P1435
	1	DPF intermediate temperature sensor temperature abnormal low temperature	P0420
	0	DPF intermediate temperature sensor temperature abnormal high (Post-injection failure)	P1426
	10	Detected value error (DPF Inside temperature sensor)	P167A
108	3	Atmospheric pressure sensor fault (High voltage)	P2229
	4	Atmospheric pressure sensor fault (Low voltage)	P2228
	10	Atmospheric pressure sensor characteristic fault	P1231
412	3	EGR gas temperature sensor fault (High voltage)	P041D
	4	EGR gas temperature sensor fault (Low voltage)	P041C
	10	Detected value error (EGR gas temperature sensor)	P1675
105	3	Intake manifold temperature sensor fault (High voltage)	P040D
	4	Intake manifold temperature sensor fault (Low voltage)	P040C
	10	Detected value error (Intake manifold temperature sensor)	P1676
173	3	Exhaust manifold temperature sensor fault (High voltage)	P0546
	4	Exhaust manifold temperature sensor fault (Low voltage)	P0545
	10	Detected value error (Exhaust manifold temperature sensor)	P1677
1485	7	Main relay contact stuck	P068B
	2	Main relay early opening	P068A
522243	5	Startup assist relay interrupted	P0543
	6	Startup assist relay GND interrupted	P0541
651 (4TNV), 652 (3TNV)	5	Injector 1 open circuit (Inherent location of the injector)	P0204 (4TNV), P0203 (3TNV)
	6	Injector 1 coil short circuit	P0271 (4TNV), P0268 (3TNV)
	3	Injector 1 short circuit	P1271 (4TNV), P1262 (3TNV)



TROUBLESHOOTING ENGINE ERROR CODE LIST

Error code		Error details	DTC
SPN	FMI		
653	5	Injector 2 open circuit (Inherent location of the injector)	P0202
	6	Injector 2 coil short circuit	P0265
	3	Injector 2 short circuit	P1265
654	5	Injector 3 open circuit (Inherent location of the injector)	P0201
	6	Injector 3 coil short circuit	P0262
	3	Injector 3 short circuit	P1262
652	5	Injector 4 open circuit (Inherent location of the injector)	P0203
	6	Injector 4 coil short circuit	P0268
	3	Injector 4 short circuit	P1268
4257	12	Injector drive IC error	P0611
2797	6	Injector drive circuit (Bank 1) short circuit (4TN: Common circuit for No.1, No.4 and all 3TN cylinders)	P1146
2798	6	Injector drive circuit (Bank 2) short circuit (4TN: Circuit for No.2 and No.3 cylinders)	P1149
523462	13	IQA corrected injection amount for injector 1 error	P1648
523463	13	IQA corrected injection amount for injector 2 error	P1649
523464	13	IQA corrected injection amount for injector 3 error	P1650
523465	13	IQA corrected injection amount for injector 4 error	P1651
522571	3	High-pressure pump drive circuit (Low side VB short-circuit)	P1641
	6	High-pressure pump drive circuit (Low side GND short-circuit)	P1643
633	3	High-pressure pump drive circuit (High side VB short-circuit)	P0629
	6	High-pressure pump drive circuit (High side GND short-circuit)	P1642
	5	High-pressure pump drive circuit (Open circuit)	P0627
522572	6	High-pressure pump drive circuit (Drive current (high level))	P062A
	11	High-pressure pump drive circuit (Pump overload error)	P1645



TROUBLESHOOTING ENGINE ERROR CODE LIST

Error code		Error details	DTC
SPN	FMI		
157	0	Actual rail pressure rise error	P0088
	18	Rail pressure deviation error during the actual rail pressure drop	P0094
	15	Rail pressure deviation error during the actual rail pressure rise	P0093
	16	PLV open valve	P000F
523469	0	Rail pressure fault (The times of PLV valve opening error)	P1666
523470	0	Rail pressure fault (The time of PLV valve opening error)	P1667
523489	0	Rail pressure fault (The actual rail pressure is too high during PRV limp home)	P1668
523468	9	Rail pressure fault (Controlled rail pressure error after PLV valve opening)	P1665
523491	0	Rail pressure fault (Injector B/F temperature error during PLV4 limp home)	P1669
523460	7	Rail pressure fault (Operation time error during RPS limp home)	P1670
190	16	Overspeed	P0219
2950	5	No-load of throttle valve drive H bridge circuit	P0660
	3	Power short circuit of throttle valve drive H bridge output 1	P1658
	4	GND short circuit of throttle valve drive H bridge output 1	P1659
	6	Overload on the drive H bridge circuit of throttle valve	P1660
2951	3	VB Power short circuit of throttle valve drive H bridge output 2	P1661
	4	GND short circuit of throttle valve drive H bridge output 2	P1662
522596	9	TSC1 (CAN message) reception time out (SA1)	U0292
522597	9	TSC1 (CAN message) reception time out (SA2)	U1301
522599	9	Y_ECR1 (CAN message) reception time out	U1292
522600	9	Y_EC (CAN message) reception time out	U1293
522601	9	Y_RSS (CAN message) reception time out	U1294
522603	9	VH (CAN message) reception time out	U1296
522605	9	Y_ECM3 (CAN message) reception time out	U1298



Error code		Error details	DTC
SPN	FMI		
237	31	VI (CAN message) reception time out	U0168
	13	VI (CAN message) reception data fault	U3002
522609	9	Y_ETCP1 (CAN message) reception time out	U1300
522618	9	EBC1 (CAN message) reception time out	U1302
522619	9	Y_DPFIF (CAN message) reception time out	U1303
522610	9	CAN1 (for EGR): Reception time out	U010B
522611	9	Exhaust throttle (CAN message from the exhaust throttle time out)	U1107
2791	0	EGR over-voltage fault	P0404
	1	EGR under-voltage fault	P1404
	7	EGR feedback malfunction	P1409
	9	EGR ECM data fault	U0401
	12	Open circuit between the EGR motor coils	P0403
522579	12	Short circuit between the EGR motor coils	P1405
522580	12	EGR position sensor malfunction	P0488
522581	7	EGR stuck open valve malfunction	P148A
522582	7	EGR initialization malfunction	P049D
522183	1	EGR high temperature thermistor malfunction	P1410
522184	1	EGR low temperature thermistor malfunction	P1411
522617	12	EGR target value out of range	U1401
522746	12	Exhaust throttle (Voltage fault)	P1438
522747	12	Exhaust throttle (Motor fault)	P1439
522748	12	Exhaust throttle (Sensor system fault)	P1440
522749	12	Exhaust throttle (MPU fault)	P1441
522750	12	Exhaust throttle (PCB fault)	P1442
522751	19	Exhaust throttle (CAN fault)	P1443
630	12	EEPROM memory deletion error	P0601
522576	12	EEPROM memory read error	P160E



TROUBLESHOOTING ENGINE ERROR CODE LIST

Error code		Error details	DTC
SPN	FMI		
522578	12	EEPROM memory writing error	P160F
522585	12	ECU internal fault (CY146 SPI communication fault)	P1613
522588	12	ECU internal fault (Excessive voltage of supply 1)	P1608
522589	12	ECU internal fault (Insufficient voltage of supply 1)	P1617
522590	12	ECU internal fault (Sensor supply voltage error 1)	P1609
522591	12	ECU internal fault (Sensor supply voltage error 2)	P1618
522592	12	ECU internal fault (Sensor supply voltage error 3)	P1619
522744	4	ECU internal fault (Actuator drive circuit 1 short to ground)	P1626
522994	4	ECU internal fault (Actuator drive circuit 2 short to ground)	P1633
523471	6	ECU internal fault (Actuator drive circuit 3 short to ground)	P1467
523473	12	ECU internal fault (AD converter fault 1)	P1469
523474	12	ECU internal fault (AD converter fault 2)	P1470
523475	12	ECU internal fault (External monitoring IC and CPU fault 1)	P1471
523476	12	ECU internal fault (External monitoring IC and CPU fault 2)	P1472
523477	12	ECU internal fault (ROM fault)	P1473
523478	12	ECU internal fault (Shutoff path fault 1)	P1474
523479	12	ECU internal fault (Shutoff path fault 2)	P1475
523480	12	ECU internal fault (Shutoff path fault 3)	P1476
523481	12	ECU internal fault (Shutoff path fault 4)	P1477
523482	12	ECU internal fault (Shutoff path fault 5)	P1478
523483	12	ECU internal fault (Shutoff path fault 6)	P1479
523484	12	ECU internal fault (Shutoff path fault 7)	P1480
523485	12	ECU internal fault (Shutoff path fault 8)	P1481
523486	12	ECU internal fault (Shutoff path fault 9)	P1482
523487	12	ECU internal fault (Shutoff path fault 10)	P1483
523488	0	ECU internal fault (Recognition error of engine speed)	P1484
522323	0	Air cleaner clogged alarm	P1101



Error code		Error details	DTC
SPN	FMI		
522329	0	Oil/water separator alarm	P1151
167	5	Charge switch (Charge switch open circuit)	P1562
	1	Charge switch (Charge alarm)	P1568
100	4	Oil pressure switch (Oil pressure switch open circuit)	P1192
	1	Oil pressure switch (Low oil pressure fault alarm)	P1198
522573	0	DPF over accumulation (Method C)	P2463
522574	0	DPF over accumulation (Method P)	P1463
522575	7	DPF regeneration defect (Stationary regeneration failure)	P2458
522577	11	DPF regeneration defect (Stationary regeneration not-performed)	P2459
3720	16	DPF OP interface (Ash cleaning request 1)	P242F
	0	DPF OP interface (Ash cleaning request 2)	P1420
3719	16	DPF OP interface (Stationary regeneration standby)	P1421
	0	DPF OP interface (Backup mode)	P1424
3695	14	DPF OP interface (Reset regeneration prohibited)	P1425
3719	9	DPF OP interface (Recovery regeneration failure)	P1445
	7	DPF OP interface (Recovery regeneration prohibition)	P1446



TROUBLESHOOTING ENGINE ERROR CODE LIST

<Applicable machine models 190200001 or later>

Error code		Error details	DTC
SPN	FMI		
91	3	Accelerator sensor 1 error (high-voltage error)	P2123
	4	Accelerator sensor 1 error (low-voltage error)	P2122
	2	Accelerator sensor 1-2 comparison error	P2138
	3	Accelerator sensor 2 error (high-voltage error)	P2128
	4	Accelerator sensor 2 error (low-voltage error)	P2127
100	3	Engine oil pressure sensor error (high-voltage error)	P0523
	4	Engine oil pressure sensor error (low-voltage error)	P0522
102	3	Boost pressure sensor error (high-voltage error)	P0238
	4	Boost pressure sensor error (low-voltage error)	P0237
108	3	Barometric sensor error (high-voltage error)	P2229
	4	Barometric sensor error (low-voltage error)	P2228
110	0	Engine overheat	P0217
	3	Water temp. sensor error (high-voltage error)	P0118
	4	Water temp. sensor error (low-voltage error)	P0117
157	3	Common rail pressure sensor error (high-voltage error)	P0193
	4	Common rail pressure sensor error (low-voltage error)	P0192
	15	Common rail pressure error (over pumping)	P0089
158	3	Battery line high-voltage error	P0563
174	3	Fuel temp. sensor error (high-voltage error)	P0183
	4	Fuel temp. sensor error (low-voltage error)	P0182
190	0	Engine overspeed	P0219
628	2	ROM error	P0601
633	7	Pressure limiter open	P0087
636	2	Cam sensor error (no signal)	P0340



TROUBLESHOOTING ENGINE ERROR CODE LIST

Error code		Error details	DTC
SPN	FMI		
639	2	CAN timeout error	U0101
	19	CAN BusOff error	U0073
651	5	Injector #1 failure	P0201
652	5	Injector #2 failure	P0202
653	5	Injector #3 failure	P0203
654	5	Injector #4 failure	P0204
676	5	Glow relay failure	P0380
677	5	Starter cut relay failure	P0615
723	2	Crank sensor error (no signal)	P0335
	2	Crank sensor error (abnormal signal)	P0336
1077	2	CPU error	P0606
1079	2	5V power system 1 error	P0641
1080	2	5V power system 2 error	P0651
1131	3	Manifold temp. sensor error (high-voltage error)	P041C
	4	Manifold temp. sensor error (low-voltage error)	P041D
1239	17	Common rail pressure error (insufficient pumping)	P1093
1347	3	SCV drive system +B short-circuit (high-voltage error)	P0092
	4	SCV drive system cable break +GND short-circuit (low-voltage error)	P0091
1381	3	Fuel filter clogging sensor error (high-voltage error)	P1294
	4	Fuel filter clogging sensor error (low-voltage error)	P1293
1485	5	Main relay system error (not activated)	P0685
	6	Main relay line error (not shut off)	P0687



TROUBLESHOOTING ENGINE ERROR CODE LIST

Error code		Error details	DTC
SPN	FMI		
10001	2	EGR position sensor error (brushless specified)	P0409
	13	EGR zero-point learning error	P1404
10002	2	EGR valve control error	P0404
10003	2	Injector com 1 error	P2146
10004	2	Injector com 2 error	P2149
10005	1	Charge circuit error (bank 1)	P1261
10006	1	Charge circuit error (bank 2)	P1262
10007	2	Sub CPU error	P0606
10008	2	A/D converter error	P060B
10009	2	5V power system 3 error	P0697
10010	2	5V power system 4 error	P1655
10013	2	EEPROM error	P1621
10023	3	EVRV vacuum sensor error (high-voltage error)	P2528
	4	EVRV vacuum sensor error (low-voltage error)	P2527
10032	2	QR code error	P0602
10033	2	RAM error	P0604
10040	19	CAN BusOff error (ISO-CAN)	U0001



OTHER SYMPTOMS

For symptoms not included in the table below or if the problem persists after the proper remedies have been taken, consult your sales or service dealer.

Symptoms	Major causes	Remedies
Left and right operating levers do not move smoothly	• Insufficient grease on the left and right operating levers	• Grease the levers. Refer to page 5-70.
Travel levers, blade lever and pedals do not move smoothly	• Insufficient grease on travel levers, blade lever and pedals	• Grease the levers and pedals. Refer to page 5-70.
Operation of hoe attachment, dozer blade, auxiliary hydraulics, slewing or traveling is not possible.	• Safety lock lever is raised (locked) • Fuse is blown	• Lower (release) the safety lock lever. Refer to page 2-48. • Replace the fuse. Refer to page 6-6.
Digging force is insufficient	• Hydraulic oil level too low • Hydraulic oil is not warm enough • Air cleaner is clogged • Hydraulic oil is not of suitable type	• Add to the specified level. Refer to page 5-24. • Perform the warm-up. Refer to pages 3-10 to 3-11. • Clean the air cleaner. Refer to page 5-40. • Replace the hydraulic oil. Refer to page 5-57.
Traveling is not possible or not smooth	• Stones or foreign objects are stuck	• Remove the foreign object.
Machine veers to the right/left	• Stones or foreign objects are stuck • Crawler belt tension is faulty.	• Remove the foreign object. • Check and adjust (ask your sales or service dealer). Refer to pages 5-30 and 5-72.
Travel speed cannot be changed	• Fuse is blown	• Replace the fuse. Refer to page 6-6.
Slewing is not possible or not smooth	• Insufficient grease on slew bearing	• Grease the bearing. Refer to page 5-30.
Hydraulic oil temperature is too high	• Hydraulic oil level too low	• Add up to the specified level. Refer to page 5-24.



Symptoms	Major causes	Remedies
Starter motor turns but engine does not start	• Insufficient fuel • Air in fuel system • Water in fuel system • Fuel is frozen. • Engine control system is faulty. • Fuel line is faulty. • Preheating device is faulty.	• Add fuel. Refer to page 5-23. • Bleed air. Refer to page 6-8. • Drain water. Refer to page 5-31. • Warm the fuel pipe with hot water or wait until the ambient temperature becomes high. • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer).
Crawlers come off	• Crawlers too loose	• Check and adjust (ask your sales or service dealer). Refer to pages 5-30 and 5-72.
Engine exhaust is white or bluish	• Excessive engine oil • Insufficient engine warm-up. • Engine control system is faulty. • Fuel line is faulty. • Prolonged idling (approx. two hours or more) • Poor fuel	• Adjust to the specified level. Refer to page 5-21. • Perform the warm-up operation. Refer to page 3-6. • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer). • Increase the engine RPM and check for smoke. • Replace the fuel.



TROUBLESHOOTING OTHER SYMPTOMS

Symptoms	Major causes	Remedies
Engine exhaust is occasionally black	• Air cleaner is clogged • Engine control system is faulty. • Fuel line is faulty. • Clogging in the exhaust line. • DPF is faulty.	• Clean the air cleaner. Refer to page 5-40. • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer). • Adjust or repair (ask your sales or service dealer).
Irregular noise is produced from the engine (combustion or mechanical noise)	• Low quality fuel is being used • Engine is overheating • Damage inside the muffler	• Replace the fuel. • Refer to “If the engine overheats” on page 6-3. • Replace the muffler. For replacement, ask your sales or service dealer.



LOWERING THE BOOM TO THE GROUND

If the hoe attachment must be lowered to the ground while the engine is stopped, use the following procedure.

Procedure 1 (machines with an accumulator)

Perform this operation within 10 minutes after the engine stopping.

1. Sit at the operator's seat.
2. Turn the starter switch to the ON position.
3. Lower the safety lock lever to the unlock position
4. Slowly push the operating lever forward to lower the boom.

Procedure 2 (machines without an accumulator)


This operation is dangerous and requires experience. Ask your sales or service dealer for it.




WARNING

- Stop the engine and allow the machine to cool down before performing maintenance.
 - The engine and the hydraulic system and many other parts of the machine are hot immediately after the engine is stopped. Touching these parts will cause burns.
 - The hydraulic oil is also hot and under high pressure immediately after the engine is stopped. Be careful when loosening the caps or plugs. Working on the machine under these conditions could result in burns or injuries due to the hot oil spurting out.
- Keep away from the working area when the hoe attachment is lowered. You may be hit by dirt falling out of the bucket or the hoe attachment as it drops.
- Stand in a position away from danger of lowering boom and loosen the hose nut. Otherwise, you could be hit by the boom.

- Do not loosen or remove the hoses not located in the specified places. Oil may spurt out if wrongly handled.
- Slowly turn the hose nut and lower the boom at a slow pace.



2-Piece boom



1. Place a pan under the hose to catch the waste oil.
2. Hold the hose fitting (1) with a wrench and slowly loosen the hose nut (2) with another wrench.
3. The oil in the boom cylinder is drained and the hoe attachment is lowered.
4. After the hoe attachment is lowered to the ground, check the safety and stability of the machine.
5. Hold the hose fitting (1) with a wrench and tighten the hose nut (2) with another wrench.
 - Tightening torque: 24.5 to 29.4 N·m (18.1 to 21.7 ft·lb.)



TOWING



WARNING

When towing, serious injury or death could result, if performed incorrectly or the wire rope being used is inappropriate or not properly inspected.


- It becomes dangerous if the wire rope breaks or becomes disengaged. Use a wire rope appropriate for the required tractive force.
- Do not use a wire rope that is kinked, twisted or otherwise damaged.
- Do not apply heavy loads abruptly to the wire rope.
- Wear safety gloves when handling the wire rope.
- Make sure there is an operator on the machine being towed as well as on the machine that is towing.
- Never tow on slopes.
- Do not let anyone come near to the wire rope while towing.

IMPORTANT: Do not tow a machine if its engine does not start or if the machine does not run. Doing so could damage the machine being towed.

IMPORTANT: Be sure to follow the steps below closely when using the towing hole to tow. Failure to heed even one of the steps may cause damage to the towing hole or other parts of the frame.

Towing the machine

Use the procedure described below to tow heavy objects or the machine itself if it should get stuck in the mud and not be able to get out on its own.



- Permissible forces: 125.2 kN (28146 lbf)
Do not tow using only a towing hole on one side.

1. Attach the wire rope to the shackle (1).
2. Fasten the shackle (1) to the towing holes (2).
3. Make sure that the wire rope is at a cone angle of 20° or less to the travel frame.
4. Move the machine to tension the wire rope.
5. Move the machine at a low speed of 2 km/h (1.24 mph) or less to a place (convenient location for repair) a short distance from the site.



IF THE CAB IS DAMAGED



WARNING

Immediately replace the damaged cab. Serious injury or death may occur if the machine is operated with damaged cab. Do not operate the machine until the replacement is complete. Do not try to repair the damaged cab by welding. Doing so could endanger the safety of the cab.

Cab part number: 05686-00128



EXHAUST GAS CONTROL SYSTEM ERROR

ERROR CODE LIST

If the exhaust gas control system detects an error, the ECM error warning lamp turns on or flashes and the following error codes are displayed.

If an error code appears, immediately repair the fault part detected, or consult your sales or service dealer for help.

Error code		Error description		DTC	NCD or PCD Error*	Limited engine
SPN	FMI	Fault location	Cause			Level
102	3	EGR Differential Pressure Sensor	1. Wiring Bypass	P0238	N	2
102	4	EGR Differential Pressure Sensor	1. Wiring Disconnection 2. Sensor Removal	P0237	N	2
102	10	EGR Differential Pressure Sensor	1. Pressure Hose Removal 2. Sensor Leave in Atmosphere 3. Dummy Resistance	P1673	N	6
110	4	Coolant Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P0117	N	4
3251	3	DPF Differential Pressure Sensor	1. Wiring Bypass	P2455	N	2
3251	4	DPF Differential Pressure Sensor	1. Wiring Disconnection 2. Sensor Removal	P2454	N	2
4795	31	DPF Differential Pressure Sensor	1. Pressure Hose Removal 2. SF Removal 3. Sensor Leave in Atmosphere 4. Dummy Resistance	P226D	P	6
3242	3	DPF Inlet Temperature Sensor	1. Wiring Bypass	P1428	P	2
3242	4	DPF Inlet Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P1427	P	2
3250	3	DPF Intermediate Temperature Sensor	1. Wiring Bypass	P1434	P	2
3250	4	DPF Intermediate Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P1435	P	2
412	3	EGR Gas Temperature Sensor	1. Wiring Bypass	P041D	N	3
412	4	EGR Gas Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P041C	N	3
105	3	Intake Manifold Temperature Sensor	1. Wiring Bypass	P040D	N	2
105	4	Intake Manifold Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P040C	N	2
173	3	Exhaust Manifold Temperature Sensor	1. Wiring Bypass	P0546	N	3
173	4	Exhaust Manifold Temperature Sensor	1. Wiring Disconnection 2. Sensor Removal	P0545	N	3
2791	12	EGR Valve	1. Wiring Disconnection	P0403	N	4

*,

N: NCD (NOx Control Diagnostic system)

P: PCD (Particulate Control Diagnostic system)

**NOX CONTROL DIAGNOSTIC SYSTEM (NCD)**

The NCD system warns the operator of any error detected by turning on the warning lamp and displaying an engine error code. The engine output is limited depending on the type of fault.

PARTICULATE CONTROL DIAGNOSTIC SYSTEM (PCD)

The PCD system warns the operator of any error detected in the particulate after-treatment system such as the DPF, by using the warning lamp and displaying an engine error code. The engine output is limited depending on the type of fault.




LIMITING THE ENGINE OUTPUT

If the exhaust gas control system detects an error, the engine output is limited depending on the type of fault.

There are three types of engine output limitation, each corresponding to the fault level determined.

Note: If the time interval between the fault repairing and error detecting is short, the regular operation may be executed with a shorter pre operation.

Level 2



Pre operation: when the error is detected, the engine torque is reduced by 85%, compared to the normal operation.


The engine revolution becomes +200 min⁻¹, compared to the maximum torque.

Regular operation: after 15-minute pre operation, the regular operation starts. The engine torque is reduced by 50%, compared to the normal operation. The engine revolution becomes +200 min⁻¹, compared to the maximum torque. The regular operation continues until the error is resolved.



TROUBLESHOOTING EXHAUST GAS CONTROL SYSTEM ERROR

Level 3 or 4



AM4J002E


— : Normal
- - - - - : Limited output

Pre operation: when the error is detected, the engine torque is reduced by 85%, compared to the normal operation.

Regular operation: after 120-minute pre operation, the regular operation starts. The engine torque is reduced by 50%, compared to the normal operation. The regular operation continues until the error is resolved.



Level 6 (only NCD)



AM4J003E

———— : Normal
- - - - - : Limited output

Pre operation 1: If an error is detected, the warning lamp turns on or starts flashing; the engine output is not limited.

Pre operation 2: Pre operation 2 starts after pre operation 1 continues 36 hours. The engine torque is reduced by 75%, compared to the normal operation.

Regular operation: Regular operation starts after the pre operation 2 continues 64 hours. The engine torque is reduced by 50%, compared to the normal operation. The regular operation continues until the error is resolved.

SPECIFICATIONS





BASIC SPECIFICATIONS

<Applicable machine models 185100001 or later>

Type			Mono boom	2-Piece boom
MASS				
Operating mass	kg (lb)	Rubber crawlers	8400 (18520)	8715 (19213)
		Steel crawlers	8635 (19035)	8950 (19731)
PERFORMANCE				
Bucket capacity (Standard bucket)	m³ (cu. ft.)	Heaped	0.245 (8.65)	
		Struck	0.185 (6.53)	
Slew speed	min ⁻¹ (rpm)	10.3 (10.3)		
Travel speed	km/h (mph)	Rubber crawlers	1st	2.6 (1.62)
			2nd	5.0 (3.11)
		Steel crawlers	1st	2.5 (1.55)
			2nd	4.8 (2.98)
Gradeability	(degrees)	35		
Ground pressure	kPa (psi)	Rubber crawlers	37.6 (5.45)	39.0 (5.66)
		Steel crawlers	39.1 (5.67)	40.5 (5.87)
Noise level dB (A)	Sound power level		L _{WA} 99	
	Emission sound pressure level at the operator's position (ISO 6396,2008:)		L _{pA} 74	
ENGINE				
Manufacturer and model			Yanmar 4TNV98CT-WTB	
Rated output	Net (ISO 14396)	kW/min ⁻¹ (hp/rpm)	51.6/2000 (69.2/2000)	
	Net (ISO 9249/ SAEJ1349)	kW/min ⁻¹ (hp/rpm)	49.6/2000 (66.5/2000)	
Displacement	ml (cu.in.)		3318 (202.5)	
Starter	V-kW		12-3.0	
Alternator	V-kW		12-0.96	
Battery (IEC 60095-1)	V-A·h		12-90	



SPECIFICATIONS


BASIC SPECIFICATIONS

<Applicable machine models 190200001 or later>

Type			Mono boom	2-Piece boom
MASS				
Operating mass	kg (lb)	Rubber crawlers	8425 (18575)	8740 (19268)
		Steel crawlers	8660 (19090)	8975 (19786)
PERFORMANCE				
Bucket capacity (Standard bucket)	m³ (cu. ft.)	Heaped	0.245 (8.65)	
		Struck	0.185 (6.53)	
Slew speed	min ⁻¹ (rpm)	10.3 (10.3)		
Travel speed	km/h (mph)	Rubber crawlers	1st	2.6 (1.62)
			2nd	5.0 (3.11)
		Steel crawlers	1st	2.5 (1.55)
			2nd	4.8 (2.98)
Gradeability	(degrees)	35		
Ground pressure	kPa (psi)	Rubber crawlers	37.7 (5.47)	39.1 (5.67)
		Steel crawlers	39.1 (5.67)	40.6 (5.89)
Noise level dB (A)	Sound power level		L _{WA} 99	
	Emission sound pressure level at the operator's position (ISO 6396,2008:)		L _{pA} 74	
ENGINE				
Manufacturer and model			ISUZU 4JJ1T	
Rated output	Net (ISO 14396)	kW/min ⁻¹ (hp/rpm)	52.0/2000 (69.7/2000)	
	Net (ISO 9249/ SAEJ1349)	kW/min ⁻¹ (hp/rpm)	49.9/2000 (66.9/2000)	
Displacement	ml (cu.in.)		2999 (183)	
Starter	V-kW		12-2.5	
Alternator	V-kW		12-1.32	
Battery (IEC 60095-1)	V-A·h		12-90	

MACHINE DIMENSIONS

Mono boom



AM1K0011



Mono boom


Unit: mm (inch)

	Item	Standard arm	Middle arm	Long arm
		Rubber crawlers		
A	Overall length	6530 (257.1) 6565 (258.5)**	6575 (258.9) 6610 (260.2)**	6660 (262.3) 6695 (263.7)**
B	Upperstructure overall width	2140 (84.3)	←	←
C	Overall height	2550 (100.5) 2560 (100.8)*	←	←
D	Slew radius	1650 (65) 1685 (66.3)**	←	←
E	Clearance height under upperstructure	770 (30.4) 760 (29.9)*	←	←
F	Crawler base	2210 (87) 2180 (85.8)*	←	←
G	Crawler overall length	2855 (112.4) 2830 (111.4)*	←	←
H	Crawler overall width	2200 (86.6)	←	←
J	Crawler shoe width	450 (17.7)	←	←
K	Ground clearance of undercarriage	370 (14.6) 360 (14.2)*	←	←
L	Minimum radius of equipment and attachment	2240 (88.2)	2360 (92.9)	2495 (98.2)
M	Minimum radius of equipment at maximum front offset	1810 (71.3)	1910 (75.3)	2030 (79.9)
P	Offset distance of bucket (right swing)	685 (27)	←	←
Q	Offset distance of bucket (left swing)	890 (35)	←	←
R	Dozer blade width	2200 (86.6)	←	←
S	Dozer blade height	500 (19.7)	←	←
T	Front distance to axis of rotation	4890 (192.5)	4935 (194.3)	5020 (197.7)
U	Dozer blade distance to axis of rotation	2055 (81.0) 2060 (81.1)*	←	←
V	Boom swing angle (Left)	70°	←	←
W	Boom swing angle (Right)	60°	←	←
X	Overall length (dozer blade at rear)	6945 (273.5)	7000 (275.6)	7085 (278.9)

* : With steel crawlers

** : With extra weight

2-Piece boom (One cylinder)



AM3K001



2-Piece boom (One cylinder)


Unit: mm (inch)

	Item	Rubber crawlers
A	Overall length	6700 (263.8) 6735 (265.2)**
B	Upperstructure overall width	2140 (84.3)
C	Overall height	2550 (100.5) 2560 (100.8)*
D	Slew radius	1650 (65) 1685 (66.3)**
E	Clearance height under upperstructure	770 (30.4) 760 (29.9)*
F	Crawler base	2210 (87) 2180 (85.8)*
G	Crawler overall length	2855 (112.4) 2830 (111.4)*
H	Crawler overall width	2200 (86.6)
J	Crawler shoe width	450 (17.7)
K	Ground clearance of undercarriage	370 (14.6) 360 (14.2)*
L	Minimum radius of equipment and attachment	2675 (105.3)
M	Minimum radius of equipment at maximum front offset	2190 (86.2)
P	Offset distance of bucket (right swing)	685 (27)
Q	Offset distance of bucket (left swing)	890 (35)
R	Dozer blade width	2200 (86.6)
S	Dozer blade height	500 (19.7)
T	Front distance to axis of rotation	5060 (199.2)
U	Dozer blade distance to axis of rotation	2055 (81.0) 2060 (81.1)*
V	Boom swing angle (Left)	70°
W	Boom swing angle (Right)	60°
X	Overall length (dozer blade at rear)	7120 (280.4)

* : With steel crawlers

** : With extra weight

2-Piece boom (Two cylinders)





2-Piece boom (Two cylinders)


Unit: mm (inch)

	Item	Rubber crawlers
A	Overall length	6780 (266.9) 6790 (267.3)**
B	Upperstructure overall width	2140 (84.3)
C	Overall height	2550 (100.5)
D	Slew radius	1650 (65) 1685 (66.3)**
E	Clearance height under upperstructure	770 (30.4)
F	Crawler base	2210 (87)
G	Crawler overall length	2855 (112.4)
H	Crawler overall width	2200 (86.6)
J	Crawler shoe width	450 (17.7)
K	Ground clearance of undercarriage	370 (14.6)
L	Minimum radius of equipment and attachment	2705 (106.5)
M	Minimum radius of equipment at maximum front offset	2220 (87.4)
P	Offset distance of bucket (right swing)	685 (27)
Q	Offset distance of bucket (left swing)	890 (35)
R	Dozer blade width	2200 (86.6)
S	Dozer blade height	500 (19.7)
T	Front distance to axis of rotation	5140 (202.4)
U	Dozer blade distance to axis of rotation	2055 (81.0)
V	Boom swing angle (Left)	70°
W	Boom swing angle (Right)	60°
X	Overall length (dozer blade at rear)	7210 (283.9)

** : With extra weight

OPERATING RANGES

Mono boom






Mono boom

Unit: mm (inch)

	Item	Standard arm	Middle arm	Long arm
		Rubber crawlers		
A	Maximum reach	7105 (279.6)	7275 (286.3)	7435 (292.7)
B	Maximum reach at ground reference plane	6950 (273.7)	7125 (280.6)	7290 (287.1)
C	Maximum digging depth	4230 (166.6)	4410 (173.7)	4580 (180.4)
D	Maximum vertical digging depth	3470 (136.5)	3650 (143.6)	3820 (150.4)
E	Reach at maximum vertical digging depth	4685 (184.4)	4720 (185.8)	4755 (187.1)
F	Maximum height of cutting edge	7030 (276.8)	7165 (282.1)	7290 (287.1)
G	Maximum dumping height	4995 (196.7)	5135 (202.1)	5260 (207.1)
H	Minimum dumping height	1950 (76.7)	1785 (70.3)	1640 (64.6)
J	Dozer blade maximum lifting	505 (19.9)	←	←
K	Dozer blade maximum lowering	500 (19.7)	←	←

2-Piece boom (One cylinder)



AMOK012




SPECIFICATIONS OPERATING RANGES

2-Piece boon (One cylinder)

Unit: mm (inch)

	Item	Rubber crawlers
A	Maximum reach	7730 (304.3)
B	Maximum reach at ground reference plane	7590 (298.8)
C	Maximum digging depth	4470 (175)
D	Maximum vertical digging depth	3980 (156.7)
E	Reach at maximum vertical digging depth	4385 (172.6)
F	Maximum height of cutting edge	8045 (316.7)
G	Maximum dumping height	6120 (240.9)
H	Minimum dumping height	2550 (100.4)
J	Dozer blade maximum lifting	505 (19.9)
K	Dozer blade maximum lowering	500 (19.7)

2-Piece boom (Two cylinders)



AM3K027



SPECIFICATIONS OPERATING RANGES

2-Piece boon (Two cylinders)

Unit: mm (inch)

	Item	Rubber crawlers
A	Maximum reach	7775 (306.1)
B	Maximum reach at ground reference plane	7640 (300.8)
C	Maximum digging depth	4480 (176.4)
D	Maximum vertical digging depth	4010 (157.9)
E	Reach at maximum vertical digging depth	4390 (172.8)
F	Maximum height of cutting edge	8060 (317.3)
G	Maximum dumping height	6110 (240.6)
H	Minimum dumping height	2540 (100)
J	Dozer blade maximum lifting	505 (19.9)
K	Dozer blade maximum lowering	500 (19.7)



LIFTING CAPACITIES

Rated lift capacity chart

- The loads in the charts do not exceed 87% of hydraulic lift capacity or 75% of tipping load.
- Figures marked with an asterisk (*) are hydraulically-limited capacities.
- The mass of slings and any other lifting devices shall be deducted from the rated load to determine the net load that may be lifted.
- The load point is the bucket hinge pin, and the bucket posture is with the standard bucket completely retracted under the arm.
- Unit: daN (lbs)

Load hooking system

A load hooking system must be provided with the following capabilities.

1. A system which can withstand twice the rated lift capacity no matter at what position the load is applied.
2. A system that poses no risk of the lifted load falling from the hooking device. For example, equipped with a hook slippage prevention device.
3. A system that poses no risk of the hooking system slipping from the hoe attachment.




WARNING

- Do not attempt to lift or hold any load that is greater than these rated values at their specified load radii and height.
- The rated lift capacities are based on the machine being level and situated on a firm supporting surface. For safe lifting, the operator is expected to make due allowance for the particular job conditions such as soft or uneven ground, non-level condition, load to the machine sides, hazardous conditions, experience of personnel, etc. The operator and other personnel should fully acquaint themselves with the operator's manual furnished by the manufacturer before operating this machine. When operating the machine, the safety rules of the equipment must also be followed.
- Do not travel while lifting a load; It is very dangerous.



Standard arm <Applicable machine models 185100001 or later>

Over Front ; Dozer Blade Up




Units: daN(lbs.)




SPECIFICATIONS LIFTING CAPACITIES

Standard arm <Applicable machine models 185100001 or later>

Over Rear



Over Side




Units: daN(lbs.)



SPECIFICATIONS LIFTING CAPACITIES

Middle arm <Applicable machine models 185100001 or later>

Over Front ; Dozer Blade Up




AM3K004E




SPECIFICATIONS LIFTING CAPACITIES

Middle arm <Applicable machine models 185100001 or later>

Over Side




Over Rear





Long arm <Applicable machine models 185100001 or later>



AM3K006E

Over Side




Over Rear





Standard arm <Applicable machine models 190200001 or later>


Over Front ; Dozer Blade Up




Units: daN(lbs.)

Standard arm <Applicable machine models 190200001 or later>

Over Side




Over Rear



Units: daN(lbs.)




Middle arm <Applicable machine models 190200001 or later>




Middle arm <Applicable machine models 190200001 or later>


Over Side



Over Rear



Over Front ; Dozer Blade Up







SPECIFICATIONS LIFTING CAPACITIES

Long arm <Applicable machine models 190200001 or later>

Over Side



Over Rear






SPECIFICATIONS LIFTING CAPACITIES

2-Piece boom (One cylinder) <Applicable machine models 185100001 or later>


Over Front ; Dozer Blade Up






2-Piece boom (One cylinder) <Applicable machine models 185100001 or later>

Over Side



Units: daN(lbs.)

Over Rear






SPECIFICATIONS LIFTING CAPACITIES

2-Piece boom (One cylinder) <Applicable machine models 190200001 or later>


Over Front ; Dozer Blade Up






2-Piece boom (One cylinder) <Applicable machine models 190200001 or later>

Over Side



Over Rear




Units: daN(lbs.)



Long arm (Equipped with Extra weight) Rubber crawlers


Over Front ; Dozer Blade Up






Long arm (Equipped with Extra weight) Rubber crawlers

Over Side



Over Rear




Units: daN(lbs.)



Long arm (Equipped with Extra weight) Steel crawlers

Over Front ; Dozer Blade Up



Units: daN(lbs.)




SPECIFICATIONS


LIFTING CAPACITIES

Long arm (Equipped with Extra weight) Steel crawlers

Over Side



Over Rear




Units: daN(lbs.)



2-Piece boom (One cylinder) (Equipped with Extra weight) Rubber crawlers

Over Front ; Dozer Blade Up




Units: daN(lbs.)




SPECIFICATIONS LIFTING CAPACITIES

2-Piece boom (One cylinder) (Equipped with Extra weight) Rubber crawlers

Over Side



Over Rear




Units: daN(lbs.)




2-Piece boom (One cylinder) (Equipped with Extra weight) Steel crawlers

Over Front ; Dozer Blade Up




2-Piece boom (One cylinder) (Equipped with Extra weight) Steel crawlers

Over Side



Over Rear




Units: daN(lbs.)



2-Piece boom (Two cylinders) Rubber crawlers


Over Front ; Dozer Blade Up




Units: daN(lbs.)

2-Piece boom (Two cylinders) Rubber crawler

Over Side



Over Rear




Units: daN(lbs.)



2-Piece boom (Two cylinders) (Equipped with Extra weight) Rubber crawlers

Over Front ; Dozer Blade Up




Units: daN(lbs.)




2-Piece boom (Two cylinders) (Equipped with Extra weight) Rubber crawler

Over Side



Over Rear




Units: daN(lbs.)



2-Piece boom (Two cylinders) (Equipped with Extra weight) Steel crawlers


Over Front ; Dozer Blade Up




Units: daN(lbs.)

2-Piece boom (Two cylinders) (Equipped with Extra weight) Steel crawlers

Over Side



Over Rear



Units: daN(lbs.)

OPTIONS



GENERAL PRECAUTIONS

SAFETY PRECAUTIONS



WARNING

When removing or installing an attachment or optional part, take the following precautions.

- Consult with Takeuchi before installing an optional attachment.
- Do not use any attachments not approved by Takeuchi. Doing so may cause safety problems. Or, it may adversely affect the machine's operation or service life.
- We will not be held responsible for any injuries, accidents or damage to its products caused by the use by a non-approved attachment.
- Select a firm, level work area. Also, be sure to park in a well ventilated place.
- Clear obstacles and dangerous objects, and clean up spilled fuel immediately.
- When hoisting, be sure to designate a person to act as a signalman. Follow the instructions of the signalman regarding the procedure and measures.
- When it is necessary to temporarily place a heavy object or an attachment on the ground during removal or installation, be sure to place it in a stable position.
- Keep everyone out of the area when hoisting. There is a hazard of objects falling or contacting with people in the area.
- Use a crane to move heavy objects (25 kg (55 lb.) or greater).
- Before removing a heavy object, be sure to put a support to it. When lifting with a crane, pay attention to the center of gravity of the load to keep the machine in balance.
- Do not operate the machine while the load is lifted by a crane stand.

- Use the proper procedure when mounting a boom or arm; otherwise serious damage could result. Consult your sales or service dealer for help.

CAUTIONS WHEN INSTALLING ATTACHMENTS

Be sure to perform a test operation after an optional or other special attachment has been replaced. Inspect the hydraulic oil level and recharge it as necessary. Consult your sales or service dealer for detailed procedures on installing/removing attachments.




CAUTIONS WHEN OPERATING ATTACHMENTS

WARNING

Long attachments reduce stability of the machine. The machine may tip over if it loses the balance when traveling or slewing on slopes.

Never perform the operations listed below as they are extremely dangerous.



- Traveling down the slopes with the attachment raised



- Traveling across slopes



- Slewing on slopes
- If there is a heavy attachment is installed, the machine takes longer distance than usual to come to a complete stop when the stopping operation is performed. Carefully judge the distance so as not to bump into an object around the machine. Keep a safe distance from surrounding obstacles. When a heavy attachment is installed, natural drop (the gradual dropping of the attachment under its own weight when it is stopped in midair) increases.
- The machine can tip over more easily in the lateral direction than in the longitudinal direction.
 - Do not slew sideways with a heavy load at the how attachment. In particular, do not slew sideways on slopes.
 - The attachment is heavier for machines equipped with breakers or crushers than for machines equipped with the standard bucket. Do not operate such machines sideways, especially digging downhill.
- When a long arm is installed, the operating range increases. Carefully judge the distance so as not to bump into an object around the machine. Keep a safe distance from surrounding obstacles.



ATTACHMENT COMBINATION TABLE

The table below shows which bucket should be installed when the machine is using a standard arm, middle arm or long arm. Select a proper bucket by following the table.

WARNING

- Consult with Takeuchi before installing an optional attachment.
- Do not use any attachments not approved by Takeuchi. Doing so may cause safety problems. Or, it may adversely affect the machine's operation or service life.
- We will not be held responsible for any injuries, accidents or damage to its products caused by the use by a non-approved attachment.
- The swing stopper must be installed when a bucket wider than a 750W (standard) bucket is installed. Failure to do so may result in the bucket hitting the machine body.
- Install the extra weight (standard) or wide width steel crawler if the long arm or middle arm is installed.

√ :Can be used.

Δ :Can be used only for light operations (digging and loading of dry and loose soil or mud)

— :Cannot be used.

Total bucket mass = Bucket mass + Heaped bucket load (specific gravity: 1.8)

Bucket	Rated capacity m ³ (cu.yd.)	Bucket cutting width mm (inch)	Standard arm 1780 mm (70 in.)	Middle arm 1960 mm (77 in.)	Long arm 2130 mm (84 in.)
430W (no side cutter)	0.14 (0.18)	430 (16.9)	√	√	√
500 W	0.14 (0.18)	500 (19.7)	√	√	√
650 W	0.20 (0.26)	650 (25.6)	√	√	√
750 W (S.T.D.)	0.25 (0.33)	750 (29.5)	√	√	—
3-hole bucket	0.26 (0.34)	610 (24.0)	√	—	—
Total bucket mass = Within 657 kg (1448 lb.)		Within 750 (29.5)	√	—	—
Hydraulic Breaker (TKB-401)			√	—	—




SELECTING A LEVER PATTERN

The operating pattern of the left and right operating levers can be changed.




WARNING

Before starting the engine, check the selector to see which operating pattern the left and right operating levers are set.



AG7L0331

SWITCHING THE LEVER PATTERN



(A) : ISO pattern

(G) : G pattern

1. Park the machine on a flat and rigid ground, and stop the engine.
2. Fully open the cab door and fix it in place.
3. Remove the floor mat.
4. Open the cover (1).
5. Loosen the wing bolt (2).
6. Turn the selector valve lever (3) to change the pattern.
7. Tighten the wing bolt (2) and fasten the lever (3) in place.
8. Close the cover (1) and return the floor mat back in place.
9. Confirm the lever pattern.




HYDRAULIC BREAKER


For handling of the breaker, read the hydraulic breaker's manual, provided separately.

IMPORTANT: When installing an attachment, make sure that it is appropriate for the machine being used. Contact your sales or service dealer for advice on selecting attachments.


CAUTIONS ON OPERATING




- Start the engine and run it at 75% of the maximum speed.




- Pound with the chisel pressed perpendicular to the surface to be pounded.
- When pounding, press the chisel properly against the object to be broken so as to avoid pounding the air.




- Do not pry with the chisel or do not pry while pounding.
- Do not move the chisel while pounding.
- Do not pound continuously for over 30 seconds on the same surface.



- Do not pound with the cylinder fully extended or retracted (at the stroke end). Leave a margin of at least 50mm(2 in).



- Do not pound with the arm placed perpendicular to the ground surface.



- Do not drop the breaker itself on the object to be broken in order to break it.
- Do not move objects to be broken or rocks with the breaker itself.
- Slew the machine occasionally to cool the engine.
- If a hydraulic hose is vibrating abnormally, nitrogen gas may be leaking from the accumulator. Ask for an inspection early.

REPLACING THE HYDRAULIC OIL REGULARLY


When a hydraulic breaker is used, the oil deteriorates more quickly than that used for a usual operation. Be sure to replace the hydraulic oil and the return filter elements.

- Failure to replace these in time can lead to damage to the machine and the breaker hydraulic system. To improve the service life of the hydraulic systems, be sure to replace the hydraulic oil and return filter element after the number of hours shown on the diagram below.
- When replacing the hydraulic oil, clean the suction strainer.

Replacement interval (hours)

Item	Hydraulic oil	Filter element
1st time	—	25
2nd time	—	100
Periodically	1200 (600)	200

When the breaker operating ratio is 100%.



(): When using conventional antiwear hydraulic oil.



TRAVEL ALARM

The alarm sounds while the machine is traveling and stops when the machine stops traveling.


If the alarm does not sound when the machine travels, the fuse may be blown. Inspect the fuses.



WARNING


If the fuse blows again soon after replacement, then the electric system is likely faulty. It may pose a fire hazard if not properly repaired. Contact your sales or service dealer for advice.

1. Turn the starter key to the OFF position to stop the engine.



AM1J002

2. Open the fuse box cover (1).
3. Check for any blown fuses (2).



AG7J013PE

4. If a fuse is blown, replace it with a spare fuse of the same capacity.

Fuse layout and circuits protected

Capacity	Symbol	Protected circuit
25A		Light
10A		Wiper
20A		Lever lock
15A	CTL	Controller power supply Travel alarm
20A	CTL (OX)	OX controller power supply
25A	CAB	Cab interior power supply
25A	OPT(1)	Option (1)
20A	OPT(2)	Option (2)
10A		Air conditioner compressor
5A		AC motor
10A		Immobilizer
25A		Air conditioner blower motor

Capacity	Symbol	Protected circuit
25A	CAB	Cab light
5A		Switch lighting
10A		Horn
5A* 10A** 15A***		Starter switch

*: Applicable machine models 185100001 to 185104995

**: Applicable machine models 185104996 or later

***: Applicable machine models 190200001 or later



OPTIONAL EQUIPMENT MASS

Standard machine mass kg (lb.) (Not including operator)		Applicable machine models 185100001 or later	Applicable machine models 190200001 or later
		Rubber crawlers	Rubber crawlers
		8325 (18355)	8350 (18410)
OPTION			
Steel crawler, 450-mm width		235 (520)	
Steel crawler, 550-mm width		356 (785)	
Segmental rubber crawler		266 (585)	
Shoe guide		18 (40)	
Center guide		21 (46)	
Step		6 (15)	
Wide width blade		7 (15)	
Angle blade		150 (330)	
Extra weight		190 (423)	
Air suspension seat		19 (40)	
Middle arm		15 (35)	
Long arm		29 (65)	
Long arm (With thumb bracket)		35 (75)	
Arm emergency shut-off valve		4 (10)	
Auxiliary hydraulic lines	Auxiliary 3rd	17 (35)	
	Auxiliary 3rd + Auxiliary 4th.	32 (70)	
Dozer blade with float		5 (10)	
Roof guard (Level II: ISO 10262)		55 (120)	
Front guard (Level II: ISO 10262)		60 (130)	

Units: kg (lb)

*: Mass of optional equipment is added to the standard machine mass.

*: This table only contains the optional equipment of 10kg (20lb) or more in mass.



BIODEGRADABLE OIL

Biodegradable oil is a new type of hydraulic oil that is decomposed into carbon dioxide and water by microorganisms in the soil and water. It is highly safe for living organisms and offers advantages in term of environmental protection.

- Recommended biodegradable oil: Mobile EAL EnviroSyn 46H (an ester synthetic oil). When replacing the hydraulic oil with biodegradable oil, use the above or an equivalent oil.
Note that other oils, even other brands of ester synthetic oils, may damage O-rings, packings and seals. Takeuchi products shipped with the optional biodegradable oil are shipped with the above brand of oil.
- When switching from a mineral oil to a biodegradable oil, the parking brake torque decreases by about 30%.

REPLACING THE HYDRAULIC OIL WITH BIODEGRADABLE OIL

Mixing mineral oil with biodegradable oil will result in a decrease of the hydraulic oil's performance as well as a decrease in biodegradability and safety. The hydraulic oil system must be flushed as described below before supplying the biodegradable oil. This operation is dangerous and requires experience. Have it performed by a Takeuchi sales or service outlet.

Flushing

To be performed by a Takeuchi sales or service outlet


1. Drain the hydraulic oil (mineral oil) from the hydraulic oil tank and clean the inside of the tank and suction strainer.
Refer to "Replacing the hydraulic oil and cleaning the suction strainer".
2. Remove the cylinder hoses and drain the hydraulic oil (mineral oil) from inside the cylinders.
3. Supply new biodegradable oil to the hydraulic oil tank.

4. Bleed the air from the hydraulic oil system.
5. Operate the hydraulic devices for 30 minutes.
6. Drain the biodegradable oil from the tank and cylinders.
7. Replace the hydraulic oil return filter with a new filter.
8. Repeat steps 3 and 4.
9. Operate the hydraulic devices for 30 minutes.
10. Drain the biodegradable oil from the tank and cylinders.
11. Repeat steps 3 and 4.
12. Operate the hydraulic devices for 1 hour.
13. Drain the biodegradable oil from the tank and cylinders.
14. Replace the return filter with a new filter.
15. Repeat steps 3 and 4.
16. Operate the hydraulic devices, then check for oil leakage.

There is no need to flush the hydraulic oil system when switching from biodegradable to mineral hydraulic oil.



CAB OPTIONS



AM1L0031

1. Rain guard
2. Front light
3. Roof guard (Level II: ISO 10262)
4. Front guard (Level II: ISO 10262)
5. Rear light



ANGLE DOZER BLADE



WARNING

- Do not press the float button while the machine is raised by the dozer blade. Doing so will cause the machine to fall. If you must work beneath the raised machine, always use a secure support to keep the machine raised.
- Do not press the float button while the dozer blade is raised. Doing so will cause the dozer blade to fall. Lower the dozer blade to the ground before pressing the float button.
- Do not travel forward while the dozer blade is in the float mode.

IMPORTANT: Do not raise the machine by using the angled dozer blade. Or, the dozer blade may be damaged due to the load concentrated onto a point on the dozer blade.

This dozer blade can be angled (to 25° right or left). Also, it can be used in the float mode.

Angle operation



Button (A)Left angle (0 to 25°)

Button (B)Right angle (0 to 25°)

The dozer blade angle is increased/decreased between 0 and 25° as long as the button is pressed.


To position the dozer blade at a right angle, align the matching marks (D) as shown in the figure.

Float operation

Button (C)Float mode

To cancel the float mode, press the button again.

Daily inspection (every 10 hours) Lubricating




1. Lower the working equipment to the ground and stop the engine.
2. Use the grease gun to lubricate the grease fitting.
3. Wipe off the excess grease.



OPTIONS ANGLE DOZER BLADE

SPECIFICATIONS



AQOL004

	Item	Rubber crawlers
A	Dozer blade width	2300 (90.6)
B	Dozer blade height	500 (19.7)
C	Dozer blade distance to axis of rotation	2165 (85.3)
D	Dozer blade maximum lifting	510 (20.1)
E	Dozer blade maximum lowering	570 (22.4)
F	Angle degree (Left/Right)	25°


Unit: mm (inch)



OPERATING LEVER SWITCH

KIT 1

HORN BUTTON




Press the button situated on the left operating lever to blow the horn.

DECELERATION BUTTON

WARNING

Before operating the deceleration button, set the operating lever to the neutral position and take your foot off the pedals. If the deceleration button is pressed while driving, the machine's operating speed will abruptly change to result in a dangerous situation.



Press this button on the left operating lever to lower the engine speed to low idling. Press the button again to return to the engine speed set with the throttle controller. For safety reasons, it is designed that the deceleration function is activated to set the

engine revolutions to low idling whenever the engine is started.


Cancel the deceleration mode by pressing the deceleration button as necessary.

Note: This deceleration button is capable of decreasing the engine speed and reducing the fuel consumption, with a simple operation, in a situation such as when little engine output is required and thus the operating or the travel levers are in neutral.

TRAVEL SPEED BUTTON

WARNING

When a load greater than a set value is applied during traveling in 2nd (high) speed, the speed will automatically slow down to 1st (low) speed. When the load becomes lighter, the speed will increase and return to 2nd (high) speed. It should be noted that the travel speed changes depending on the load condition (for machines with the automatic travel shift-down system).




Press this switch to set the travel speed to 2nd (high) speed. Press it again to return to 1st (low) speed.



AUXILIARY 1ST SWITCHES

Auxiliary hydraulic buttons




Press those buttons to control the flow of the oil in the first auxiliary hydraulic lines.

- Proportional control of the auxiliary hydraulic circuit is not possible.
- (A).....Hydraulic oil flows to the left auxiliary line (a).
 (B)Hydraulic oil flows to the right auxiliary line (b).

Slider switch (Proportional control)

Proportional control allows for slow-to-fast/ fast-to-slow movement of attachment.
 Example: If you move the slider switch half way, the attachment will move at approximately one-half the speed.



Move this switch to control the flow of the oil in the first auxiliary hydraulic lines.


- (A).....Hydraulic oil flows to the left auxiliary line (a).
 (B)Hydraulic oil flows to the right auxiliary line (b).

Refer to “Auxiliary hydraulic lines” on pages 2-76 to 2-81.

AUXILIARY 2ND/4TH SWITCH


Slider switch (Proportional control)

Proportional control allows for slow-to-fast/ fast-to-slow movement of attachment.
 Example: If you move the slider switch half way, the attachment will move at approximately one-half the speed.



Move this switch to control the flow of the oil in the second auxiliary hydraulic lines.


- (C):Hydraulic oil flows to the left auxiliary line (c).
 (D):Hydraulic oil flows to the right auxiliary line (d).



To use the auxiliary 4th hydraulic line, press the auxiliary 2/4 select button to change to the operation of the auxiliary 4th.
 Refer to “Auxiliary hydraulic lines” on pages 2-76 to 2-81.



AUXILIARY 2/4 SELECT BUTTON



This switch is used to change from the second auxiliary operation to the fourth auxiliary operation.


Pressing this button displays the second auxiliary on the Multi-information display to indicate that the second auxiliary operation is enabled. Pressing this button again displays the auxiliary 4th on the Multi-information display to indicate that the auxiliary 4th operation is enabled.

The actual operation is performed with the auxiliary 2nd/4th switch (slider switch).


SWING/SECOND BOOM SELECT BUTTON

WARNING

Pressing (switching ON or OFF) the selector button while the boom swing pedal is depressed is dangerous, since the attachment will move unexpectedly. Always set the boom swing pedal back to the neutral position before operating the selector button.



This button changes from the boom swing operation to the second boom operation. Press this button to change over to operation of the second boom. The second boom operation indicator lamp will light. One more press of this button will result in a return to boom swing operation. Actual operation is performed with the boom swing pedal.

**Operating**

Press those buttons to control the flow of the oil in the first/second auxiliary hydraulic lines.

- (A).....Hydraulic oil flows to left auxiliary line (a).
- (B)Hydraulic oil flows to right auxiliary line (b).
- (C)Hydraulic oil flows to left auxiliary line (c).
- (D)Hydraulic oil flows to right auxiliary line (d).

Refer to "Auxiliary hydraulic lines" on pages 2-76 to 2-81.

Releasing the residual pressure

After the auxiliary hydraulic circuits have been used, pressure remains in the circuits. This is called the residual pressure. Release this residual pressure before disconnecting the lines.

Perform the residual pressure releasing within 10 minutes after the engine stopping.

1. Park the machine on a flat, rigid and safe ground.
2. Stop the engine.
3. Lower the safety lock lever to the unlocked position.
4. Turn the starter switch to the ON position.
5. Press the auxiliary hydraulic switches several times to release the residual pressure in the auxiliary hydraulic circuitry.




TAKEUCHI SECURITY SYSTEM

The Takeuchi Security System is a system that allows only registered starter keys to be used for starting the engine.


The engine cannot be started with any unregistered or counterfeit starter keys. If a registered starter key is lost or stolen, you can set the system to delete the registered key information, so that the lost or stolen key cannot be used to start the engine. Although machine theft cannot be completely prevented, the system certainly helps reduce the risk of theft.

STARTER KEY



There are two types of starter key, red and black, which can be registered in the Takeuchi Security System. The red key is the master key. The black key is the starting key.


STARTING THE ENGINE



The engine can be started using the normal method with a registered BLACK key. The engine cannot be started using the RED master key.

Refer to Chapter 3, "Starting and stopping the engine".

If an attempt is made to start the engine with an unregistered key:



If an unregistered starter key is turned from the OFF to the ON (ACC) position, the message "Authentication failure" appears and the alarm starts sounding.

If this attempt is repeated five times in a row, the horn sounds for two minutes, and the engine cannot be started. The horn stops when the key is turned to the OFF position.



REGISTERING AND DELETING THE STARTER KEY



WARNING

- Sit on the operator's seat.
- Raise the safety lock lever to the locked position.
- Clear all people from the machine and the area.
- Sound the horn to warn people around the machine.


Registration may fail if the starter key is on a keyring or keychain; remove it before starting registration.

A malfunction could occur if multiple starter keys are brought near to the key cylinder. Be sure that no starter keys other than the correct key are near the key cylinder during registration.


Starter key registration procedure

For Steps 1 to 6 below, complete each step and proceed to the next one within five minutes. If no operation is performed for five minutes during this procedure, the system returns to the initial state.



From Step 7 onward, the system automatically ends the operation if no operation is performed for five minutes.



1. Insert the master key (1) into the starter switch and turn the key from the OFF to the ON (ACC) position.




2. On the LCD, select “REGISTER” and press (A).



3. Select whether to delete all of the existing registration information.



On the LCD, select “YES” and press (A):
All registration information will be deleted;
register a new key.

On the LCD, select “NO” and press (A): A
new starter key will be added to the
existing registration information.




4. When the message “Certification was completed” appears on the LCD, turn the master key (1) from the ON (ACC) to the OFF position, and then remove it from the starter switch.




The number (3) in the lower left indicates the number of starter keys currently registered (only for canopy). Up to 13 starter keys can be registered.




5. Insert the starter key (2) to be registered into the starter switch and turn the key from the OFF to the ON (ACC) position.



6. If the registration was successfully completed, the message "Registration was completed" appears. This means that the starter key (2) currently inserted has been registered.
If the registration fails, the message "Registration failure" appears.



8. Insert the master key (1) into the starter switch and turn the key from the OFF to the ON (ACC) position. Or, wait for five minutes or more.




7. Turn the starter key (2) from the ON (ACC) to the OFF position, and then remove it from the starter switch. To continue registration, repeat the steps from Step 5. To end registration, proceed to Step 8.

9. If any starter key has been registered, the message “All the registration is completed” appears. Turn the master key (1) from the ON (ACC) to the OFF position, and then remove it from the starter switch to complete the registration. If no starter key has been registered, the message “Registration failure” appears, and the registration information is returned to the initial state.




Deleting a registered starter key



The information of each registered starter key can be deleted to cancel its ability to start the engine.



1. Insert the master key (1) into the starter switch and turn the key from the OFF to the ON (ACC) position.




2. On the LCD, select "DELETE" and press (A).




3. When the display shown as the illustration appears on the LCD, turn the master key (1) from the ON (ACC) to the OFF position, and then remove it from the starter switch.

Note: If the registered key is lost and you want to delete all registration information, please refer to STEP 3 (A) on page 8-20.




4. Insert the starter key (2) to be deleted into the starter switch and turn the key from the OFF to the ON (ACC) position.

5. If the deletion is successful, the message "Success" appears. This means that the information registered for the starter key (2) currently inserted has been deleted. If the deletion fails, the message "Failure" or "Authentication failure" appears on the LCD. Remove the starter key, and then repeat the steps from Step 1 again.



6. Turn the starter key (2) from the ON (ACC) to the OFF position, and then remove it from the starter switch. To continue deletion, repeat the steps from Step 1.



**IF THE MASTER KEY IS LOST**

If you lose your master key, contact your service or sales dealer for assistance.

COUNTRIES WHERE THE SYSTEM CAN BE USED

To use the Takeuchi Security System, “radio wave authentication” must be obtained in the country where the system is to be used. The system can be used in the countries listed below, as of January 2017. Do not use the system in other countries. For details on how to disable the system, please contact your service or sales dealer for assistance.

Countries where the system can be used:


Ireland, Italy, UK, Estonia, Austria, Holland, Cyprus, Greece, Croatia, Sweden, Spain, Slovakia, Slovenia, Czech, Denmark, Germany, Hungary, Finland, France, Bulgaria, Belgium, Poland, Portugal, Malta, Latvia, Lithuania, Rumania, Luxemburg, Iceland, Norway, Liechtenstein, Switzerland, Turkey



LED LIGHTS

The power consumption can be reduced by replacing the lights, such as the working light, with LED lights.

If the light fails to turn on after replacement, please contact your sales or service dealer for help.



AM3L001

LED lights package 1

The LED lights are used for the boom light (1), working light (2) and front light (3).


Note: The rear light (4) is not included in the LED lights package 1.



LED lights package 2

The LED lights are used for the boom light (1), working light (2), front light (3) and rear light (4).

The light switch is also changed.



OFF ...Off

ON1 ...The boom light (1), working light (2), front light (3), side lights, tail lamps and the switch lamp are turned on.

ON2 ...The boom light (1), working light (2), front light (3), rear light (4), side lights, tail lamps and the switch lamp are turned on.

First Published October 2013
Seventeenth Published December 2018

OPERATOR'S MANUAL

TB290 Hydraulic excavator

Edited and issued by TAKEUCHI MFG. CO., LTD.

Printed in Japan by STATION M Co., Ltd.



6-2-1 Somejidai, Hamakita-ku, Hamamatsu, Shizuoka 434-0046, Japan

EU DECLARATION of CONFORMITY (DoC)

This declaration of conformity is issued under the sole responsibility of the manufacturer:

Name: ASAHI DENSO CO.,LTD

Address: 6-2-1 Somejidai, Hamakita-ku, Hamamatsu, Shizuoka, 434-0046 Japan

We declare that the DoC is issued under our sole responsibility and belongs to the following product.

Object of the declaration:

Product Name Immobilizer

Model Name CZ156

Accessories N/A

The object of the declaration described above is in conformity with the relevant Union harmonization legislation:

Radio Equipment (RE) Directive (2014/53/EU)

The following harmonized standards and technical specifications have been applied:

Health & Safety
(Article 3.1(a)): EN 60065: 2014

EMC
(Article 3.1(b)): EN 301 489-1 V2.1.1
EN 301 489-3 V2.1.1 (Final draft)

Radio Spectrum
(Article 3.2): EN 300 330 V2.1.1

Japan, Shizuoka

Place of Issue:

May 29, 2017

Date of Issue:

Tomohiro Yaguchi

Tomohiro Yaguchi
Section chief
Engineering Department

Declaration of Conformity

We herewith declare that following named machine, based on its conception and design and in the form brought into service is in accordance with the relevant, basic safety and health requirements of the following EU directives. In case of any alteration of the machine not coordinated with us, this certificate loses its validity.

Designation of the machine Hydraulic Excavator
Manufacturer TAKEUCHI MFG. CO., LTD
 205 Uwadaira, Sakaki-machi, Hanishina-gun, Nagano
 389-0605, Japan

Model TB290 <S/N 185100001~>
Engine type 4TNV98CT-WTB
Engine power 51.6 kW @ 2000 rpm

The machine is in accordance with the requirements of EU directives:

- 1) Machine directive 2006/42/EC and appendix
- 2) Electromagnetic compatibility-regulation 2014/30/EU and appendix
- 3) Noise directive 2000/14/EC (Evaluation procedure according to appendix VI), 2005/88/EC and appendices.
- 4) Regulations on engine emissions: 2004/26/EC and appendices.

Harmonized norms: EN474-1:2006+A1:2009, EN474-5:2006+A2:2012.

Compiler of the technical files:
Hans Friedrich
Oliver Scharschmidt
Wilhelm Schäfer GmbH
68307 Mannheim-Sandhofen GERMANY

Issued in Sakaki, Japan
Akio Takeuchi, President

Declaration of Conformity

We herewith declare that following named machine, based on its conception and design and in the form brought into service is in accordance with the relevant, basic safety and health requirements of the following EU directives. In case of any alteration of the machine not coordinated with us, this certificate loses its validity.

Designation of the machine Hydraulic Excavator
Manufacturer TAKEUCHI MFG. CO., LTD
 205 Uwadaira, Sakaki-machi, Hanishina-gun, Nagano
 389-0605, Japan

Model TB290 <S/N 190200001~>
Engine type AP-4JJ1TASB-01
Engine power 52 kW @ 2000 rpm

The machine is in accordance with the requirements of EU directives:

- 1) Machine directive 2006/42/EC and appendix
- 2) Electromagnetic compatibility-regulation 2014/30/EU and appendix
- 3) Noise directive 2000/14/EC (Evaluation procedure according to appendix VI), 2005/88/EC and appendices.
- 4) Regulations on engine emissions: 2004/26/EC and appendices.

Harmonized norms: EN474-1:2006+A1:2009, EN474-5:2006+A2:2012.

Compiler of the technical files:

Hans Friedrich
Oliver Scharschmidt
Wilhelm Schäfer GmbH
68307 Mannheim-Sandhofen GERMANY

Issued in Sakaki, Japan
Akio Takeuchi, President



WARNING: Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.



WARNING:

Cancer and Reproductive Harm –
www.P65Warnings.ca.gov